




802.11ax-40 CHANNEL 8, SPURIOUS
30 MHz ~ 3 GHz




802.11ax-40 CHANNEL 8, SPURIOUS
2 GHz ~ 25 GHz




802.11ax-40 CHANNEL 9 CARRIER LEVEL



802.11ax-40 CHANNEL 9, SPURIOUS
30 MHz ~ 3 GHz



802.11ax-40 CHANNEL 9, SPURIOUS
2 GHz ~ 25 GHz




Aux. Antenna


802.11b CHANNEL 1 CARRIER LEVEL




802.11b CHANNEL 1, SPURIOUS 30 MHz ~ 3 GHz




802.11b CHANNEL 1, SPURIOUS 2 GHz ~ 25 GHz




802.11b CHANNEL 6 CARRIER LEVEL




802.11b CHANNEL 6, SPURIOUS 30 MHz ~ 3 GHz




802.11b CHANNEL 6, SPURIOUS 2 GHz ~ 25 GHz



802.11b CHANNEL 11 CARRIER LEVEL




802.11b CHANNEL 11, SPURIOUS 30 MHz ~ 3 GHz




802.11b CHANNEL 11, SPURIOUS 2 GHz ~ 25 GHz




802.11g CHANNEL 1 CARRIER LEVEL




802.11g CHANNEL 1, SPURIOUS 30 MHz ~ 3 GHz




802.11g CHANNEL 1, SPURIOUS 2 GHz ~ 25 GHz




802.11g CHANNEL 2 CARRIER LEVEL




802.11g CHANNEL 2, SPURIOUS 30 MHz ~ 3 GHz




802.11g CHANNEL 2, SPURIOUS 2 GHz ~ 25 GHz




802.11g CHANNEL 6 CARRIER LEVEL




802.11g CHANNEL 6, SPURIOUS 30 MHz ~ 3 GHz




802.11g CHANNEL 6, SPURIOUS 2 GHz ~ 25 GHz



802.11g CHANNEL 11 CARRIER LEVEL




802.11g CHANNEL 11, SPURIOUS 30 MHz ~ 3 GHz




802.11g CHANNEL 11, SPURIOUS 2 GHz ~ 25 GHz




802.11n-20 CHANNEL 1 CARRIER LEVEL




802.11n-20 CHANNEL 1, SPURIOUS
30 MHz ~ 3 GHz




802.11n-20 CHANNEL 1, SPURIOUS
2 GHz ~ 25 GHz




802.11n-20 CHANNEL 2 CARRIER LEVEL




802.11n-20 CHANNEL 2, SPURIOUS
30 MHz ~ 3 GHz




802.11n-20 CHANNEL 2, SPURIOUS
2 GHz ~ 25 GHz




802.11n-20 CHANNEL 6 CARRIER LEVEL




802.11n-20 CHANNEL 6, SPURIOUS
30 MHz ~ 3 GHz




802.11n-20 CHANNEL 6, SPURIOUS
2 GHz ~ 25 GHz




802.11n-20 CHANNEL 10 CARRIER LEVEL




802.11n-20 CHANNEL 10, SPURIOUS
30 MHz ~ 3 GHz




802.11n-20 CHANNEL 10, SPURIOUS
2 GHz ~ 25 GHz



802.11n-20 CHANNEL 11 CARRIER LEVEL




802.11n-20 CHANNEL 11, SPURIOUS
30 MHz ~ 3 GHz




802.11n-20 CHANNEL 11, SPURIOUS
2 GHz ~ 25 GHz




802.11n-40 CHANNEL 3 CARRIER LEVEL



802.11n-40 CHANNEL 3, SPURIOUS 30 MHz ~ 3 GHz



802.11n-40 CHANNEL 3, SPURIOUS 2 GHz ~ 25 GHz



802.11n-40 CHANNEL 4 CARRIER LEVEL

