




802.11ac-40 MHz CHANNEL 4, Carrier level




802.11ac-40 MHz CHANNEL 4, Reference level




802.11ac-40 MHz CHANNEL 4, Band Edge




802.11ac-40 MHz CHANNEL 7, Carrier level




802.11ac-40 MHz CHANNEL 7, Reference level




802.11ac-40 MHz CHANNEL 7, Band Edge




802.11ac-40 MHz CHANNEL 8, Carrier level




802.11ac-40 MHz CHANNEL 8, Reference level




802.11ac-40 MHz CHANNEL 8, Band Edge




802.11ac-40 MHz CHANNEL 9, Carrier level




802.11ac-40 MHz CHANNEL 9, Reference level




802.11ac-40 MHz CHANNEL 9, Band Edge




802.11ax-20 MHz CHANNEL 1, Carrier level




802.11ax-20 MHz CHANNEL 1, Reference level




802.11ax-20 MHz CHANNEL 1, Band Edge




802.11ax-20 MHz CHANNEL 2, Carrier level




802.11ax-20 MHz CHANNEL 2, Reference level




802.11ax-20 MHz CHANNEL 2, Band Edge




802.11ax-20 MHz CHANNEL 10, Carrier level




802.11ax-20 MHz CHANNEL 10, Reference level




802.11ax-20 MHz CHANNEL 10, Band Edge




802.11ax-20 MHz CHANNEL 11, Carrier level



802.11ax-20 MHz CHANNEL 11, Reference level




802.11ax-20 MHz CHANNEL 11, Band Edge







802.11ax-40 MHz CHANNEL 3, Carrier level




802.11ax-40 MHz CHANNEL 3, Reference level




802.11ax-40 MHz CHANNEL 3, Band Edge




802.11ax-40 MHz CHANNEL 4, Carrier level




802.11ax-40 MHz CHANNEL 4, Reference level




802.11ax-40 MHz CHANNEL 4, Band Edge




802.11ax-40 MHz CHANNEL 5, Carrier level




802.11ax-40 MHz CHANNEL 5, Reference level




802.11ax-40 MHz CHANNEL 5, Band Edge




802.11ax-40 MHz CHANNEL 7, Carrier level




802.11ax-40 MHz CHANNEL 7, Reference level




802.11ax-40 MHz CHANNEL 7, Band Edge




802.11ax-40 MHz CHANNEL 8, Carrier level




802.11ax-40 MHz CHANNEL 8, Reference level




802.11ax-40 MHz CHANNEL 8, Band Edge




802.11ax-40 MHz CHANNEL 9, Carrier level



802.11ax-40 MHz CHANNEL 9, Reference level




802.11ax-40 MHz CHANNEL 9, Band Edge



MIMO-Aux. Antenna

802.11b CHANNEL 1, Carrier level



802.11b CHANNEL 1, Reference level



802.11b CHANNEL 1, Band Edge

