



802.11ax-20 MHz(SU) CHANNEL 1




802.11ax-20 MHz(SU) CHANNEL 2




802.11ax-20 MHz(SU) CHANNEL 6




802.11ax-20 MHz(SU) CHANNEL 10



802.11ax-20 MHz(SU) CHANNEL 11




802.11ax-40 MHz(SU) CHANNEL 3




802.11ax-40 MHz(SU) CHANNEL 4



802.11ax-40 MHz(SU) CHANNEL 5




802.11ax-40 MHz(SU) CHANNEL 6




802.11ax-40 MHz(SU) CHANNEL 7




802.11ax-40 MHz(SU) CHANNEL 8




802.11ax-40 MHz(SU) CHANNEL 9




802.11ax-20 MHz(RU26) CHANNEL 1




802.11ax-20 MHz(RU26) CHANNEL 2




802.11ax-20 MHz(RU26) CHANNEL 6




802.11ax-20 MHz(RU26) CHANNEL 10




802.11ax-20 MHz(RU26) CHANNEL 11



802.11ax-20 MHz(RU52) CHANNEL 1




802.11ax-20 MHz(RU52) CHANNEL 2




802.11ax-20 MHz(RU52) CHANNEL 6




802.11ax-20 MHz(RU52) CHANNEL 10




802.11ax-20 MHz(RU52) CHANNEL 11




802.11ax-20 MHz(RU106) CHANNEL 1




802.11ax-20 MHz(RU106) CHANNEL 2




802.11ax-20 MHz(RU52) CHANNEL 6




802.11ax-20 MHz(RU52) CHANNEL 10




802.11ax-20 MHz(RU52) CHANNEL 11




802.11ax-40 MHz(RU26) CHANNEL 3




802.11ax-40 MHz(RU26) CHANNEL 4




802.11ax-40 MHz(RU26) CHANNEL 5




802.11ax-40 MHz(RU26) CHANNEL 6




802.11ax-40 MHz(RU26) CHANNEL 7




802.11ax-40 MHz(RU26) CHANNEL 8




802.11ax-40 MHz(RU26) CHANNEL 9




802.11ax-40 MHz(RU52) CHANNEL 3




802.11ax-40 MHz(RU52) CHANNEL 4




802.11ax-40 MHz(RU52) CHANNEL 5




802.11ax-40 MHz(RU52) CHANNEL 6




802.11ax-40 MHz(RU52) CHANNEL 7




802.11ax-40 MHz(RU52) CHANNEL 8




802.11ax-40 MHz(RU52) CHANNEL 9




802.11ax-40 MHz(RU106) CHANNEL 3




802.11ax-40 MHz(RU106) CHANNEL 4




802.11ax-40 MHz(RU106) CHANNEL 5




802.11ax-40 MHz(RU106) CHANNEL 6



802.11ax-40 MHz(RU106) CHANNEL 7



802.11ax-40 MHz(RU106) CHANNEL 8



802.11ax-40 MHz(RU106) CHANNEL 9

