

MIMO-Main Antenna

802.11b CHANNEL 1




802.11b CHANNEL 6




802.11b CHANNEL 11




802.11g CHANNEL 1



802.11g CHANNEL 2




802.11g CHANNEL 3




802.11g CHANNEL 6




802.11g CHANNEL 8




802.11g CHANNEL 9




802.11g CHANNEL 10




802.11g CHANNEL 11




802.11 n-20 MHz CHANNEL 1




802.11n-20 MHz CHANNEL 2




802.11n-20 MHz CHANNEL 3




802.11n-20 MHz CHANNEL 4




802.11n-20 MHz CHANNEL 5




802.11n-20 MHz CHANNEL 6




802.11n-20 MHz CHANNEL 8




802.11n-20 MHz CHANNEL 9




802.11n-20 MHz CHANNEL 10




802.11n-20 MHz CHANNEL 11




802.11n-40 MHz CHANNEL 3




802.11n-40 MHz CHANNEL 4



802.11n-40 MHz CHANNEL 5



802.11n-40 MHz CHANNEL 6



802.11n-40 MHz CHANNEL 7




802.11n-40 MHz CHANNEL 8




802.11n-40 MHz CHANNEL 9




VHT-20 MHz(SU) CHANNEL 1




VHT-20 MHz(SU) CHANNEL 2



VHT-20 MHz(SU) CHANNEL 3




VHT-20 MHz(SU) CHANNEL 4




VHT-20 MHz(SU) CHANNEL 5




VHT-20 MHz(SU) CHANNEL 6




VHT-20 MHz(SU) CHANNEL 8




VHT-40 MHz(SU) CHANNEL 9



VHT-20 MHz(SU) CHANNEL 10



VHT-40 MHz(SU) CHANNEL 11




VHT-40 MHz(SU) CHANNEL 3




VHT-40 MHz(SU) CHANNEL 4



VHT-40 MHz(SU) CHANNEL 5




VHT-40 MHz(SU) CHANNEL 6




VHT-20 MHz(SU) CHANNEL 7




VHT-40 MHz(SU) CHANNEL 8




VHT-20 MHz(SU) CHANNEL 9



802.11ax-20 MHz(SU) CHANNEL 1



802.11ax-20 MHz(SU) CHANNEL 2



802.11ax-20 MHz(SU) CHANNEL 3





802.11ax-20 MHz(SU) CHANNEL 4



802.11ax-20 MHz(SU) CHANNEL 5



802.11ax-20 MHz(SU) CHANNEL 6




802.11ax-20 MHz(SU) CHANNEL 8




802.11ax-20 MHz(SU) CHANNEL 9



802.11ax-20 MHz(SU) CHANNEL 10




802.11ax-20 MHz(SU) CHANNEL 11




802.11ax-40 MHz(SU) CHANNEL 3




802.11ax-40 MHz(SU) CHANNEL 4




802.11ax-40 MHz(SU) CHANNEL 5



802.11ax-40 MHz(SU) CHANNEL 6




802.11ax-40 MHz(SU) CHANNEL 7




802.11ax-40 MHz(SU) CHANNEL 8




802.11ax-40 MHz(SU) CHANNEL 9




802.11ax-20 MHz(RU26) CHANNEL 1




802.11ax-20 MHz(RU26) CHANNEL 2




802.11ax-20 MHz(RU26) CHANNEL 3




802.11ax-20 MHz(RU26) CHANNEL 4




802.11ax-20 MHz(RU26) CHANNEL 5




802.11ax-20 MHz(RU26) CHANNEL 6




802.11ax-20 MHz(RU26) CHANNEL 8




802.11ax-20 MHz(RU26) CHANNEL 9



802.11ax-20 MHz(RU26) CHANNEL 10




802.11ax-20 MHz(RU26) CHANNEL 11




802.11ax-20 MHz(RU52) CHANNEL 1



802.11ax-20 MHz(RU52) CHANNEL 2




802.11ax-20 MHz(RU52) CHANNEL 3




802.11ax-20 MHz(RU52) CHANNEL 4



802.11ax-20 MHz(RU52) CHANNEL 5




802.11ax-20 MHz(RU52) CHANNEL 6




802.11ax-20 MHz(RU52) CHANNEL 8




802.11ax-20 MHz(RU52) CHANNEL 9



802.11ax-20 MHz(RU52) CHANNEL 10



802.11ax-20 MHz(RU52) CHANNEL 11



802.11ax-20 MHz(RU106) CHANNEL 1



802.11ax-20 MHz(RU106) CHANNEL 2



802.11ax-20 MHz(RU106) CHANNEL 3



802.11ax-20 MHz(RU106) CHANNEL 4




802.11ax-20 MHz(RU106) CHANNEL 5




802.11ax-20 MHz(RU106) CHANNEL 6




802.11ax-20 MHz(RU106) CHANNEL 8




802.11ax-20 MHz(RU106) CHANNEL 9




802.11ax-20 MHz(RU106) CHANNEL 10




802.11ax-20 MHz(RU106) CHANNEL 11




802.11ax-40 MHz(RU26) CHANNEL 3




802.11ax-40 MHz(RU26) CHANNEL 4



802.11ax-40 MHz(RU26) CHANNEL 5




802.11ax-40 MHz(RU26) CHANNEL 6







802.11ax-40 MHz(RU26) CHANNEL 7




802.11ax-40 MHz(RU26) CHANNEL 8




802.11ax-40 MHz(RU26) CHANNEL 9




802.11ax-40 MHz(RU52) CHANNEL 3




802.11ax-40 MHz(RU52) CHANNEL 4



802.11ax-40 MHz(RU52) CHANNEL 5



802.11ax-40 MHz(RU52) CHANNEL 6




802.11ax-40 MHz(RU52) CHANNEL 7



802.11ax-40 MHz(RU52) CHANNEL 8



802.11ax-40 MHz(RU52) CHANNEL 9




802.11ax-40 MHz(RU106) CHANNEL 3




802.11ax-40 MHz(RU106) CHANNEL 4



802.11ax-40 MHz(RU106) CHANNEL 5



802.11ax-40 MHz(RU106) CHANNEL 6



802.11ax-40 MHz(RU106) CHANNEL 7



802.11ax-40 MHz(RU106) CHANNEL 8



802.11ax-40 MHz(RU106) CHANNEL 9



802.11ax-40 MHz(RU242) CHANNEL 3



802.11ax-40 MHz(RU242) CHANNEL 4



802.11ax-40 MHz(RU242) CHANNEL 5




802.11ax-40 MHz(RU242) CHANNEL 6



802.11ax-40 MHz(RU242) CHANNEL 7



802.11ax-40 MHz(RU242) CHANNEL 8



802.11ax-40 MHz(RU242) CHANNEL 9



MIMO-Aux. Antenna

802.11b CHANNEL 1




802.11b CHANNEL 6




802.11b CHANNEL 11



802.11g CHANNEL 1



802.11g CHANNEL 2



802.11g CHANNEL 3

