




802.11b CHANNEL 2, SPURIOUS
30 MHz ~ 3 GHz




802.11b CHANNEL 2, SPURIOUS
2 GHz ~ 25 GHz




802.11b CHANNEL 3 CARRIER LEVEL




802.11b CHANNEL 3, SPURIOUS
2 GHz ~ 25 GHz




802.11b CHANNEL 3, SPURIOUS
30 MHz ~ 3 GHz




802.11b CHANNEL 4 CARRIER LEVEL




802.11b CHANNEL 4, SPURIOUS
30 MHz ~ 3 GHz




802.11b CHANNEL 4, SPURIOUS
2 GHz ~ 25 GHz




802.11b CHANNEL 5 CARRIER LEVEL



802.11b CHANNEL 5, SPURIOUS
30 MHz ~ 3 GHz




802.11b CHANNEL 5, SPURIOUS
2 GHz ~ 25 GHz




802.11b CHANNEL 6 CARRIER LEVEL



802.11b CHANNEL 6, SPURIOUS
30 MHz ~ 3 GHz




802.11b CHANNEL 6, SPURIOUS
2 GHz ~ 25 GHz




802.11b CHANNEL 7 CARRIER LEVEL




802.11b CHANNEL 7, SPURIOUS 30 MHz ~ 3 GHz




802.11b CHANNEL 7, SPURIOUS 2 GHz ~ 25 GHz




802.11b CHANNEL 8 CARRIER LEVEL




802.11b CHANNEL 8, SPURIOUS
30 MHz ~ 3 GHz




802.11b CHANNEL 8, SPURIOUS
2 GHz ~ 25 GHz




802.11b CHANNEL 9 CARRIER LEVEL




802.11b CHANNEL 9, SPURIOUS
30 MHz ~ 3 GHz




802.11b CHANNEL 9, SPURIOUS
2 GHz ~ 25 GHz




802.11b CHANNEL 10 CARRIER LEVEL




802.11b CHANNEL 10, SPURIOUS
30 MHz ~ 3 GHz




802.11b CHANNEL 10, SPURIOUS
2 GHz ~ 25 GHz




802.11b CHANNEL 11 CARRIER LEVEL




802.11b CHANNEL 11, SPURIOUS
30 MHz ~ 3 GHz




802.11b CHANNEL 11, SPURIOUS
2 GHz ~ 25 GHz




802.11g CHANNEL 1 CARRIER LEVEL




802.11g CHANNEL 1, SPURIOUS 30 MHz ~ 3 GHz




802.11g CHANNEL 1, SPURIOUS 2 GHz ~ 25 GHz




802.11g CHANNEL 2 CARRIER LEVEL




802.11g CHANNEL 2, SPURIOUS
30 MHz ~ 3 GHz




802.11g CHANNEL 2, SPURIOUS
2 GHz ~ 25 GHz




802.11g CHANNEL 6 CARRIER LEVEL




802.11g CHANNEL 6, SPURIOUS
30 MHz ~ 3 GHz




802.11g CHANNEL 6, SPURIOUS
2 GHz ~ 25 GHz




802.11g CHANNEL 10 CARRIER LEVEL




802.11g CHANNEL 10, SPURIOUS
30 MHz ~ 3 GHz




802.11g CHANNEL 10, SPURIOUS
2 GHz ~ 25 GHz




802.11g CHANNEL 11 CARRIER LEVEL




802.11g CHANNEL 11, SPURIOUS
30 MHz ~ 3 GHz




802.11g CHANNEL 11, SPURIOUS
2 GHz ~ 25 GHz




802.11n-20 MHz CHANNEL 1 CARRIER LEVEL




802.11n-20 MHz CHANNEL 1, SPURIOUS
30 MHz ~ 3 GHz




802.11n-20 MHz CHANNEL 1, SPURIOUS
2 GHz ~ 25 GHz




802.11n-20 MHz CHANNEL 2 CARRIER LEVEL




802.11n-20 MHz CHANNEL 2, SPURIOUS
2 GHz ~ 25 GHz




802.11n-20 MHz CHANNEL 2, SPURIOUS
30 MHz ~ 3 GHz




802.11n-20 MHz CHANNEL 6 CARRIER LEVEL



802.11n-20 MHz CHANNEL 6, SPURIOUS
30 MHz ~ 3 GHz



802.11n-20 MHz CHANNEL 6, SPURIOUS
2 GHz ~ 25 GHz



802.11n-20 MHz CHANNEL 10 CARRIER LEVEL

