


802.11ax-40 MHz(RU52) LOW CHANNEL



802.11ax-40 MHz(RU52) MIDDLE CHANNEL




802.11ax-40 MHz(RU52) HIGH CHANNEL



802.11ax-40 MHz(RU106) LOW CHANNEL



802.11ax-40 MHz(RU106) MIDDLE CHANNEL



802.11ax-40 MHz(RU106) HIGH CHANNEL



802.11ax-40 MHz(RU242) LOW CHANNEL



802.11ax-40 MHz(RU242) MIDDLE CHANNEL



802.11ax-40 MHz(RU242) HIGH CHANNEL



Aux. Antenna

802.11b CHANNEL 1



802.11b CHANNEL 2



802.11b CHANNEL 3



802.11b CHANNEL 4



802.11b CHANNEL 5



802.11b CHANNEL 6



802.11b CHANNEL 11




802.11g CHANNEL 1



802.11g CHANNEL 2



802.11g CHANNEL 3



802.11g CHANNEL 6



802.11g CHANNEL 8



802.11g CHANNEL 9



802.11g CHANNEL 10




802.11g CHANNEL 11



802.11n-20 MHz CHANNEL 1




802.11n-20 MHz CHANNEL 2



802.11n-20 MHz CHANNEL 3




802.11n-20 MHz CHANNEL 6



802.11n-20 MHz CHANNEL 8



802.11n-20 MHz CHANNEL 9



802.11n-20 MHz CHANNEL 10



802.11n-20 MHz CHANNEL 11



802.11n-40 MHz CHANNEL 3



802.11n-40 MHz CHANNEL 5




802.11n-40 MHz CHANNEL 6



802.11n-40 MHz CHANNEL 7



802.11n-40 MHz CHANNEL 9



VHT-20 MHz CHANNEL 1



VHT-20 MHz CHANNEL 2



VHT-20 MHz CHANNEL 3



VHT-20 MHz CHANNEL 6



VHT-20 MHz CHANNEL 8



VHT-20 MHz CHANNEL 9




VHT-20 MHz CHANNEL 10



VHT-20 MHz CHANNEL 11



VHT-40 MHz CHANNEL 3



VHT-40 MHz CHANNEL 5



VHT-40 MHz CHANNEL 6



VHT-40 MHz CHANNEL 7




VHT-40 MHz CHANNEL 9



802.11ax-20 MHz(SU) CHANNEL 1



802.11ax-20 MHz(SU) CHANNEL 2




802.11ax-20 MHz(SU) CHANNEL 3



802.11ax-20 MHz(SU) CHANNEL 6



802.11ax-20 MHz(SU) CHANNEL 8




802.11ax-20 MHz(SU) CHANNEL 9



802.11ax-20 MHz(SU) CHANNEL 10



802.11ax-20 MHz(SU) CHANNEL 11



802.11ax-40 MHz(SU) CHANNEL 3



802.11ax-40 MHz(SU) CHANNEL 5



802.11ax-40 MHz(SU) CHANNEL 6



802.11ax-40 MHz(SU) CHANNEL 7



802.11ax-40 MHz(SU) CHANNEL 9




802.11ax-20 MHz(RU26) LOW CHANNEL




802.11ax-20 MHz(RU26) MIDDLE CHANNEL




802.11ax-20 MHz(RU26) HIGH CHANNEL




802.11ax-20 MHz(RU52) LOW CHANNEL



802.11ax-20 MHz(RU52) MIDDLE CHANNEL



802.11ax-20 MHz(RU52) HIGH CHANNEL




802.11ax-20 MHz(RU106) LOW CHANNEL




802.11ax-20 MHz(RU106) MIDDLE CHANNEL




802.11ax-20 MHz(RU106) HIGH CHANNEL




802.11ax-40 MHz(RU26) LOW CHANNEL




802.11ax-40 MHz(RU26) MIDDLE CHANNEL




802.11ax-40 MHz(RU26) HIGH CHANNEL




802.11ax-40 MHz(RU52) LOW CHANNEL




802.11ax-40 MHz(RU52) MIDDLE CHANNEL




802.11ax-40 MHz(RU52) HIGH CHANNEL




802.11ax-40 MHz(RU106) LOW CHANNEL



802.11ax-40 MHz(RU106) MIDDLE CHANNEL



802.11ax-40 MHz(RU106) HIGH CHANNEL



802.11ax-40 MHz(RU242) LOW CHANNEL



802.11ax-40 MHz(RU242) MIDDLE CHANNEL



802.11ax-40 MHz(RU242) HIGH CHANNEL



MIMO-Main Antenna

802.11b CHANNEL 1



802.11b CHANNEL 2



802.11b CHANNEL 3



802.11b CHANNEL 4



802.11b CHANNEL 5



802.11b CHANNEL 6



802.11b CHANNEL 11




802.11g CHANNEL 1



802.11g CHANNEL 2




802.11g CHANNEL 3



802.11g CHANNEL 6



802.11g CHANNEL 8



802.11g CHANNEL 9




802.11g CHANNEL 10




802.11g CHANNEL 11



802.11n-20 MHz CHANNEL 1




802.11n-20 MHz CHANNEL 2



802.11n-20 MHz CHANNEL 3



802.11n-20 MHz CHANNEL 6



802.11n-20 MHz CHANNEL 8



802.11n-20 MHz CHANNEL 9




802.11n-20 MHz CHANNEL 10



802.11n-20 MHz CHANNEL 11



802.11n-40 MHz CHANNEL 3



802.11n-40 MHz CHANNEL 5




802.11n-40 MHz CHANNEL 6



802.11n-40 MHz CHANNEL 7



802.11n-40 MHz CHANNEL 9



VHT-20 MHz CHANNEL 1



VHT-20 MHz CHANNEL 2



VHT-20 MHz CHANNEL 3



VHT-20 MHz CHANNEL 6




VHT-20 MHz CHANNEL 8



VHT-20 MHz CHANNEL 9



VHT-20 MHz CHANNEL 10



VHT-20 MHz CHANNEL 11

