## Your cellphone .....

### Keys in idle mode



## **7** Getting started ......

### 2.1 Removing the back cover



### 2.2 Inserting your SIM card

To insert your SIM card, turn off your cellphone by holding down the

The SIM compartment on the phone is shaped to fit the SIM card. To place the SIM card inside make sure that both slanted corners on the card and on the phone are matching. Push the SIM card out with your finger to



### 2.3 Inserting and removing your battery

To insert the battery, place the top of the battery first as shown and press down gently. To remove the battery, pull battery up from bottom using index finger.



## . then press again the left softkey to confirm.

select the menu you want by pressing the navigation keys ( ==, iii)

Access the Alarm and Calculator functions



Access functions such as voicemail number call memory call settings, network, forward and call barring.

Messages:

Read, write and send SMS messages. View your messages in your inbox and outbox. Adjust the settings and activate/ deactivate SMS CB (1) message reception.



Access/create directory files and make calls from your directory.



sounds and key been.



Change the main screen wallpaper, colors, power on/off display, screensaver and contrast.



Set the time, date, language, security mode, answer mode, etc...



Play the 2 games embedded in your cellphone.

Services (2) Access the Operator services

### (i) Contact your network operator to check service availability.

<sup>(2)</sup> Depending on your operator's network.

### Menu ...... 4 Main screen icons ......

### Battery charge level.

Vibrate mode (1

Silence mode (

Unread message

Message list is full Unanswered call

Call forwarding activated: your calls are forwarded

Alarm programmed

Signal strength indicator.

Keypad lock.

# Tools......

### Alarm

# = "snooze":The alarm will ring again after 5 minutes. + 🖵 = "cancel"

When the cellphone is switched off, the alarm will ring

### 5.2 Calculator



### 6.1 Making a call

Dial number then press To hang up, press 🖚 0

If you make a mistake, press \_\_\_ . Press and hold to delete all digits.

### Making an emergency call

Dial 911 or other local emergency number and press —. Emergency Send to many: send the message to a group of people you have calls can be performed at anytime without your SIM card or PIN code. defined Once the call has been made, the screen will display: "SOS".

### Making an international call

Hold down • + when "+" is displayed, enter the country and area Discard: discard the message. codes, then complete the number and send the call.

### Calling a number from the directory

Press the end key to access the directory. Select the desired cellphone number and press -.

### 6.2 Calling your voicemail (1)

Press and hold the I on key until connected

### 6.3 Available functions during the call

Access the available options during a call by pressing -.....

## Calls ..... Press = or press and select

### 7.I Create an SMS



and choose your action

Send: send the message to a recipient.

Messages .....

Send to email: send a message to an email address (1).

Save: save the message in the unsent box and send it later.

Templates: use or modify an existing message.

Predictive (T9): select this mode to enter the words more quickly. 123: switch to numeric mode

T9 help: help menu for the predictive mode

### 7.2 Read an SMS

In the inbox, read and unread messages are shown with different icons.

The outbox includes sent and unsent messages.

### 7.3 Inbox/Outbox

Select the message and press and choose your option: Reply/Delete/ Forward message/Archives/Modify/Extract number/Call number.

(1) Contact your network operator for service availability

## Directory .....

You may store up to 250 entries in the phone memory.

### 8.1 Directory menu

ALCATEL

View: access the list contacts (alphabetic order). Create: enter number and name of a new contact.

Delete: delete the selected contact Copy: copy the selected contact from the SIM memory to the phone

memory and vice versa. Caller group: group together names by category.

Select Dir.: select the SIM directory, Phone directory or both at the Vibrate.Beep.Ring: vibrator then warning beep, then tone. same time

space left My number: enter your own cellphone numbers for future reference. 9.2 Volume

Speed Dial: set up speed dial for each key from abc to

### 8.2 Creating a contact

select "create" and enter number and name of a new contact.

### 8.3 Consulting your directory ("View")

Select "Dir." then "View" to access the list of your contacts

### Available options in the contact list

Once you have selected a name, press to access the following options: Call number/Send message/Details/Modify/Delete/Copy/Caller group/ Choose different colors for the presentation of the screen. Search number

### Caller group

You can group together names by category and select a special Set the contrast of your cellphone by choosing one of the 5 levels ringtone. For each group, you can select the following options: proposed. Modify/Ringtone/SMS alert/Members/Add member/Delete all.

9.1 Mode Ringtone: only the tone is played.

will be played anyway).

Vibrate & ring: vibrator and tone at the same time. Vibrate then ring: vibrator then tone.

options in order to customize your cellphone.

Silence: no sound no beep (but the alarms and low battery sound will | 11.3 | Languages Memory status: check the numbers of contacts and the memory be played anyway).

The volume can be adjusted to one of the set levels.

# Olisplay ...... ☑

## 10.1 Wall paper

Select the image you wish to be displayed as the idle screen.

### 10.3 Contrast

### 10.4 Backlight

Select the display backlight duration: 7s, 15s, 20s, 30s.

### From the main screen $\longrightarrow$ and select one of the following | | | | Clock

Set time and date, time format, display (show or hide the clock).

### 11.2 Nitz

Vibrate: only vibrator is set (but the alarms and low battery sound Your phone will automatically adjust to the correct time zone when you travel from one zone to another. Note: This option is on by default; you can access it and change it in "Settings/Clock/Date/ Date format/Nitz setup"

To choose the language in which the messages will be displayed.

### 11.4 Dictionary

creating an SMS, words typed are predicted from this dictionary and my ID. are automatically called if you choose the Predictive Mode (T9).

### 11.5 Auto keypad lock

handset is not in use. From this function you may select a timing of 5 the 1 00 key to reach directly your voice mailbox. to 40 seconds, or to set it "off" if you prefer to lock it manually.

### 11.6 Auto power

II.7 Answer mode

### 11.8 Factory reset

# Settings...... 2 Call services......

12.1 Call memory Each call is displayed with an icon indicating the type of the call.

Select a cellphone number in the list and press — to redial it or **Key functions** press — to access the following options:

Details: display the information of the call selected. Save number: store the number in your directory.

Send message: create an SMS. Call number call the selected number

Modify: modify the number, then call it or save it. Delete: delete the number selected Delete all: delete the entire list.

### 12.2 Call settings (1)

Create, modify or delete a word in your personal dictionary. When Minute alert/Call waiting/Auto redial/Billing/Duration/Amount/Hide the level, the higher the speed.

### 12.3 Call services (1)

MWI - "Message Waiting Indicator". This icone will alert you when you To select the timing for the automatic locking of the keypad when the have a new message in your voice mailbox. Make a long keypress on 3 lives per game.

Contact your network operator for more information.

### 13.1 Russia

From the main screen, press — and your cellphone displays a call list. The object of this game is to make as many complete lines of bricks as possible



Toggle the upgrade level flag; if the flag is on, the game level will move up when your score increases to 300. The level impacts the speed of the bricks : the higher

### 13.2 Bricks

The object of this game is to break as many bricks as possible with a bat and ball.

Miss a ball = lose a life

Bonus depending on the position in which the ball hits the bricks.

### **Key functions**



Alcatel logo and Alcatel name are trademark of Alcatel-Lucent used under license by T&A Mobile Phones Limited.

All rights reserved © Copyright 2007 T&A Mobile Phones Limited.

T&A Mobile Phones Limited reserves the right to alter material or technical specification without prior notice.

Contact your network operator for more information. 10 English - T5002309AAAA 02

-11

12

We recommend that you read this chapter carefully before using your cellphone. The manufacturer's recommended operating temperature range is -20°C to +55°C. Over manufacturer disclaims any liability for damage, which may result as a consequence 55°C the legibility of the cellphone's display may be impaired, though this is of improper use or use contrary to the instructions contained in this manual.

Recent studies show that using a cellphone while driving a vehicle constitutes a real risk, even when the hands-free kit is used (headset...), drivers are requested to refrain from using their cellphone when the vehicle is not parked. Check the laws and regulations on the use of wireless telephones and their accessories in the areas where you drive. Always obey them. The use of these devices may be prohibited or

When switched on, your cellphone emits electromagnetic waves that can interfere with the vehicle's electronic systems such as ABS anti-lock brakes or airbags. To ensure that there is no problem:

- do not place your cellphone on top of the dashboard or within an airbag deployment area.
- check with your dealer or can manufacturer to make sure that the car's electronics devices are well shielded.

### CONDITIONS OF USE

You are advised to switch off your cellphone from time to time to optimize

Switch the cellphone off before boarding aircraft.

Switch the cellphone off when you are in health care facilities, except in designated areas. As with many other types of equipment now in regular use, cellphones can interfere with other electrical or electronic devices, or equipment using radio frequency.

Switch the cellphone off when you are near gas or flammable liquids. Strictly obey all signs and instructions posted in a fuel depot, gas station, or chemical plant, or in any potentially explosive atmosphere.

When the cellphone is switched on, it should be kept at least 15 cm from any medical device such as a pacemaker a hearing aid or insulin pump. When using the cellphone you should hold it against the ear on the opposite side to the device, if any

To avoid hearing impairment press to answer the call before holding your cellphone to your ear. Also move the handset away from your ear while using the "hands-free" option because the amplified volume might cause hearing damage.

Do not let small children use the cellphone without supervision.

When replacing the cover please note that your cellphone may contain substances that could create an allergic reaction.

Always handle your cellphone with care and keep it in a clean and dust-free place. This symbol found on your cellphone, battery and accessories means

CHARGERS: conditions (moisture, humidity, rain, infiltration of liquids, dust, sea air, etc). The

> temporary and not serious. Emergency call numbers may not be reachable on all cellular networks. You should

never rely only on your cellphone for emergency calls.

Do not open, dismantle or attempt to repair your cellphone yourself Do not drop, throw or try to bend your cellphone.

Do not paint it

Use only Alcatel batteries, battery chargers, and accessories that are compatible with In non European Union countries your cellphone model. T&A Mobile Phones Limited or its affiliates disclaim any ltems of equipment with this symbol are not to be thrown into ordinary bins if your liability for damage caused by the use of non approved batteries or accessories. Your cellphone should not be disposed of in a municipal dump. Please check local to be taken to collection points for them to be recycled. In the United Stares you regulations for disposal of electronic products.

Remember to make back-up copies or keep a written record of all important www.recyclewirelessphones.com information stored in your cellphone.

Some people may suffer epileptic seizures or blackouts when exposed to flashing Please note that you must respect the laws and regulations in force in your country THIS CELLPHONE MEETS THE GOVERNMENT'S REQUIREMENTS FOR ments, or disorientation. To limit the likelihood of such symptoms, please take cellphone. the following safety precautions

- Do not play or use a flashing-lights feature if you are tired or need sleep. Take a minimum of a 15 minute break hourly.
- Play in a well lit room

13

- Play at the farthest distance possible from the screen.
- If your hands, wrists, or arms become tired or sore while playing, stop and rest for several hours before playing again.
- If you continue to have sore hands, wrists, or arms during or after playing, stop the game and see a doctor

in your hands, arms, shoulders, neck, or other parts of your body. Follow the istructions to avoid problems such as tendonitis, carpal tunnel syndrome, or other that these products must be taken to collection points at the end of  $\,^{\circ}$  Mains powered chargers will operate within the temperature range: 0°C to 40°C. Municipal waste disposal centers with specific bins for these items of

- Collection bins at points of sale.

They will then be recycled, preventing substances being disposed of i environment, so that their components can be reused.

### In European Union countries:

These collection points are accessible free of charge. All products with this sign must be brought to these collection points.

country or your region has suitable recycling and collection facilities; instead they are 220 V charger: may learn more about CTIA's Recycling Program at Battery: Lithium 650 mAh

### · PRIVACY:

lights, or when playing video games. These seizures or blackouts may occur even if a regarding taking photographs and recording sounds with your cellphone. Pursuant to EXPOSURE TO RADIO WAVES. person never had a previous seizure or blackout. If you have experienced seizures or such laws and regulations, it may be strictly forbidden to take photographs and/or to blackouts, or if you have a family history of such occurrences, please consult your record the voices of other people or any of their personal attributes, and duplicate not to exceed the emission limits for exposure to radio-frequency (RF) energy. These doctor before playing videos games on your cellphone or enabling a flashing-lights or distribute them, as this may be considered to be an invasion of privacy. It is the feature on your cellphone. Parents should monitor their children's use of video user's sole responsibility to ensure that prior authorization be obtained, if necessary, energy for the general population. The guidelines are based on standards that were games or other features that incorporate flashing lights on the cellphones. All in order to record private or confidential conversations or take a photograph of persons should discontinue use and consult a doctor if any of the following another person; the manufacturer, the seller or vendor of your cellphone (including evaluation of scientific studies. These guidelines include a substantial safety margin ymptoms occur: convulsion, eye or muscle twitching, loss of awareness, involuntary the operator) disclaim any liability which may result from the improper use of the

Take precautions with the battery and do not attempt to open the battery (chemical substances may cause burns) Do not pierce, disassemble nor cause a short-circuit in a battery

Batteries must be disposed of in accordance with locally applicable environ

use damaged batteries or not recommended by T&A Mobile Phones Limited and/or regulations and standards must be shown. its affiliates

The chargers designed for your cellphone meet with the standard for safety of NOTE: This equipment has been tested and found to comply with the limits fo information technology equipment and office equipment use. They should be used Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed

T&A Mobile Phones Limited cannot be held liable for any damages due to use

Electrical characteristic of power supply (depending on the country): 110 V charger (Mexico / USA):

Input: 100-127 V, 50/60 Hz, 0.30 A

Output: 4.5 V, 350 mA

Input: 220-240 V, 50/60 Hz, 0.30 A Output: 4.5 V. 350 mA

### • RADIO WAVES:

developed by independent scientific organizations through periodic and thorough designed to ensure the safety of all persons, regardless of age and health.

The exposure standard for cellphones employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by public authorities such as the Canada, is 1.6 W/kg averaged over 1 gram of body tissue. Tests for SAR are conducted using standard operating positions with the cellphone transmitting at its highest certified power level in all tested frequency bands.

Do not burn or dispose of a used battery in household waste or store it at level of the cellphone while operating can be well below the maximum value. This is because the cellphone is designed to operate at multiple power levels so as to use ental only the power required to reach the network. In general, the closer you are to a On our Internet site, you will find our FAQ (Frequently Asked wireless base station antenna, the lower the power output of the cellphone Before Questions) section You can also contact us by e-mail to ask any Batteries should not be used for any other purpose than the one intended. Never a cellphone model is available for sale to the public, compliance with national questions you may have.

The highest SAR value for this cellphone when tested is 1.21 W/kg for use at the ear Your cellphone is a transceiver that operates on PCS networks with and 0.75 W/kg in 2.0 cm distance close to the body.

instruction manual, may cause harmful interference to radio communications.

While there may be differences between the SAR levels of various cellphones and at various positions, they all meet the government requirement for RF exposure. For body-worn operation, the cellphone meets FCC RF exposure guidelines provided Protection against theft (1) that it is used with a non-metallic accessory with the handset at least XXX cm from the body. Use of other accessories may not ensure compliance with FCC RF exposure guidelines.

keep cellphones away from the head and body (fact sheet n° 193). Additional WHO information about electromagnetic fields and public health are available on the following website: http://www.who.int/peh-emf.

Your cellphone is equipped with a built-in antenna. For optimal operation, you should Disclaimen avoid touching it or degrading it

### Hearing Aid Compatibility

phones that may be compatible with their hearing devices. Explanation about rates your cellphone or specific operator services.

- a Substitution of the SAR is determined at the highest certified power level, the actual SAR Hot Line Number: see the "TCL & Alcatel Mobile Phones Services" leaflet or go to our Internet site.

850 and 1900 MHz bands

The **CE** marking indicates that your cellphone complies with to provide reasonable protection against harmful interference when the equipment "1999/5/EC (R&TTE)" directive and that the accessories concerned The charger in this package shall ONLY be used with Alcatel OT-E206A. The use on is operated in a commercial environment. This equipment generates, uses, and can comply with current EC directives. The entire copy of the Declaration any other product or equipment including Alcatel products is strictly prohibited.

radiate radio frequency energy and, if not installed and used in accordance with the of Conformity for your cellphone can be obtained through our website: www.tctmobile.com.

Your cellphone is identified by an IMEI (cellphone serial number) shown on the packaging label and in the product's memory. We The World Health Organization (WHO) considers that present scientific recommend that you note the number the first time you use your information does not indicate the need for any special pregautions for use of cellphone by entering \* # 0.6 # and keep it in a safe place It may be cellphones. If individuals are concerned, they might choose to limit their own or their requested by the police or your operator if your cellphone is stolen. children's RF exposure by limiting the length of calls, or using "hands-free" devices to

This number allows your cellphone to be blocked preventing a third person from using it, even with a different SIM card.

There may be certain differences between the user manual description Your telephone has "rated for hearing aid". To assist hearing devices users in finding and the cellphone's operation depending on the software release of



T9 Text Input is licensed under one or more of the following: U.S. Pat. Nos. 5,187,480, 5,818,437, 5,945,928, 5,953,541, 6,011,554, 6,286,064, 6,307,548, 6,307,549, and 6,636,162, 6,646,573; European Pat. Nos. 0 842 463 (96927260.8), I 010 057 (98903671.0), I 018 069 (98950708.2); and additional patents are pending worldwide

## Cellphone warranty .....

Congratulations on choosing this cellphone - we hope that you will be completely satisfied with it.

a period of twelve (12) months from the date specified on your original invoice (1). The warranty terms defined in the manual also apply to the battery and accessories sold with the cellphone but for a period of six (6) months (2) from the date of 6) purchase shown on your original invoice.

Under the terms of this warranty you must immediately inform your vendor (or any repair center approved by T&A Mobile Phones Limited or its affiliates, which are 7) listed on our website http://www.tctmobile.com) in case of a conformity defect on 8) your cellphone, you must present the invoice given to you at the time of purchase. 9) The vendor or maintenance center will decide whether to replace or repair as appropriate all or any part of the cellphone or accessory found to be defective; this 10) modifications made to the equipment even if required by changes in regulations. • Check the battery contacts, remove and reinstall your battery, then warranty covers the cost of parts and labor but excludes any other costs. Repair or replacement may be carried out using reconditioned components offering equivalent II) faulty connections resulting from unsatisfactory radio transmission or caused by functionality

Servicing under the terms of this warranty, especially repair, modification or replacement of products, shall entitle to a ONE (I) month (I) warranty unless there are statutory provisions to the contrary.

This warranty shall not apply to damage or defects to your cellphone and/or In accordance with the applicable law, your product is warranted against hidden accessory caused by:

1) failure to follow the instructions for use or installation

are applicable in your country.

2) failure to comply with technical and safety standards applicable in the geographical area where the equipment is used,

- 3) improper maintenance of batteries and other sources of energy, and of the overall electric installation accidents or consequences of theft of the vehicle in which the cellphone is
- connecting or integrating the cellphone into equipment not supplied or not Your cellphone is guaranteed against any deviation from technical specifications for 5)
  - any servicing, modification or repair performed by individuals not authorized by T&A Mobile Phones Limited or its affiliates, the vendor or the approved
  - use of the equipment for a purpose other than that for which it was designed.
  - malfunctions caused by external causes (e.g., radio interference from other equipment, power or cellphone line voltage fluctuations),
  - and/or modification of network parameters,
  - the absence of radio relay coverage. 12) equipment on which markings or serial numbers have been removed or altered, • Clean your screen

excluded from the warranty. defects (defects inherent in the design, manufacture, etc.).

There are no express warranties, whether written or oral, other than this printed limited warranty, express or implied, of any nature whatsoever

In no event shall T&A Mobile Phones Limited or its affiliates be liable for incidental • Check the battery charge level or consequential damages of any nature whatsoever, including but not limited to • Check that the function "Auto OFF" is not activated. trading loss, commercial loss, to the full extent those damages can be disclaimed by law Some countries/states do not allow the exclusion or limitation of incidental or consequential damages, or limitation of the duration of implied warranties, so the preceding limitations or exclusions may not apply to you

transported, acts of vandalism, lightning, fire, humidity, infiltration of liquids, Before contacting your retailer or service center, it is recommended

- Switch off the cellphone from time to time to optimize its
- Fully charge the battery ( ) for optimal operation
- affect the performance of your cellphone

### My cellphone does not switch on

- Press until the screen comes on.
- Check the battery charge level
- turn your cellphone back on

### My screen is difficult to read

- and handsets on which labels have been removed or deteriorated shall be Use your cellphone in accordance with the recommended Make sure the SIM card was correctly inserted

- · Check that your keypad is locked when you are not using your

### My cellphone does not charge properly

battery charge indicator can take several minutes and may be accompanied by a quiet hissing sound.

- Make sure charging is carried out under normal conditions (0°C
- Make sure your battery is inserted. It must be inserted before Make sure that you have not barred certain calls plugging in the charger
- When abroad, check that the electrical current is compatible

### My cellphone does not connect to a network

- Try connecting in another location
- · Verify the network coverage with your operator
- · Check with your operator that your SIM card is valid
- Try connecting at a later time if the network is overloaded

### SIM card error

- old 5V SIM cards cannot be used
- Make sure the chip on your SIM card is not damaged or scratched

### Unable to make outgoing calls

- For international calls, make sure you have entered the country and area codes
- Check your subscription with your operator (credit, SIM card valid,
- Make sure you have not barred outgoing calls

### Unable to receive incoming calls

- network (check for overloaded or unavailable network)
  - Check your subscription with your operator (credit, SIM card valid,
  - Make sure you have not forwarded incoming calls

### The caller's name does not appear when a call is received

Check that you have subscribed to this service with your operator

### Your caller has concealed his/her number

- The sound quality of the calls is not optimal
- You can adjust the volume during a call by means of the

### 

I am unable to use the features described in the manual • Check with your operator to make sure that your subscription includes this service

## Check to be sure this feature does not require an Alcatel accessory.

· Make sure that you have correctly recorded the number in your file Make sure that you have selected the country prefix when calling a

### I am unable to create a file in my directory

the files in the product directory

### Mv callers are unable to leave messages on my voicemail

(i) Contact your network operator for service availability

- Contact your network operator to check service availability I can't access my voicemail
- Make sure your operator's voicemail number is correctly entered in
- . Try later if the network is busy

### I am unable to send and receive messages

- · Check your phone memory as it might be full, if necessary, delete
- Contact your network operator to check service availability, see the
- Verify the server center number with your operator
- The server center may be saturated: try again later

I have already entered 3 incorrect PIN codes • Contact your network operator to obtain the PUK code (Personal

conversation time standby time and total service life will depend

200 more recharges.

(1) The mandatory period may vary if overriding statutory provisions

(2) The life of a rechargeable Alcatel cellphone battery in terms of on the conditions of use and network configuration. Batteries being considered expendable supplies, the specifications state that you should obtain optimal performance for your Alcatel cellphone during the first six months after purchase and for approximately

- you try the following steps below: recommended by T&A Mobile Phones Limited or its affiliates, without their

  - Avoid storing large amounts of data in your cellphone as this may Make sure you are using an Alcatel battery and charger

My cellphone turns off by itself

Try selecting the available network(s) manually

- Verify with your operator that your SIM card is 3V compatible; the

- Make sure you have dialed a valid number and pressed the 
   key
- Make sure your cellphone is connected to a network, and that the network is not overloaded or unavailable

- "Call services/Voicemail"
- some messages
- messages settings

The << - >> icon is displayed When I select a number from my directory, the number is . You are outside the network coverage area

23 20 22