

Your cellphone.....



- 1 Left softkey
- 2 Call log (idle screen)
Activate fake call (long keypress)
Send call
- 3 Voicemail
- 4 Lock/Unlock
- 5 Right softkey
- 6 Power on/Power off
End call
Deactivate the Torch
- 7 Vibration alert
- 8 Navigation key :
Menu/Confirm an option ○/◇
- 9 Profiles
- 10 Organizer
- 11 Create message
- 12 Alarm
- 13 Torch

⚠ Prolonged exposure to music at full volume on the music player may damage the listener's hearing. Set your cellphone volume safely. Use only headphones recommended by TCT Mobile Limited and its affiliates.

OT-104A
OT-209A
ALCATEL
mobile phones

1.1 Keys

- Navigation key
Confirm an option (press the middle of the key)
Activate/Deactivate LCD backlights ⁽¹⁾ (long keypress ○ in idle screen)
Access favorite contact(s) ⁽²⁾ (long keypress ◇ in idle screen)
- Send call
Access to call log (idle screen)
Activate Fake call (long keypress)
- Power on/off the handset (long keypress)
- End call
Return to idle
- Left softkey
- Right softkey
- Dial the voicemail number (long keypress)
- In edit mode
- Short keypress: access the language list
- Long keypress: enter zero
- In Edit mode:
- Short keypress: change input methods
- Long keypress: access the Symbols table
- From Idle screen
- Short keypress: #
- Long keypress: activate/deactivate the vibrator
- In edit mode:
- Short keypress: ␣ (space)
- Long keypress: add a word
- From Idle screen
- Short keypress: dial '5'
- Long keypress: switch on/off the torch

⁽¹⁾ OT-104A only.
⁽²⁾ OT-209A only.

1.2 Idle screen icons

- Battery charge level.
- Vibration alert: your cellphone vibrates, but neither rings nor beeps.
- Headset connected ⁽¹⁾.
- Call forwarding activated: your calls are forwarded.
- Alarm clock programmed.
- Voicemail message arrived ⁽²⁾.
- FM radio is on ⁽³⁾.
- Unanswered calls ⁽⁴⁾.
- Roaming.
- Level of network reception.
- Silence mode: your cellphone neither rings, beeps nor vibrates.
- Message unread.
- Keypad locked.
- Stopwatch is active ⁽⁵⁾.
- Ringtone alert ⁽⁶⁾.
- Vibration and ringtone alert ⁽⁷⁾.

⁽¹⁾ OT-104A only.
⁽²⁾ OT-209A only.

2 Getting started

2.1 Set-up

Removing and installing the back cover

Installing and removing the battery

Inserting and removing the SIM Card

Place the SIM card with the chip facing downwards and slide it into its housing. Make sure that it is correctly inserted. To remove the card, press it and slide it out.

2.2 Power on your cellphone
Hold down the key until the cellphone powers on.

2.3 Power off your cellphone
Hold down the key from the idle screen.

3 Calls

3.1 Making a call

Dial the desired number then press the key to place the call. If you make a mistake, you can delete the incorrect digits by pressing the right softkey.

To hang up the call, press the key.

Making an emergency call
If your phone is covered by the network, dial emergency number and press the key to make an emergency call. This works even without a SIM card and without typing the PIN code or unlocking the keypad.

3.2 Calling your voicemail ⁽¹⁾
To access your voicemail, hold down the key.

3.3 Receiving a call
When you receive an incoming call, press the key to talk and then hang up using the key.

3.4 Available functions during the call
During a call, you can use your directory, short messages, etc. without losing your correspondent.

4 Call register

4.1 Unanswered

In this menu, you can find the unanswered calls list.

4.2 Outgoing calls
In this menu, you can find the outgoing calls list.

4.3 Answered calls
In this menu, you can find the answered calls list.

4.4 My numbers
Type in or modify your cellphone number or the number to access your voicemail and confirm by pressing . Your cellphone number is usually written on your SIM card.

4.5 Billing
You can access different items with this option: Amount, Duration.

4.6 Call settings
You can access a number of items with this option: Caller ID, Call waiting, Call forward, Answer mode, Call barring...

4.7 Call control ⁽¹⁾
The menu serves you the dual purposes of cost monitoring and controlling during a call by the settings of "By cost" and "By duration".

⁽¹⁾ Contact your network operator to check service availability.

⁽¹⁾ Depending on your network operator.

5 Directory.....

5.1 Consulting your directory

To access the **directory** from the idle screen, press the key and select the icon from the menu.

5.2 Adding a contact

Select the directory in which you wish to create a file, press the "Options" softkey, select "Add contact" then .

7 Settings

From the main menu, select the menu icon and select the function of your choice in order to customize your cellphone: Display, Clock, Keys, Power saving ⁽¹⁾, Dictionary, More settings...

6 Messages

6.1 Create SMS

From the main menu select "Messages" to create text message. You can type a message, and you're also able to insert a pre-defined message from "Templates". While writing a message, select "Options" to access all the messaging options. You can save your messages that you send often to "Drafts".

8 Tools ⁽¹⁾ Games & Tools ⁽²⁾

8.1 Games ⁽²⁾
Your Alcatel cellphone includes some games. Select "Game settings", it allows you to manage settings, in which you may set background audio and vibration alert.

8.2 Organizer
Once you enter this menu, there is a monthly-view calendar for you to keep track of important appointments, etc. Days with events entered will be marked.

8.3 Stopwatch
Stopwatch is simple application for measuring time with possibility to register several results and suspend/resume measurement.

8.4 Alarm

Your cellphone has a built-in alarm clock with snooze feature.

8.5 Calculator

Hold down the key to get the decimal point. Confirm with the key or the left softkey.

8.6 Converter

Unit converter and Currency converter.

8.7 Fake Call

Protect yourself from annoying situations with the "Fake Call". In this menu, you can set "Caller's name", "Call time" and "Ring tone". When the timer reaches, the cellphone will ring and display like receiving a real cellphone call. Press key, pretend answering a call, the screen will display just like have an ongoing call. Press key, pretend reject the call, the call will terminate automatically.

8.8 Torch

To light in darkness, you may activate "Torch" by below operations:
In idle screen, long keypress key to activate the Torch light; short keypress key or Long keypress key to deactivate it.

9 Games ⁽¹⁾

Your Alcatel cellphone may include some games.

9.1 Game settings

It allows you to manage settings, in which you may set background audio and vibration alert.

12 Profiles.....

With this menu, you may personalize ringtones for different events and environments.

13 Services

Contact your network operator to check service availability.

10 FM Radio ⁽²⁾

Your cellphone is equipped with an FM radio ⁽¹⁾ with RDS functionality. You can use the application as a traditional FM radio with automatic tuning and saved channels or with parallel visual information related to the radio program on the display, if you tune to stations that offer Visual Radio service. You can listen to it while running other applications.

11 My shortcuts.. ⁽¹⁾ ⁽²⁾

Access the shortcuts already programmed. To program new shortcuts: select "Add" if you want to create a quick access to functions, Numbers, Channel list ⁽³⁾, etc.

⁽¹⁾ OT-104A only.
⁽²⁾ OT-209A only.
⁽³⁾ The quality of the radio depends on the coverage of the radio station in that particular area.

ALCATEL is a trademark of Alcatel-Lucent and used under license by TCT Mobile Limited.
All rights reserved © Copyright 2010 TCT Mobile Limited.
TCT Mobile Limited reserves the right to alter material or technical specification without prior notice.

Safety and use

We recommend that you read this chapter carefully before using your cellphone. The manufacturer disclaims any liability for damage, which may result as a consequence of improper use or use contrary to the instructions contained herein.

- **TRAFFIC SAFETY:**
 - **That studies show that using a cellphone while driving a vehicle constitutes a real risk, even when the hands-free kit is used (car kit, headset...), drivers are requested to refrain from using their cellphone when the vehicle is not parked. Check the laws and regulations on the use of wireless cellphones and their accessories in the areas where you drive. Always obey them. The use of these devices may be prohibited or restricted in certain areas.**

When driving, do not use your cellphone and headphone to listen to music or to the radio. Using a headphone can be dangerous and forbidden in some areas.

When switched on, your cellphone emits electromagnetic waves that can interfere with the vehicle's electronic systems such as ABS anti-lock brakes or airbags. To ensure that there is no problem:

- do not place your cellphone on top of the dashboard or within an airbag deployment area,
- check with your car dealer or the car manufacturer to make sure that the car's electronic devices are shielded from cellphone RF energy.

• **CONDITIONS OF USE:**
You are advised to switch off the cellphone from time to time to optimize its performance.

Switch the cellphone off before boarding an aircraft to avoid prosecution. Switch the cellphone off when you are in health care facilities, except in designated areas. As with many other types of equipment now in regular use, cellphones can interfere with other electrical or electronic devices, or equipment using radio frequency.

Switch the cellphone off when you are near gas or flammable liquids. Strictly obey all signs and instructions posted in a fuel depot, gas station, or chemical plant, or in any potentially explosive atmosphere.

When the cellphone is switched on, it should be kept at least 15 cm from any medical device such as a pacemaker, a hearing aid or insulin pump. In particular when using the cellphone you should hold it against the ear on the opposite side to the device, if any.

To avoid hearing impairment, answer the call before holding your cellphone to your ear. Also move the handset away from your ear while using the "hands-free" option because the amplified volume might cause hearing damage.

Do not let children use the cellphone and/or play with the cellphone and accessories without supervision.

When replacing the cover please note that your cellphone may contain substances that could create an allergic reaction.

Always handle your cellphone with care and keep it in a clean and dust-free place.

Do not allow your cellphone to be exposed to adverse weather or environmental conditions (moisture, humidity, rain, infiltration of liquids, dust, sea air, etc.). The manufacturer's recommended operating temperature range is -10°C to +55°C (the max value depends on device, materials and housing paint/texture). Over 55°C the legibility of the cellphone's display may be impaired, though this is temporary and not serious.

Do not open or attempt to repair your cellphone yourself. Do not drop, throw or try to bend your cellphone. Do not paint it.

Use only batteries, battery chargers, and accessories which are recommended by TCT Mobile Limited and its affiliates and are compatible with your cellphone model. TCT Mobile Limited and its affiliates disclaim any liability for damage caused by the use of other chargers or batteries.

Your cellphone should not be disposed of in a municipal waste. Please check local regulations for disposal of electronic products.


Remember to make back-up copies or keep a written record of all important information stored in your cellphone.

Some people may suffer epileptic seizures or blackouts when exposed to flashing lights, or when playing video games. These seizures or blackouts may occur even if a person never had a previous seizure or blackout. If you have experienced seizures or blackouts, or if you have a family history of such occurrences, please consult your doctor before playing video games on your cellphone or enabling a flashing-lights feature on your cellphone. Parents should monitor their children's use of video games or other features that incorporate flashing lights on the cellphones. All persons should discontinue use and consult a doctor if any of the following symptoms occur: convulsion, eye or muscle twitching, loss of awareness, involuntary movements, or disorientation. To limit the likelihood of such symptoms, please take the following safety precautions:

- Do not play or use a flashing-lights feature if you are tired or need sleep.
- Take a minimum of a 15-minute break hourly.
- Play in a well lit environment.
- Play at the farthest distance possible from the screen.

When you play games on your cellphone, you may experience occasional discomfort in your hands, arms, shoulders, neck, or other parts of your body. Follow these instructions to avoid problems such as tendinitis, carpal tunnel syndrome, or other musculoskeletal disorders:

- Take a minimum of a 15-minute break every hour of game playing.
- If your hands, wrists, or arms become tired or sore while playing, stop and rest for several hours before playing again.
- If you continue to have sore hands, wrists, or arms during or after playing, stop the game and see a doctor.


 Prolonged exposure to music at full volume on the music player may cause the listener's hearing impairment. Adjust the volume before placing headphones on or in your ear. Only use headphones recommended by TCT Mobile Limited and its affiliates.

• **PRIVACY:**
Please note that you must respect the laws and regulations in force in your jurisdiction or other jurisdiction(s) where you will use your cellphone regarding taking photographs and recording sounds with your cellphone. Pursuant to such laws and regulations, it may be strictly forbidden to take photographs and/or to record the voices of other people or any of their personal attributes, and reproduce or distribute them, as this may be considered to be an invasion of privacy. It is the user's sole responsibility to ensure that prior authorization be obtained, if necessary, in order to record private or confidential conversations or take a photograph of another person; the manufacturer, the seller or vendor of your cellphone (including the operator) disclaim any liability which may result from the improper use of the cellphone.

• **BATTERY AND ACCESSORIES:**
Before removing the battery from your cellphone, please make sure that the cellphone is switched off.

- Observe the following precautions for battery use:
- Do not attempt to open the battery (due to the risk of toxic fumes and burns).
- Do not puncture, disassemble or cause a short-circuit in a battery.
- Do not burn or dispose of a used battery in the garbage or store it at temperatures above 60°C.

Batteries must be disposed of in accordance with locally applicable environmental regulations. Only use the battery for the purpose for which it was designed. Never use damaged batteries or those not recommended by TCT Mobile Limited and/or its affiliates

 This symbol on your cellphone, the battery and the accessories means that these products must be taken to collection points at the end of their life:

- Municipal waste disposal centers with specific bins for these items of equipment
- Collection bins at points of sale.

They will then be recycled, preventing substances being disposed of in the environment, so that their components can be reused.

In European Union countries:
These collection points are accessible free of charge. All products with this sign must be brought to these collection points.

In non European Union jurisdictions:
Items of equipment with this symbol are not to be thrown into ordinary bins if your jurisdiction or your region has suitable recycling and collection facilities; instead they are to be taken to collection points for them to be recycled.

In the United States you may learn more about CTIA's Recycling Program at www.recyclewirelessphones.com

CAUTION: RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS

• **CHARGERS**
Home A.C. chargers will operate within the temperature range of 0°C to 40°C. The chargers designed for your cellphone meet with the standard for safety of information technology equipment and office equipment use. Due to different applicable electrical specifications, a charger you purchased in one jurisdiction may not work in another jurisdiction. They should be used for this purpose only.

Characteristics of power supply (depending on the country):
Travel charger: Input : 100-240V, 50/60 Hz, 0.15 A
Output : 5 V, 350 mA

Lithium 500 mAh
• **RADIO WAVES:**
THIS CELLPHONE MEETS THE GOVERNMENT'S REQUIREMENTS FOR EXPOSURE TO RADIO WAVES.

Your cellphone is a radio transmitter and receiver. It is designed and manufactured not to exceed the emission limits for exposure to radio-frequency (RF) energy. These limits are part of comprehensive guidelines and establish permitted levels of RF energy for the general population. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. These guidelines include a substantial safety margin designed to ensure the safety of all persons, regardless of age and health.

The exposure standard for cellphones employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by public authorities such as the Federal Communications Commission of the US Government (FCC), or by Industry Canada, is 1.6 W/Kg averaged over 1 gram of body tissue. Tests for SAR are conducted using standard operating positions with the cellphone transmitting at its highest certified power level in all tested frequency bands. Although the SAR is determined at the highest certified power level, the actual SAR level of the cellphone while operating can be well below the maximum value. This is because the cellphone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output of the cellphone. Before a cellphone model is available for sale to the public, compliance with national regulations and standards must be shown.

The highest SAR value for this model cellphone when tested is:

- OT-104A: 1.1 W/Kg for use at the ear and 0.735 W/Kg for use close to the body.
- OT-209A: 1.16 W/Kg for use at the ear and 0.796 W/Kg for use close to the body.

While there may be differences between the SAR levels of various cellphones and at various positions, they all meet the government requirement for RF exposure. For body-worn operation, the cellphone meets FCC RF exposure guidelines provided that it is used with a non-metallic accessory with the handset at least 1.5 cm from the body. Use of other accessories may not ensure compliance with FCC RF exposure guidelines. The World Health Organization (WHO) considers that present scientific information does not indicate the need for any special precautions for use of cellphones. If individuals are concerned, they might choose to limit their own or their children's RF exposure by limiting the length of calls, or using "hands-free" devices to keep cellphones away from the head and body. (fact sheet n°193). Additional WHO information about electromagnetic fields and public health are available on the following website: <http://www.who.int/peh-emf>.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

For the receiver devices associated with the operation of a licensed radio service (e.g. FM broadcast), they bear the following statement:


This device complies with Part 15 of the FCC Rules. Operation is subject to the condition that this device does not cause harmful interference.

For other devices, they bear the following statement:
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Your cellphone is equipped with a built-in antenna. For optimal operation, you should avoid touching it or degrading it.

As mobile devices offer a range of functions, they can be used in positions other than against your ear. In such circumstances the device will be compliant with the guidelines when used with headset or USB data cable. If you are using another accessory ensure that whatever product is used is free of any metal and that it positions the cellphone at least 2cm away from the body.

• **LICENCES**
 eZiText™ and Zi™ are trademarks of Zi Corporation and/or its Affiliates.

General information

• **Website:** www.alcatel-mobilephones.com
On our Internet site, you will find our FAQ (Frequently Asked Questions) section. You can also contact us by e-mail to ask any questions you may have.

An electronic version of this user guide is available in English and other languages according to availability on our server: www.alcatel-mobilephones.com

Your cellphone is a transceiver that operates on GSM networks with 850 and 1900 MHz bands.

Protection against theft ⁽¹⁾

Your cellphone is identified by an IMEI (cellphone serial number) shown on the packaging label and in the product's memory. We recommend that you note the number the first time you use your cellphone by entering *#06# and keep it in a safe place. It may be requested by the police or your operator if your cellphone is stolen. This number allows your cellphone to be blocked preventing a third person from using it, even with a different SIM card.

Disclaimer

There may be certain differences between the user manual description and the cellphone's operation, depending on the software release of your cellphone or specific operator services.

⁽¹⁾ Contact your network operator for service availability.

Cellphone warranty.....

Your cellphone is warranted against any defect which may occur in conditions of normal use during the warranty period of twelve (12) months⁽¹⁾ from the date of purchase as shown on your original invoice. Batteries⁽²⁾ and accessories sold with your cellphone are also warranted against any defect which may occur during the first six (6) months⁽¹⁾ from the date of purchase as shown on your original invoice. In case of any defect of your cellphone which prevents you from normal use thereof, you must immediately inform your vendor and present your cellphone with a proof of purchase.

If the defect is confirmed, your cellphone or part thereof will be either replaced or repaired, as appropriate. Repaired cellphone and accessories are entitled to a one (1) month warranty for the same defect. Repair or replacement may be carried out using reconditioned components offering equivalent functionality. This warranty covers the cost of parts and labor but excludes any other costs.

This warranty shall not apply to defects to your cellphone and/or accessory due to (without any limitation):

- 1) Non-compliance with the instructions for use or installation, or with technical and safety standards applicable in the geographical area where your cellphone is used,
- 2) Connection to any equipment not supplied or not recommended by TCT Mobile Limited,
- 3) Modification or repair performed by individuals not authorized by TCT Mobile Limited or its affiliates or your vendor,
- 4) Inclement weather, lightning, fire, humidity, infiltration of liquids or foods, chemical products, download of files, crash, high voltage, corrosion, oxidation...


Your cellphone will not be repaired if case labels or serial numbers (IMEI) have been removed or altered.

There are no express warranties, whether written, oral or implied, other than this printed limited warranty or the mandatory warranty provided by your jurisdiction.


In no event shall TCT Mobile Limited or any of its affiliates be liable for incidental or consequential damages of any nature whatsoever, including but not limited commercial loss, to the full extent those damages can be disclaimed by law. Some countries/states do not allow the exclusion or limitation of incidental or consequential damages, or limitation of the duration of implied warranties, so the preceding limitations or exclusions may not apply to you.


Troubleshooting.....

Before contacting the aftersales department, you are advised to follow the instructions below:

- You are advised to switch off the cellphone from time to time to optimize its performance.
- You are advised to fully charge () the battery for optimal operation.
- Avoid storing large amounts of data in your cellphone as this may affect the performance of your cellphone.

and carry out the following checks:

- **My cellphone will not switch on**
 - Press  until the screen comes on
 - Check the battery charge level
 - Check the battery contacts, remove and reinstall your battery, then turn your cellphone back on

- **My cellphone has not responded for several minutes**
 - Press the  key
 - Remove the battery and re-insert it, then switch the cellphone back on

- **My screen is difficult to read**
 - Clean your screen
 - Use your cellphone in accordance with the recommended conditions of use

- **My cellphone turns off by itself**
 - Check that your keypad is locked when you are not using your cellphone
 - Check the battery charge level

My cellphone has a low level of autonomy

- Make sure you respected the complete charge timing (minimum 3 hours)
- After a partial charge, the battery level indicator may not be exact. Wait for at least 20 minutes after removing the charger to obtain an exact indication

My cellphone will not charge properly


- Make sure that your battery is not completely discharged; the battery charge indicator can take several minutes and may be accompanied by a quiet whistling sound
- Make sure charging is carried out under normal conditions (0°C +40°C)
- Make sure your battery is inserted. It must be inserted **before** plugging in the charger
- Make sure you are using an Alcatel battery and charger in the box
- When abroad, check that the electrical current is compatible

My cellphone will not connect to a network

- Try connecting in another location
- Verify the network coverage with your operator
- Check with your operator that your SIM card is valid
- Try selecting the available network(s) manually
- Try connecting at a later time if the network is overloaded

- **SIM card error**
 - Make sure the SIM card has been correctly inserted
 - Verify with your operator that your SIM card is 3V or 1.8V compatible; the old 5V SIM cards cannot be used
 - Make sure the chip on your SIM card is not damaged or scratched

Unable to make outgoing calls

- Make sure you have dialled a valid number and press the  key
- For international calls, check the country and area codes
- Make sure your cellphone is connected to a network, and that the network is not overloaded or unavailable
- Check your subscription status with your operator (credit, SIM card valid, etc.)
- Make sure you have not barred outgoing calls

Unable to receive incoming calls

- Make sure your cellphone is switched on and connected to a network (check for overloaded or unavailable network)
- Check your subscription status with your operator (credit, SIM card valid, etc.)
- Make sure you have not forwarded incoming calls
- Make sure that you have not barred certain calls

The caller's name does not appear when a call is received

- Check that you have subscribed to this service with your operator
- Your caller has concealed his/her number

The sound quality of the calls is not optimal

- You can adjust the volume during a call by means of the  key
- Check the network strength 

I am unable to use the features described in the manual

- Check with your operator to make sure that your subscription includes this service
- Make sure this feature does not require an Alcatel accessory

When I select a number from my directory, the number is not dialled

- Make sure that you have correctly recorded the number in your file
- Make sure that you have selected the country prefix when calling a foreign country

I am unable to create a file in my directory

- Make sure that your SIM card directory is not full; delete some files or save the files in the product directory (i.e. your professional or personal directories)

My callers are unable to leave messages on my voicemail

- Contact your network operator to check service availability

⁽¹⁾ The warranty period may vary depending on your country.

⁽²⁾ The life of a rechargeable cellphone battery in terms of conversation time standby time, and total service life, will depend on the conditions of use and network configuration. Batteries being considered expendable supplies, the specifications state that you should obtain optimal performance for your cellphone during the first six months after purchase and for approximately 200 more recharges.