one touch | \(\O\O\D\)

Your cellphone.....

Navigation key:

an option (

Profiles A

Create new

message 🜗

Switch on/

Switch off

End call

Calls 🔻

Battery charge level.

Main screen icons

Vibration alert: your cellphone vibrates but neither rings nor beens except for the alarms

Call forwarding activated: your calls are forwarded.

Alarm clock programmed.

Voicemail message arrived

Roaming

Level of network reception

Vibration and ringtone alert.

Message unread.

Keypad locked.

Ringtone alert

Silence mode: your cellphone neither rings, beeps n vibrates except for the alarms

Installing and removing the battery

Removing and installing the back cover



2.I Set-up





Getting started













backlight time, etc.

(avoid electric extension cables)

Charging the battery

Place the SIM card with the chip facing downwards and slide it into its 2.2 Power on your cellphone

housing. Make sure that it is correctly inserted. To remove the card,
Hold down the key until the cellphone powers on.

Be careful not to force the plug into the socket.

Connect the battery charger to your cellphone and mains socket

The charging may take about 20 minutes to start if the battery is flat.

Make sure the battery is correctly inserted before connecting the

The mains socket must be near to the cellphone and easily accessible

When using your cellphone for the first time, charge the battery fully

(approximately 3 hours). You are advised to fully charge the battery

To reduce power consumption and energy waste, when battery is

fully charged disconnect your charger from the plug; reduce the

The charge is complete when the animation stops.

2.3 Power off your cellphone

Hold down the key until the cellphone powers off.

Ouick Start Guide

For more information about how to use the cellphone, please go to www.alcatelonetouch.com to download complete user manual (English version only). Moreover, from the website you can also consult FAQ (English version only).



Limited and its affiliates

To hang up the call, press the <a> key.

3.2 Calling your voicemail (1)

To access your voicemail, hold down the 1 oo key

Making an emergency call

ALCATELOnetouch

3.6 Message counter

you make a mistake, you can delete the incorrect digits by pressing the calls, Incoming calls, Reset timer.

forwarding, Call barring, Answer mode, Auto redial, Call time

Black list: set some contact in blacklist and the call from him(her) will environments. reminder. Auto handsfree.

without a SIM card and without typing the PIN code or unlocking the 3.9 Call control (1)

The menu serves you the dual purposes of cost monitoring and controlling during a call by the settings of "By cost" and "By 4.5 Memory status

3.3 Receiving a call

When you receive an incoming call, press the Very to talk and then hang up using the ~ key.

3.4 Available functions during the call

During a call, you can use your directory, short messages, etc. without losing your correspondent.

3.5 Call log

right softkey

keypad (1).

You can access your call memory by pressing the Very key from the idle screen. You may also access to "Calls" menu and check "All calls"/"Missed calls"/"Received calls"/"Dialed calls".

(1) Contact your network operator to check service availability

English - CIB21AAALAAA

Record your message quantity of "Sent" and "Received"

3.7 Call duration

Left softkey

Answer

Send call

Call memory

Lock/Unlock

7 PORS R TIM

Torch key

Dial the desired number then press the Vey to place the call. If You can access different items with this option: Last call, Outgoing 4.4 Settings

You can access a number of items with this option: Call waiting, Call then long press number key to speed dial(in idle screen). If your cellphone is covered by the network, dial emergency number and press the Very to make an emergency call. This works even

Contacts

4.1 Consulting your contact

To access the contacts from the idle screen, press the exercise key and 5.1 Create message press wey, and select "Contacts" from the menu.

below options for you: Family, Friends, Colleague, Business, VIP. send often to "Drafts" or "Templates".

4.3 Add new contact

Select the directory in which you wish to create a file, press the "Options" softkey, and select "Add new contact" then

Confirm an option (press the middle of the key) Access "Messaging" (short keypress
in idle screen)

Switch on/Switch off the cellphone (long keypress)

keypress (a) in idle screen)

Access call memory

Return to the idle screen

Short keypress; space

Long keypress: enter zero

Short keypress: dial "0" - Long keypress: switch on/off the torch

- Long keypress: keypad lock

- Short keypress: #

Access your voicemail (long keypress)

Long keypress: access the Symbols table

Short keypress: switch among "*" / "+" / "P" / "W"

- Long keypress: activate/deactivate the Vibration mode - Short keypress: Switch between abc/Abc/ABC/123

Send a call

Left softker

Right softkey

In Edit mode

In Idle mode:

In Edit mode

Manual switch on/off keypad backlight and LCD light (long

Memory in use: you may choose to save your memory in SIM, SIM and phone, Phone

Speed dials: activate this function, add the contact to speed dials list 6.1 Profiles

My number: Type in or modify your cellphone number and confirm by 6.2 Phone settings

Indicates how much space is used and how much is currently free on 6.3 Time and Date vour cellphone

Messaging

can type a message, and you're also able to insert a pre-defined message be connected. from "Templates". While writing a message, select "Options" to You can sort the contacts list into groups which you preferred and access all the messaging options. You can save your messages that you



Specific letters (accent) will increase the size of the SMS, this may cause multiple SMS to be sent to your recipient.

Settings......

From the main menu, select the icon menu 🎡 and select the function (in idle screen). of your choice in order to customize your cellphone: Access to Menu and select "Games & Tools" and choose "Torch" Profiles, Phone settings, Time and date, Network settings, Security settings, Restore factory settings...

With this menu, you may personalize ringtones for different events and

You may set Languages, Shortcuts, LCD setting, Auto keylock, Power View appointments: see today's appointments. saving mode according to your request

You have settings of time and date, including 12/24h format and DD/MM 7.5 Calculator

6.4 Network settings

Network selection: The choice of network connection is left up to

From the main menu select "Messaging" to create text message. You Preferred networks: List the networks and select which you wish to

Games & Tools

Your cellphone may include some games. It allows you to manage settings in which you may set Audio and Vibration

To light in darkness, you may activate "Torch" by below operations: Long press Op key to activate it; short press to deactivate it

Your cellphone has a built-in alarm clock.

Once you enter this menu from the main menu there is a monthly-view calendar for you to keep track of important meetings, appointments.

lump to date: input the required date and it will be immediately highlighted.

Hold down the <⊕ key to get the decimal point. Confirm with the key or the left softkey.

Unit converter and Currency converter.

Latin input mode.....

This mode allows you to type a text by choosing a letter or a sequence of characters associated with a key. Press the key several times until the desired letter is highlighted. When you release the key, the highlight character is inserted into the text.

ALCATEL is a trademark of Alcatel-Lucent and used under license by TCT Mobile Limited.

All rights reserved © Copyright 2010 TCT Mobile Limited.

TCT Mobile Limited reserves the right to alter material or technical specification without prior notice.

(I) Depending on your network operator

Safety and use

We recommend that you read this chapter carefully before using your cellphone. The manufacturer disclaims any liability for damage, which may result as a consequence of (131°F) (the max value depends on device, materials and housing paint/texture). mproper use or use contrary to the instructions contained herein.

• TRAFFIC SAFETY:

Given that studies show that using a cellphone while driving a vehicle constitutes a real risk, even when the hands-free kit is used (car kit, headset...), drivers are requested to refrain from using their cellphone when the vehicle is not parked. Check the laws and Do not paint it. regulations on the use of wireless cellphones and their accessories in the areas where Use only batteries, battery chargers, and accessories which are recommended by TCT you drive. Always obey them. The use of these devices may be prohibited or restricted

When driving do not use your cellphone and headphone to listen to music or to the radio. Using a headphone can be dangerous and forbidden in some areas. When switched on, your cellphone emits electromagnetic waves that can interfere

that there is no problem do not place your cellphone on top of the dashboard or within an airbag

- check with your car dealer or the car manufacturer to make sure that the car's electronic devices are shielded from cellphone RF energy.

CONDITIONS OF USE:

You are advised to switch off the cellphone from time to time to optimize its

Switch the cellphone off before boarding an aircraft to avoid prosecution

Switch the cellphone off when you are in health care facilities, except in designated areas. As with many other types of equipment now in regular use, cellphones can interfere with other electrical or electronic devices, or equipment using radio safety precautions:

Switch the cellphone off when you are near gas or flammable liquids. Strictly obey all signs and instructions posted in a fuel depot, gas station, or chemical plant, or in any notentially explosive atmosphere

When the cellphone is switched on, it should be kept at least 15 cm from any medical device such as a pacemaker, a hearing aid or insulin pump. In particular when using the To avoid hearing impairment, answer the call before holding your cellphone to your ear. Also move the handset away from your ear while using the "hands-free" option because the amplified volume might cause hearing damage.

Do not let children use the cellphone and/or play with the cellphone and accessories without supervision.

. When replacing the cover please note that your cellphone may contain substances that

Always handle your cellphone with care and keep it in a clean and dust-free place. Do not allow your cellphone to be exposed to adverse weather or envir conditions (moisture, humidity, rain, infiltration of liquids, dust, sea air, etc.). The manufacturer's recommended operating temperature range is -10°C (14°F) to +55°C

is temporary and not serious. Do not open or attempt to repair your cellphone yourself.

Do not drop, throw or try to bend your cellphone

Mobile Limited and its affiliates and are compatible with your cellphone model.TCT • BATTERY AND ACCESSORIES: Mobile Limited and its affiliates disclaim any liability for damage caused by the use of Before removing the battery from your cellphone, please make sure that the cellphone other chargers or batteries.

Your cellphone should not be disposed of in a municipal waste. Please check local Observe the following precautions for battery use: regulations for disposal of electronic products.

with the vehicle's electronic systems such as ABS anti-lock brakes or airbags. To ensure Remember to make back-up copies or keep a written record of all important information stored in your cellphone.

me people may suffer epileptic seizures or blackouts when exposed to flashing lights, or when playing video games. These seizures or blackouts may occur even if a Batteries must be disposed of in accordance with locally applicable en person never had a previous seizure or blackout. If you have experienced seizures or blackouts, or if you have a family history of such occurrences, please consult your doctor before playing video games on your cellphone or enabling a flashinglights feature on your cellphone. Parents should monitor their children's use of video games or other features that incorporate flashing lights on the cellphones. All persons should discontinue use and consult a doctor if any of the following symptoms occur: nvulsion, eve or muscle twitching, loss of awareness, involuntary m disorientation. To limit the likelihood of such symptoms, please take the following

- Do not play or use a flashing-lights feature if you are tired or need sleep
- Take a minimum of a 15-minute break hourly.
- Play in a well lit environment
- Play at the farthest distance possible from the screen

When you play games on your cellphone, you may experience occasional discomfort in your hands, arms, shoulders, neck, or other parts of your body. Follow these Items of equipment with this symbol are not be thrown into ordinary bins if your cellphone you should hold it against the ear on the opposite side to the device, if any. instructions to avoid problems such as tendinitis, carpal tunnel syndrome, or other jurisdiction or your region has suitable recycling and collection facilities; instead they are musculoskeletal disorders:

- Take a minimum of a 15-minute break every hour of game playing.
- If your hands, wrists, or arms become tired or sore while playing, stop and rest for several hours before playing again.
- If you continue to have sore hands, wrists, or arms during or after playing, stop the

that you must respect the laws and regulations in force in your jurisdiction urisdiction(s) where you will use your cellphone regarding taking photographs 40°C (104°F) ling sounds with your cellphone. Pursuant to such laws and regulations, it may strictly forbidden to take photographs and/or to record the voices of other people Over 55°C (131°F) the legibility of the cellphone's display may be impaired, though this or any of their personal attributes, and reproduce or distribute them, as this may be

> It is the user's sole responsibility to ensure that prior authorization be obtained if necessary, in order to record private or confidential conversations or take a photograph

- Do not attempt to open the battery (due to the risk of toxic fumes and burns).
- Do not puncture, disassemble or cause a short-circuit in a battery.
- Do not burn or dispose of a used battery in the garbage or store it at temperatu above 60°C (140°F)

regulations. Only use the battery for the purpose for which it was designed. Never use The exposure standard for celliphones employs a unit of measurement known as the compliance could void the user's authority to operate the equip

This symbol on your cellphone, the battery and the accessories means

- Municipal waste disposal centers with specific bins for these
- items of equipment - Collection hins at points of sale

They will then be recycled, preventing substances being disposed of in the envir so that their components can be reused

In European Union countries:

These collection points are accessible free of charge All products with this sign must be rought to these collection points. In non European Union jurisdictions

to be taken to collection points for them to be recycled. In the United States you may learn more about CTIA's Recycling Program at

CAUTION: RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT guide TYPE DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS

CHARGERS

Home A C / Travel chargers will operate within the temperature range of 0°C (32°F) to does not indicate the need for any special precautions for use of cellphones.

information technology equipment and office equipment use. Due to different applicable cellphones away from the head and body, (fact sheet n°193). Additional WHO electrical specifications, a charger you purchased in one jurisdiction may not work in another jurisdiction. They should be used for this purpose only.

Characteristics of power supply (depending on the country): Travel charger: Input: 100-240 V, 50/60 Hz, 150 mA

5 V. 400 mA

Lithium 500 mAh

EXPOSURE TO RADIO WAVES.

Your cellphone is a radio transmitter and receiver. It is designed and manufactured not to exceed the emission limits for exposure to radio-frequency (RF) energy. These nits are part of comprehensive guidelines and establish permitted levels of RF energy for the general population. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. These guidelines include a substantial safety margin designed to - Consult the dealer or an experienced radio/TV technician for help. ensure the safety of all persons, regardless of age and health.

damaged batteries or those not recommended by TCT Mobile Limited and/or its affiliates. Specific Absorption Rate, or SAR. The SAR limit set by public authorities such as the For the receiver devices associated with the operation of a licensed radio service (e.g. nications Commission of the US Government (FCC), or by Industry FM broadcast), they bear the following state Canada, is 1.6 W/kg averaged over 1 gram of body tissue Tests for SAR are conducted. This device complies with Part 15 of the FCC Rules. Operation is subject to the using standard operating positions with the cellphone transmitting at its highest certified power level in all tested frequency hands

Although the SAR is determined at the highest certified power level, the actual SAR

This device complies with Part 15 of the FCC Rules. Operation is subject to the level of the cellphone while operating can be well below the maximum value. This is following two conditions: because the cellphone is designed to operate at multiple power levels so as to use only (1) this device may not cause harmful interference the power required to reach the network. In general, the closer you are to a wireless (2) this device must accept any interference received, including interference that may There may be certain differences between the user manual description base station antenna, the lower the power output of the cellphone. Before a cellphone nodel is available for sale to the public, compliance with national regulations and Your cellphone is equipped with a built-in antenna. For optimal operation, you should standards must be shown

the ear and 1.04 W/Kg for use close to the body.
While there may be differences between the SAR levels of various cellphones and at

various positions, they all meet the government requirement for RF exposure. For that whatever product is used is free of any metal and that it positions the cellphone body-worn operation, the cellphone meets FCC RF exposure guidelines provided that at least 1.5 cm away from the body. it is used with a non-metallic accessory with the handset at least 1.5 cm from the body. Use of other accessories may not ensure compliance with FCC RF exposure

The World Health Organization (WHO) considers that present scientific information individuals are concerned, they might choose to limit their own or their children's RI The charger's designed for your cellphone meet with the standard for safety of exposure by limiting the length of calls, or using "hands-free" devices to keep information about electromagnetic fields and public health are available on the following website: http://www.who.int/peh-emf. Note: This equipment has been tests and found to comply with the limits for a Class B digital device pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against radiate radio frequency energy and, if not installed and used in accordance with the Questions you may have. instructions, may cause harmful interference to radio communications. However, there THIS CELLPHONE MEETS THE GOVERNMENT'S REQUIREMENTS FOR is no guarantee that interference to radio or television reception, which can be correct the interference by one or more of the following measures

- Reorient or relocate the receiving antenna.
- Connect the equipment into an outlet on a circuit different from that to which the

Changes or modifications not expressly approved by the party respo

condition that this device does not cause harmful interference For other devices they hear the following statement

cause undesired operation.

avoid touching it or degrading it.

The highest SAR value for this model cellphone when tested is 1.2 W/Kg for use at As mobile devices offer a range of functions, they can be used in positions other than TCT Mobile shall not be held legally responsible for such differences, if against your ear. In such circumstances the device will be compliant with the guidelines when used with headset or usb data cable. If you are using another accessory ensure by the operator exclusively.

General information

- Internet address: www.alcatelonetouch.com
- Hot Line Number: see "TCT Mobile Services" leaflet or go to our

On our Internet site, you will find our FAQ (Frequently Asked Questions) section. You can also contact us by e-mail to ask any

An electronic version of this user guide is available in English and other determined by turning the equipment off and on, the user is encouraged to try to languages according to availability on our server: www.alcatelonetouch.com

> Your cellphone is a transceiver that operates on GSM networks with 850 and 1900 MHz bands

Protection against theft (1)

our cellphone is identified by an IMEI (cellphone serial number) shown n the packaging label and in the product's memory. We recommend hat you note the number the first time you use your cellphone by ntering * # 0 6 # and keep it in a safe place. It may be requested by the lice or your operator if your cellphone is stolen. This number allows your cellphone to be blocked preventing a third person from using it even with a different SIM card

Disclaimer

and the cellphone's operation, depending on the software release of your cellphone or specific operator services.

Telephone warranty This warranty shall not apply to detects accessory due to (without any limitation):

Your cellphone is warranted against any defect or malfunctioning which may occur in conditions of normal use during the warranty period of twelve (12) months (1) from the date of purchase as shown on your

against any defect which may occur during the first six (6) months (1) 3) Modification or repair performed by individuals not authorized by from the date of purchase as shown on your original invoice.

use thereof, you must immediately inform your vendor and present your cellphone with your proof of purchase

replaced or repaired, as appropriate. Repaired cellphone and accessories (IMEI) have been removed or altered. are entitled to a one (1) month warranty for the same defect. Repair or replacement may be carried out using reconditioned components offering equivalent functionality.

This warranty shall not apply to defects to your cellphone and/or **Troubleshooting......**

- 1) Non-compliance with the instructions for use or installation, or with technical and safety standards applicable in the geographical the instructions below: area where your cellphone is used,
- by TCT Mobile Limited
- 4) Inclement weather, lightning, fire, humidity, infiltration of liquids or foods, chemical products, download of files, crash, high voltage, and carry out the following checks:

There are no express warranties, whether written, oral or implied. other than this printed limited warranty or the mandatory warranty provided by your country or jurisdiction.

indirect, incidental or consequential damages of any nature whatsoever. including but not limited commercial or financial loss or damage, loss of data or loss of image to the full extent those damages can be disclaimed My screen is difficult to read

Some countries/states do not allow the exclusion or limitation of indirect, incidental or consequential damages, or limitation of the duration of implied warranties, so the preceding limitations or My cellphone turns off by itself exclusions may not apply to you.

Before contacting the aftersales department, you are advised to follow

- You are advised to switch off the cellphone from time to time to optimize its performance
- You are advised to fully charge () the battery for optimal
- Avoid storing large amounts of data in your cellphone as this may affect the performance of your cellphone.

My cellphone will not switch on

- · Check the battery charge level
- Check the battery contacts, remove and reinstall your battery, ther turn your cellphone back on

My cellphone has not responded for several minutes

- Press the 🚗 key

- Check the battery charge level

My cellphone has a low level of autonomy

- Make sure you respected the complete charge timing (minimum 3 Make sure you have dialled a valid number and press the \checkmark key hours)
- · After a partial charge, the battery level indicator may not be exact. · Make sure your cellphone is connected to a network, and that the Wait for at least 20 minutes after removing the charger to obtain an exact indication

My cellphone will not charge properly

- Make sure that your battery is not completely discharged; If the battery is flat, it may take around 20 minutes to display the battery Unable to receive incoming calls charger indicator on the screen
- Make sure charging is carried out under normal conditions (0°C (32°F)- +40°C (104°F))
- Make sure your battery is inserted. It must be inserted before plugging in the charge
- Make sure you are using an Alcatel battery and charger in the box When abroad, check that the electrical current is compatible

My cellphone will not connect to a network

- Verify the network coverage with your operator
- Try selecting the available network(s) manually

SIM card error

- Make sure the SIM card has been correctly inserted
- Verify with your operator that your SIM card is 3V or 1.8V compatible; the old 5V SIM cards cannot be used

Unable to make outgoing calls

- For international calls check the country and area codes
- network is not overloaded or unavailable Check your subscription status with your operator (credit, SIM card
- valid, etc.) Make sure you have not barred outgoing calls

- Make sure your cellphone is switched on and connected to a network (check for overloaded or unavailable network)
- Check your subscription status with your operator (credit SIM card valid, etc.)
- Make sure you have not forwarded incoming calls
- Make sure that you have not barred certain calls

The caller's name does not appear when a call is received

Check that you have subscribed to this service with your operator

Your caller has concealed his/her number

- I am unable to use the features described in the manual Check with your operator to make sure that your subscription
- includes this service Make sure this feature does not require an Alcatel accessory

When I select a number from my directory, the number is not dialled

- Make sure that you have correctly recorded the number in your file
- Make sure that you have selected the country prefix when calling a

(I) Contact your network operator for service availability.

I am unable to create a file in my directory Make sure that your SIM card directory is not full; delete some files or save the files in the product directory (i.e. your professional or

Contact your network operator to check service availability

- Make sure your operator's voicemail number is correctly entered in
- Try later if the network is busy

The icon is displayed on my standby screen

You have saved too many short messages on your SIM card; delete some of them or archive them in the product memory

"No service is displayed

You are outside of the network coverage area

Contact your network operator to obtain the PUK code (Personal Unblocking Key)

- Make sure your battery is not completely used up or damaged
- power on again, if still does not work Hold down \sim key and press power on/off key for a while to reset



How to make your battery last longer

 After a partial charge, the battery level indicator may not be exact. Wait for at least 20 minutes after removing the charger to obtain an exact indication

corrosion oxidation

This warranty covers the cost of parts and labor but excludes any other

Batteries (2) and accessories sold with your cellphone are also warranted

If the defect is confirmed, your cellphone or part thereof will be either Your cellphone will not be repaired in case labels or serial numbers • Press 🐟 until the screen comes on

In case of any defect of your cellphone which prevents you from normal

(1) The warranty period may vary depending on your country. (2) The life of a rechargeable cellphone battery in terms of conversation time standby time, and total service life, will depend on the conditions of use and network configuration. Batteries being considered expendable supplies, the specifications state that you should obtain optimal performance for your cellphone during the

first six months after purchase and for approximately 200 more

- 2) Connection to any equipment not supplied or not recommended
- TCT Mobile Limited or its affiliates or your vendor.

In no event shall TCT Mobile Limited or any of its affiliates be liable for

Remove the battery and re-insert it, then switch the cellphone back

- Clean your screen · Use your cellphone in accordance with the recommended conditions
- · Check that your keypad is locked when you are not using your

- Try connecting in another location
- Check with your operator that your SIM card is valid

Try connecting at a later time if the network is overloaded

personal directories)

My callers are unable to leave messages on my voicemail

- I cannot access my voicemail
- "My numbers'

I have already entered 3 incorrect PIN codes

- My cellphone is frozen, can't power on
- Remove your battery, remove your SIM card then reinstall them to
- All user cellphone data: contacts photos messages and files



Make sure you follow the complete charge time (minimum 3 hours)

· Switch on the backlight upon request.

23