



Picture 11: Left Hand Touch Cheek Position




Picture 12: Left Hand Tilt 15 Degree Position




Picture 13: Right Hand Touch Cheek Position




Picture 14: Right Hand Tilt 15 Degree Position




Picture 15: Back Side, the distance from handset to the bottom of the Phantom is 15mm



Picture 16: Front Side, the distance from handset to the bottom of the Phantom is 15mm



Picture 17: Back Side, the distance from handset to the bottom of the Phantom is 10mm




Picture 18: Front Side, the distance from handset to the bottom of the Phantom is 10mm



Picture 19: Left Edge, the distance from handset to the bottom of the Phantom is 10mm



Picture 20: Right Edge, the distance from handset to the bottom of the Phantom is 10mm



Picture 21: Top Edge, the distance from handset to the bottom of the Phantom is 10mm



Picture 22: Bottom Edge, the distance from handset to the bottom of the Phantom is 10mm