

Quick Start Guide



www.sar-tick.com

This product meets applicable national SAR limits of 1.6W/kg. The specific maximum SAR values can be found in the RADIOWAVES section of this user guide.

When carrying the product or using it while worn on your body, either use an approved accessory such as a holster or otherwise maintain a distance of 1.5 cm from the body to ensure compliance with RF exposure requirements. Note that the product may be transmitting even if you are not making a phone call.



PROTECT YOUR HEARING

To prevent possible hearing damage, do not listen at high volume levels for long periods. Exercise caution when holding your device near your ear while the loudspeaker is in use.



ALCATEL onetouch.

English - CJB18FDALAAA

Your mobile.....

ALCATEL 2050A



- 1 Left soft key
- 2 Call log (Idle screen) Send call
- 3 Voicemail (press and hold)
- 4 Right soft key
- 5 Power on/Power off End call
- 6 Vibrate alert
- 7 Navigation key: Menu/Confirm an option

1.1 Keys

- Navigation key
- Confirm an option (press the middle of the key)
- Receive call
- Power on/off the handset (press and hold)
- End call
- Return to idle
- Left soft key
- Right soft key
- Dial the voicemail number (press and hold)
- From Idle screen
 - Press: enter zero
 - Press and hold: +, "+" are used for dialing an international call.
 - Press longer: Input P/W, "P" and "W" are used for calling the extension.
- In Edit mode:
 - Press: access the Symbols table 0 (Add numbers)
- From Idle screen
 - Press: Input "*"
- In Edit mode:
 - Press: press * to switch input mode
- From Idle screen
 - Press: Input "#"
 - Press and hold: activate/deactivate the vibrator
- In Edit mode:
 - Press: space

1.2 Idle screen icons

- Battery charge level.
- Vibrate mode: your phone vibrates, but neither rings nor beeps.
- Headset connected.
- Silence mode: your phone neither rings, beeps nor vibrates.
- Alarm clock programmed.
- Voicemail message arrived.
- Missed calls.
- Roaming.
- Level of network reception.
- Message unread.
- MMS unread.
- Call divert.
- Message full.
- Bluetooth activated.

2 Getting started

2.1 Set-up

Removing and installing the back cover



Installing and removing the battery




Inserting and removing TF card



Inserting and removing SIM



Charging the battery



Connect the battery charger to your phone and outlet respectively.

- The charging may take about 20 minutes to start if the battery is flat.
- Be careful not to force the plug into the socket.
- Make sure the battery is correctly inserted before connecting the charger.
- The outlet must be near to the phone and easily accessible (avoid electric extension cables).
- When using your telephone for the first time, charge the battery fully (approximately 3 hours). You are advised to fully charge the battery ().
- To reduce power consumption and energy waste, when battery is fully charged, disconnect your charger from the plug; reduce the backlight time, etc.



The charge is complete when the animation stops.

2.2 Power on your phone

Hold down the key until the phone powers on.

2.3 Power off your phone

Hold down the key from the idle screen.

3 Calls.....

3.1 Making a call

Dial the desired number, press the key to place the call. If you make a mistake, you can delete the incorrect digits by pressing the key. To hang up the call, press the key.

Making an emergency call

If your phone is covered by the network, dial emergency number and press the key to make an emergency call. This works even without a SIM card and without typing the PIN code or unlocking the keypad.

3.2 Calling your voicemail (1)

You can see SIM voice mail in this menu.

3.3 Receiving a call

When you receive an incoming call, press the key to talk and then hang up using the key.

3.4 Available functions during the call

During a call, you can use your directory, text messages, etc. without losing your correspondent.

(1) Contact your network operator to check service availability.

4 Messages

4.1 Create SMS

From the main menu select "Messages" to create text message. You can type a message send it to a recipient in the SIM card directory. You can type a message, and you're also able to insert a pre-defined message from "Templates". While writing a message, select "Options" to access all the messaging options.

Specific letters (accent) will increase the size of the SMS, this may cause multiple SMS to be sent to your recipient.

4.2 Create MMS

Select Messages-Options-New chat-Options-Add subject, it will switch to MMS interface automatically.

5 Contacts.....

5.1 Consulting your contacts

To access the directory from the idle screen, press the key and select the icon from the menu.

5.2 Adding a contact

Select the directory in which you wish to create a file, press the "Options", select "New" then save it to "Phone", "SIM Card" as you like.

6 Call logs

You can access your call memory by pressing from the idle screen, or press the key and select the icon from the menu.

In this menu, you will see all call history.

7 Browser.....

This function enables you to surf the Internet using the mobile phone. Note: Consulting the local network operator for related fee and specific setup.

8 Camera.....

This function enables you to take pictures. Press key to take the picture.

9 Music

Use this function to play audio files. Press key to play/pause the audio player, press key to last or next audio, in audio player interface, press key and key to tune volume.

10 Videos.....

Use this function to play video files. Press key to play/pause the video player, short press key and key to tune volume; press key or key to last or next video.

11 FM radio

Your phone is equipped with a radio. You can use the application as a traditional radio with saved channels. In FM radio interface, press key to play/pause the playing process of the current channel, press key and key to tune volume.

12 Recorder.....

Use this function to record audio files. The phone support WAV and AMR. The recording file you stopped will be stored in record file list automatically.

13 My files.....

The phone provides a certain space for users to manage files and support the memory card. The capacity of the memory card is selectable. You can use the file manager to conveniently manage various directories and files on the phone and the memory card.

14 Games.....

Three games named Snake, Sokoban and Tetris were embedded in the phone, for more information please refers to "help" in the game.

15 Profiles.....

With this menu, you may personalize ringtones for different events and environments.

16 Alarm.....

Your mobile phone has a built-in alarm clock with snooze feature.

17 Calculator.....

Press the up, down, left, right and OK key to select +, -, x, ÷ and = respectively. Press key to delete the figure.

18 Calendar.....

Once you enter this menu, there is a monthly-view calendar for you to view the date; you can go to any day you want.

19 Fake call.....

You can create fake call through this function.

20 Call filter.....

You can filter the calls you don't want to get through this function.

21 Services

STK service is the tool kit of SIM card. This phone supports the service function. The specific items depend on SIM card and network. Service menu will be automatically added to the phone menu when supported by network and SIM card.

22 Settings.....

From the main menu, select the menu icon and select the function of your choice in order to customize your telephone: Phone settings, Call settings, Connections, Security and Restore factory settings.

23 Bluetooth

You can transfer data, such as music to other device using Bluetooth. Search the device and accept/transfer data. The received data is automatically stored in the directory

24 Image

You can view images through this function.

ALCATEL is a trademark of Alcatel-Lucent and is used under license by TCT Mobile Limited.
© Copyright 2013 TCT Mobile Limited All rights reserved
TCT Mobile Limited reserves the right to alter material or technical specification without prior notice.

