

Picture 15: Left Hand Touch Cheek Position



Picture 16: Left Hand Tilt 15 Degree Position



Picture 17: Right Hand Touch Cheek Position



Picture 18: Right Hand Tilt 15 Degree Position




Picture 19: Back Side, the distance from handset to the bottom of the Phantom is 10mm




Picture 20: Front Side, the distance from handset to the bottom of the Phantom is 10mm



Picture 21: Left Edge, the distance from handset to the bottom of the Phantom is 10mm



Picture 22: Right Edge, the distance from handset to the bottom of the Phantom is 10mm



Picture 23: Top Edge, the distance from handset to the bottom of the Phantom is 10mm



Picture 24: Bottom Edge, the distance from handset to the bottom of the Phantom is 10mm



Picture 25: Back Side with Earphone 1, the distance from handset to the bottom of the Phantom is 10mm



Picture 26: Back Side with Earphone 2, the distance from handset to the bottom of the Phantom is 10mm