

# USER MANUAL

Model:RFD-973T

—

# IMPORTANT SAFETY INSTRUCTIONS

All of the safety and operating instructions should be read, adhered to and followed before the unit is operated.

## SAVE THESE INSTRUCTIONS

### CAUTION

- TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER. THERE ARE NO SERVICEABLE PARTS INSIDE.
- TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS UNIT TO RAIN OR MOISTURE.



The lightning flash with arrow-head symbol within an equilateral triangle is intended to alert the user to the presence of uninsulated “dangerous voltage” within the unit’s enclosure that may be of sufficient magnitude to constitute a risk of electric shock.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the unit.

## BATTERY PRECAUTIONS

- Dispose of the old batteries properly. Do not dispose of the old batteries in a fire.
- Do not leave the batteries where a child or pet could play with or swallow them. If the batteries are swallowed, contact a physician immediately.
- The batteries may explode if mistreated. Do not attempt to recharge or disassemble the batteries.
- Use only fresh batteries of the required size and type. Do not mix old and new batteries, different types of batteries, or rechargeable batteries of different capacities.
- **Important!** Remove batteries from this product if it will be stored and/or not used for an extended period of time.

## **DANGER**

To reduce the risk of electric shock, burns, fire or injury:

1. Do not use while bathing or in a shower.
2. Do not place or store unit where it can fall or be pulled into a tub or sink.
3. Do not place in, drop or submerge in water or other liquid.
4. Do not reach for unit that has fallen into water. Unplug it immediately.
5. Care should be taken so that objects do not fall and liquids are not spilled onto the unit.

## **WARNING**

1. Close supervision is necessary when this appliance/product is used by or near children or mentally disabled individuals.
2. Use this unit only for its intended use as described in this manual.
3. Unplug this unit during lightning storms or when unused for long periods of time.
4. Never drop or insert an object into any opening.
5. Protect the power cord from being walked on or pinched, particularly at plug outlets, convenience receptacles and the point where it exits the unit.
6. Do not allow cord to touch hot surfaces. Wrap cord loosely around the unit when storing.

7. The unit should be situated away from direct sunlight or heat sources such as radiators, electric heaters, heat registers, stoves, or other units (including amplifiers) that produce heat. Avoid placing on top of stereo equipment that radiates heat.
8. Never block the air openings of the unit with materials such as clothing, plastic bags or papers, or place it on a soft surface such as a bed or couch, where the air openings may be blocked.
9. Do not overload electrical outlet. Use only the power source as indicated.
10. Do not carry this unit by cord or use cord as handle.
11. Never operate this unit if it has a damaged cord or plug, if it is not working properly, or if it has been dropped or damaged, or dropped into water. If the unit's power supply cord or plug is damaged, do not attempt to fix it yourself.
12. To avoid the risk of electric shock, do not disassemble or attempt to repair the unit. Incorrect repair can cause risk of electric shock or injury to persons when unit is used.
13. Do not operate in the presence of explosive and/or flammable fumes.
14. Never remove the plug from the socket by pulling the power cord.

## FCC INFORMATION

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1) This device may not cause harmful interference.
- 2) This device must accept any interference received including interference that may cause undesired operation.

**Warning:** Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### **FCC 15.105: This equipment has been tested and found to comply with the**


limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This unit generates, uses, and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try and correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

# LOCATION OF PARTS AND CONTROLS

## PILLOW SPEAKER CONTROLLER


1. Power LED
2. Power Button
3. Sleep Timer LED Indicators
4. Sleep Timer
5. Auto Scan LED
6. Auto Scan Button
7. Volume + Button
8. Volume - Button




# LOCATION OF PARTS AND CONTROLS

## TRANSMITTER

1. Power/Auto Scan LED
2. USB Power Input
3. Audio Jack
4. Power Button




## ACCESSORIES



## INSTALLING THE BATTERIES (SPEARER PART)

1. Unzip the pillow cover and inner shell to access the battery compartment.
2. Remove the battery compartment from the Pillow. Slide the BATTERY COMPARTMENT cover in the direction of the arrow to open.
2. Insert four AA batteries (not included) according to the polarity indicators inside the compartment.
3. Replace the BATTERY COMPARTMENT COVER and tuck the battery compartment into the Pillow and re-zip both the inner shell and pillow cover zippers.



## TRANSMITTER/PILLOW SET UP

The Transmitter must be within 30 feet of the Speaker Pillow for the RF (Radio Frequency) to work properly.

1. Insert one end of the Transmitter's POWER ADAPTER into the USB INPUT on the Transmitter, and the other end into an electrical outlet.
2. a. If your audio source has left and right RCA output jacks, use the Y ADAPTER to 3.5mm CABLE (included). Insert one end of the Y ADAPTER to 3.5mm CABLE into the appropriately colored R/L Line-in jacks on the audio source and the other end into the transmitter's AUDIO JACK.  
b. If your audio source has a 3.5mm stereo headphone jack, use the 3.5mm to 3.5mm CABLE (included). Insert one end of the 3.5mm CABLE to 3.5mm CABLE into the audio source's headphone jack and the other end into the transmitter's AUDIO JACK.
3. To turn the Transmitter on, press and hold the POWER  button on the Transmitter until the POWER/AUTO SCAN LED illuminates.
4. To turn the Pillow on, press and hold the POWER button on the Pillow until the POWER LED illuminates.
5. The POWER/AUTO SCAN LED on the TRANSMITTER and the POWER LED on the Pillow will start flashing as they start to search the RF frequency, it may take several seconds to match the signal.
6. When the Pillow and Transmitter are matched, the POWER LED on the Pillow and the POWER/AUTO SCAN LED on the Transmitter will illuminate solid and audio will be heard through the Pillow's speaker.

7. To turn the Pillow off, press and hold the POWER button until the POWER LED turns off. To turn the Transmitter off, press and hold the POWER button until the POWER/AUTO SCAN LED turns off.

**Note:** If the Transmitter and Pillow do not match within a few minutes, press the AUTO SCAN button on the pillow to perform a new search. You may need to move the Transmitter closer to the location of the Pillow.

## **SPEAKER PILLOW OPERATION**

1. Position the pillow with the Controller at the top right for optimal sound.
2. Press the + button to increase the volume. Press the - button to decrease the volume.
3. Press the SLEEP TIMER  button to select the SLEEP TIME. Press to scroll through 30, 60, 90, 180 minutes, or Off. An LED will illuminate to show the selected auto shutoff time. If no LEDs are lit the SLEEP TIMER is off.
4. To turn the unit off, press and hold the POWER button until the Power LED turns off.

### **Notes:**

- After a button is pressed, the LEDs will auto shutoff after 3-5 seconds.
- If the sound source is shut off, the pillow speaker will auto shutoff after 4-5 minutes to preserve battery life.

# CARE

## CLEANING THE PILLOW

Power-off and remove batteries before cleaning.

- Foam insert: Spot-clean foam with a clean, damp cloth, and allow to air dry completely before use
- Removable pillow cover: Remove from foam insert and machine wash warm using delicate cycle, tumble dry low, do not use bleach

**Note:** Pillow may retain a slight odor when first removed from the package. This is easily eliminated by allowing the pillow to air out.

## CLEANING THE TRANSMITTER

- Wipe with a soft, slightly damp cloth.
- Do not use abrasive chemicals.

# SPECIFICATIONS

## TRANSMITTER

Range.....	Up to 30 feet
Number of Channels.....	<b>79</b>
Frequency.....	ISM band 2.4~2.4835 GHz
Dimensions.....	Approximately 5" x 3" x 1"
Power Supply Input:.....	AC100-240V~50-60Hz 0.3A Output: DC 5V, 500mA

## SPEAKER

Battery Life .....	Up to 8 hours
Max Output .....	1W
Frequency Response .....	10Hz-20kHz
Dimensions .....	Approximately 26" x 18" x 5"
Power Supply .....	4 AA batteries (not included)

# TROUBLESHOOTING

## PROBLEM

## SOLUTION(S)

---

The Pillow Speaker and Transmitter will not pair.

Confirm the Pillow Speaker and the Transmitter are powered on and the Power/Auto Scan LED on the Pillow Speaker and the Power LED on the Transmitter are flashing.

---

Press the Auto Scan button on the Pillow to perform a new search.

---

There is no sound coming from the Pillow Speaker.

Confirm the Pillow Speaker and the Transmitter are paired (Auto Scan LED on the Pillow Speaker and the Power LED on the Transmitter are solid).

---

Check the cable connections between your audio source and the Transmitter.

---

Try removing and reinstalling the batteries.

# ONE (1) YEAR LIMITED WARRANTY

Brookstone® warrants this product against defects in materials and/or workmanship under normal use for a period of ONE (1) YEAR from the date of purchase by the original purchaser (“Warranty Period”). If a defect arises and a valid claim is received within the Warranty Period, at its option, Brookstone will either 1) repair the defect at no charge, using new or refurbished replacement parts, or 2) replace the product with a new product that is at least functionally equivalent to the original product, or 3) provide a store credit in the amount of the purchase price of the original product. A replacement product or part, including a user-installable part installed in accordance with instructions provided by Brookstone, assumes the remaining warranty of the original product. When a product or part is exchanged, any replacement item becomes your property and the replaced item becomes Brookstone’s property. When a store credit is given, the original product must be returned to Brookstone and becomes Brookstone’s property.

**Obtaining Service:** To obtain warranty service, call Brookstone Limited Warranty Service at 1-800-292-9819. Please be prepared to describe the product that needs service and the nature of the problem. A purchase receipt is required. All repairs and replacements must be authorized in advance. Service options, parts availability and response times will vary. You are responsible for delivery and the cost of delivery of the product or any parts to the authorized service center for replacement, per our instructions.

**Limits and Exclusions:** Coverage under this Limited Warranty is limited to the United States of America, including the District of Columbia and the U.S. Territories of Guam, Puerto Rico, and the U.S. Virgin Islands. This Limited Warranty applies only to products manufactured for Brookstone that can be identified by the “Brookstone” trademark, trade name, or logo affixed to them or their packaging. The Limited Warranty does not apply to any non-Brookstone products. Manufacturers or

suppliers other than Brookstone may provide their own warranties to the purchaser, but Brookstone, in so far as permitted by law, provides these products "as is." This warranty does not apply to: a) damage caused by failure to follow instructions relating to product's use or the installation of components; b) damage caused by accident, abuse, misuse, fire, floods, earthquake or other external causes; c) damage caused by service performed by anyone who is not a representative of Brookstone; d) accessories used in conjunction with a covered product; e) a product or part that has been modified to alter functionality or capability; f) items intended to be periodically replaced by the purchaser during the normal life of the product including, without limitation, batteries or light bulbs; g) any product sold "as is" including, without limitation, floor demonstration models and refurbished items; or h) a product that is used commercially or for a commercial purpose.

**BROOKSTONE SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT, OR ARISING OUT OF ANY BREACH OF THIS WARRANTY. TO THE EXTENT PERMITTED BY APPLICABLE LAW, BROOKSTONE DISCLAIMS ANY AND ALL STATUTORY OR IMPLIED WARRANTIES, INCLUDING, WITHOUT LIMITATION, WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND WARRANTIES AGAINST HIDDEN OR LATENT DEFECTS. IF BROOKSTONE CANNOT LAWFULLY DISCLAIM STATUTORY OR IMPLIED WARRANTIES, THEN TO THE EXTENT PERMITTED BY LAW, ALL SUCH WARRANTIES SHALL BE LIMITED IN DURATION TO THE DURATION OF THIS EXPRESS WARRANTY.**

Some states disallow the exclusion or limitation of incidental or consequential damages or how long an implied warranty lasts, so the above exclusions or limitations may not apply to you. This warranty gives you specific legal rights and you may also have other rights, which vary from state to state.