


Label Location



The label is placed on the bottom of the EUT.