

Place Label on back side of unit;  
label sits in recessed area



## Label Placement for Firetide Model 2100