

## Mechanical drawing




Fig. 4 Mechanical Dimensions

## Installation Guide

1. The module can be mounted to the target product using a socket without soldering.
2. Please follow the pin assignments to connect the module to the socket on the target product.
3. Make sure that the specified supply voltage is not exceeded.
4. Make sure that the supply voltage is clean from noise and ripple.
5. Decoupling capacitor is recommended to be placed next to the Vcc pin.
6. Unused pins should be disconnected.
7. The module is self sufficient to function without the need for external components.
8. PCB traces for Vcc and Ground should be thick and short.
9. Make sure there is no metallic object placed directly on top and below the module after the module is installed.