

## IMPORTANT – PLEASE READ FIRST

Using the directions here in conjunction with the Quick Start Guide will ensure that you set up Wabi correctly. Please read these added instructions carefully. *The instructions listed here correspond to same steps as the Quick Start Guide.*

- STEP 1** The first step in the Quick Start Guide shows you how to fully charge Wabi before initial use. Wabi will work while he is attached to his power cord. However, if Wabi's battery is very low, the sound quality of his messages and stories may suffer. To avoid this, simply take Wabi out of the box, plug him into his charger as the guide shows and charge him for a FULL 12 HOURS before turning him on. When recharging in the future, turn him off, plug him into the charger overnight, take him off the charger and then turn him on again.
- STEP 2**
1. From your telephone wall outlet, plug the cord into the top phone connection on your Wabi Base Station. **IMPORTANT: DSL users must use a filter (See below).** If you have a phone on that outlet already, simply use the supplied telephone cord to plug the phone back into the lower phone connection on your Wabi Base Station.
  2. Once Wabi is charged, unplug him from the charger, turn on his power switch and sit Wabi up within 3 feet of the base station. Taking this step is very important the first time you turn Wabi on. When Wabi is first activated, he receives his first story. When you first activate Wabi (turn on his power switch for the first time), please stay off the telephone line and allow Wabi to complete the entire set up process as outlined in the guide.
- STEP 3** Follow the instructions in the guide to complete the registration process. Whenever you see the yellow (Send/Receive) light on the base station lit, Wabi is communicating with Wabiland, downloading new messages, stories and more. Do not activate any of Wabi's buttons when you see the yellow light on as this will interrupt the call and Wabi will have to call back later to get any messages or stories waiting at Wabiland. You also need to stay off the line to complete the registration process. This may take up to twenty minutes to complete. Don't worry, if you do interrupt the process, Wabi will try again later until he completes the download of content and stories.

DSL phone lines require the use of a filter. Filters are usually supplied by your provider when you first activate your DSL line. If you do not have a filter, you can purchase one at a telephone or electronic store. The filter needs to be placed directly between the wall outlet and Wabi Base Station. Wabi will work on a DSL line without a filter, but the sound quality of messages and content will be poor.

**FCC NOTICE:** Any user performed changes or modifications not expressly approved in advance and in writing by Wabi, Inc. may void the user's authority to operate this product.