

2.7. Test Photo

Test Mode : Mode 1: Transmit (Power by Adapter)

Description : Front View of Conducted Emission Test Setup



Test Mode : Mode 1: Transmit (Power by Adapter)


Description : Back View of Conducted Emission Test Setup



4.7. Test Photo

Test Mode : Mode 1: Transmit (Power by Adapter)

Description : Front View of Radiated Emission Test Setup




Test Mode : Mode 1: Transmit (Power by Adapter)

Description : Back View of Radiated Emission Test Setup



Test Mode : Mode 2: Transmit (Power by Car Charger)
Description : Front View of Radiated Emission Test Setup



Test Mode : Mode 2: Transmit (Power by Car Charger)
Description : Back View of Radiated Emission Test Setup



Test Mode : Mode 1: Transmit (Power by Adapter)
Description : Front View of Radiated Emission Test Setup (Horn)

