


# COBY®

FM Wireless Transmitter

Connect to your car, home or computer from this FM high quality transmitter through FM radio.

## LOCATIONS OF PARTS AND FUNCTION CONTROLS



**WARNING:** The unit must not be exposed ot dripping and splashing!

**NOTICE:** The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

## Power Supply

### Battery Operation (BATTERIES NOT INCLUDED):

Your unit operates on 2x "AAA" alkaline Batteries. Open the battery cover and insert the batteries in the battery compartment following the polarity diagram located inside.

### Rechargeable Battery Operation (BATTERIES NOT INCLUDED):

You can also operate this unit with 2x "AAA" rechargeable batteries. For new or exhausted rechargeable batteries, we recommend the batteries be recharged for 15 hours. (Refer to battery manufacturer's guide).


**NOTE:** Remove the batteries if the player will not be in use for a long period of time.

### Adapter Operation (ADAPTER NOT INCLUDED)

Your unit also operates on 4.5V DC adapter.

**NOTE:** Unplug the adapter if the player will not be in use for a long period of time.

## Connections



## Using a Wireless Transmitter

1. Connect the transmitter to the audio source.
2. Slide the POWER switch to the ON position. The LED POWER indicator will be lit.
3. Select the proper frequency for transmission by the Frequency select switch. The selected frequency will be shown on the Frequency indicator.
  - There are four frequencies available: **88.1 MHz, 88.3 MHz, 88.5 MHz and 88.7 MHz.**
  - The max transmission distance can be up to 4 meters.(The transmission distance differs depending on the sensitivity of the receiver you use).
4. Turn the frequency of your FM radio receiver to the same frequency as your transmitter.
5. To turn the transmitter OFF, slide the POWER switch to OFF position.

## Specifications:

Power supply: 4.5V DC Adapter or 2x "AAA" alkaline batteries

FM: 88.1 MHz-88.7MHz

Dimension:

Weight:

## Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, used and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio of television reception. Which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**FCC Caution:** To assure continued compliance, any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.(Example-use only shielded interface cables when connecting to computer or peripheral devices).

**This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:**

1. This device may not cause harmful interference .
2. This device must accept any interference received, including interference that may cause undesired operation.

# COBY®

## 90 DAYS LIMITED WARRANTY

COBY ELECTRONICS CORP. ("COBY") warrants this product to the original purchaser to be free from defects in material or workmanship under normal use for 90 DAYS from the date of original purchase. COBY agrees under this warranty, to repair or replace it with a new or reconditioned product at no additional charge. Our warranty does not cover any product which has been subject to neglect, unreasonable use, accident, violation of operating instruction or any product that has been repaired or modified by an unauthorized service agent. To obtain factory service, return this unit freight-prepaid to the address shown below within the duration of this warranty. Enclose \$6.00 for each item in the form of money order made payable to COBY ELECTRONICS CORP. to cover the cost of shipping and handing. Also, include a copy of the sales receipt to show proof of purchase and a detailed description of the problem. The unit(s) must be packaged in such a way as to reasonably protect it from possible shipping damage. For further information write to

## COBY ELECTRONICS CORP.

Customer Service Dept.

56-65 Rust Street

Maspeth, N.Y.11378

COBY's liability under any legal theory for any loss damage in any way related to this product shall not exceed the sales price of this product. In no event shall COBY be liable for any incidental or consequential damages resulting from the use of this product, or inability to use this product. Repair or replacement as provided under this warranty is the exclusive right of the consumer.Except to the extent prohibited by law, no express or implied warranty of merchant ability or fitness for a particular purpose on this product shall be extended beyond the period of this warranty. Some states prohibit the exclusion or limitation of incidental or consequential damages, so that the above limitation or exclusion may not apply to you. This warranty gives you specific rights, and you may also have other rights which may vary from state to state.