

USER'S MANUAL

Bluetooth Speaker S156S



Charging The Bluetooth Speaker

1. Connect the Bluetooth Speaker's Micro USB socket (2) with the Computer's USB port through USB cable.
2. The Charging LED (3) will turn ON in red light; the rechargeable battery is in charging.
3. The Charging LED (3) red light will turn OFF when the rechargeable battery is fully charged.

Bluetooth Speaker Pairing / Reconnecting

1. Press and hold the button (1) , a message sound; "Di" will announce from speaker and the Mode LED (3) will blinking in blue; the device is turned ON and goes into searching / paring / reconnect mode for pair.
2. Now, turn ON the Bluetooth function on your mobile phone.
3. Search for "**Armin Retro Speaker**" and select it to pair. (for first time pairing or pairing a new mobile device)
4. The Bluetooth Speaker will be reconnecting automatically if your mobile phone has been paired. (Depend on the of mobile phone's type and configuration, manual reconnection may require on some devices)
5. If pairing is successful, a message sound; "Di-" will announce from speaker and the Mode LED (2) light will switch to slow blink in blue (once per 2 seconds).
6. Press and hold the button (1) to turn OFF the Bluetooth Speaker.

Bluetooth Speaker Control Function

In playing music, press button (1) to pause music, press it once again to play.

Hand Free Function

1. When there is an incoming call; The ringing sound will up and the playing music will pause automatically. Press button (1) to pick up the call if you want. Now you have hand free function with the Bluetooth speaker.
2. Press  button (1) again to hand up the call when finished. The paused music will start to play automatically.

Tip: speak to the MIC hole direct with distance in 30 cm to get the best speakerphone performance when necessary.

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.