




**General setup of the EUT on the test stand
during radiated emissions tests**




Front view of the EUT setup in vertical orientation.




Front view of the EUT setup in Horizontal orientation.



View of the EUT setup during testing in RS-232 mode.



**View of the EUT setup during testing in USB and Ethernet mode,
With power over USB as shown below.**



View of the EUT connections during testing in USB and Ethernet mode, showing laptop connection and Ethernet hub as the case is below, during the initial investigations.



**General test setup during RF emissions tests onto AC Mains,
Test in RS-232 mode pictured below.**



**Test in Ethernet mode pictured below, with power from external power source.
The EUT was also investigated with power over Ethernet.**

