

MODEL DIFFERENCES (USN3E, MX3E-3I3P)

The definitions of the models are **USN3e** & **MX3e-y1zP**:

- Where **y** means the number of contact interfaces.
- Where **z** means the number of contactless interfaces.

Backplane connector

The difference between USN3e & MX3e-3I3P is the backplane connector pin out.

The PCB remains the same.

The signals are routed to the correct pin using 0 ohms resistors (mounted or not) close to the backplane connector.

This authorizes to connect the product into 2 kinds of customer's backplanes.

Front Panel

The delivered front panel is different for each model (See below).

