


BT/WiFi Module

BT/WiFi Antenna



BT/WiFi Module and Antenna Locations on Endeavor/Tour PCB