


REFERENCE



YYWW is the manufacturing datecode where YY is the year and WW is the week of manufacture.