



# Install the Battery and Take the Tour

Let's get started discovering Lynx!

## a. Install the battery in Lynx

Turn Lynx over and place your fingernail into the groove on the side. Pull to remove the rear cover. (Lynx will not power on if the battery is not installed.)



Install the battery into the battery compartment and replace the rear cover. (Lynx will not power on if the battery is not installed.)

**You'll need to charge the battery soon.** See **Charging the Battery** on the reverse side.


## b. Turn Lynx on

Press the **Power** button on the top of the Lynx for 2 seconds.



## c. Take the tour

Go ahead, take the tour. It's the easy and fun way to learn Lynx's features. Tap **Take the tour?** with your finger and begin discovering Lynx.



Tap **Done** when you have completed the tour.

You can take the tour again at another time: **Home + Settings + Application Tour.**

Next, let's get your Lynx subscribed so you can begin enjoying SiriusXM Radio.

# Subscribe Lynx to SiriusXM Internet Radio

## Subscribe/Connect to SiriusXM Internet Radio


In order to subscribe (or connect to Internet radio if you already are subscribed) you will need to connect to a Wi-Fi® Internet connection, so be sure you are in a location where a Wi-Fi connection is available. If the Wi-Fi network is secured, you will need to know the password or key. Lynx should not be in a Vehicle Dock or Bluetooth Home Dock during the activation.

### a. Turn Lynx on

If Lynx is off, press the **Power** button on the top of the Radio. If you are prompted to take the tour, tap **No Thanks**.

### b. Find a Wi-Fi network

Lynx will scan for and detect any Wi-Fi networks within its range. If it finds one or more, you will be prompted that it has detected Wi-Fi networks. Tap **View Networks**. If no Wi-Fi networks were detected, move to a location where there is a Wi-Fi network and tap **Scan Again**.




### c. Select a Wi-Fi network and connect

Find your Wi-Fi network in the list and tap it. Lynx will attempt to connect to the network. If the network is secured, you will be prompted for the password or key.

### d. Subscribe/Connect to Internet Radio

Once connected to a Wi-Fi network, you will be presented with three choices on the SiriusXM Online Login screen:



- If you already are subscribed to SiriusXM Internet radio you can enter your username and password and tap **Login and Listen Now**.

- If you are not yet subscribed to SiriusXM Internet radio, you can tap **Subscribe Now** and follow the instructions to subscribe.

If you wish to subscribe to SiriusXM Satellite Radio at the same time, you will need the Radio ID which can be found:

- on the **Activation** screen (tap **Subscribe Now**)
- by tuning to channel 0
- on a label on the bottom of the gift box
- on the label inside the rear cover of Lynx

The Radio ID does not use the letters I, O, S, or F.


- To subscribe:
  - Online:** Go to [www.siriusxm.com/activatenow](http://www.siriusxm.com/activatenow) and follow the instructions.
  - By phone:** Call 1-800-967-2346.

When you have subscribed and obtained your Internet radio username and password, press **Done** if you are not at the Online Login screen. Enter your username and password, and tap **Login and Listen Now**.

- You can choose to explore your subscription options. Tap **Learn More** to read about the different subscription options.


### e. Explore. Listen. Enjoy.

An easy way to scan and change channels is by swiping your finger across the screen — try it! Then tap to tune the channel and listen.



# Audio

You can listen to Lynx using the built-in speaker, or by connecting your own headphones or earbuds to the headphone jack, or by **Bluetooth**®. Lynx **Bluetooth** is compatible with stereo audio streaming devices (A2DP Profile). Lynx is not compatible with the Hands Free Profile (HFP), which is typically used for a **Bluetooth** connection to a cellphone.



**TIP:** If Lynx is in **Airplane** mode, Wi-Fi and **Bluetooth** will be turned off. Check to be sure Lynx is not in Airplane mode.

## Pairing and Connecting a Bluetooth Device with Lynx

To use a **Bluetooth** device for the audio you'll need to pair and connect it with Lynx. You'll need to know how to place your **Bluetooth** device in discoverable mode, and may also need the passcode. Follow these steps:


- Tap **Home** and then tap **Bluetooth**.
- In the **Bluetooth Devices** menu, if **Bluetooth** does not have a checkmark, tap **Bluetooth** to turn it on. A checkmark will appear in the box at the right once **Bluetooth** is turned on.
- If necessary, consult the instructions for your **Bluetooth** device. Place the device in **Bluetooth** discoverable mode.
- From the **Bluetooth Devices** menu tap **Scan for devices**. Allow Lynx to scan for a few moments for **Bluetooth** devices. If Lynx found your device, it's name will be listed below **Bluetooth devices**.
- Tap your **Bluetooth** device name in the menu and Lynx will attempt to pair with the device. (You may be prompted for the passcode for your device. If so, enter the passcode.) If pairing is successful, the **Paired but not connected** message will be displayed below your **Bluetooth** device name.
- Tap your **Bluetooth** device name again and a menu will be displayed with the choices **Connect, Unpair, Options....** Tap **Connect** and Lynx will connect to the device. If successful, the **Connected to...** message will be displayed below your **Bluetooth** device name. You should now hear the SiriusXM audio playing through your **Bluetooth** device.

# Using Lynx

Let's get familiar with some of the screens you will see when navigating Lynx. The symbol **MORE** means more detailed information is available in another screen description, so keep reading. This section continues on the opposite side.

## Home

The Home screen is where you choose what you want to do with Lynx — listen to Satellite or Internet radio, listen to My Library, find a show, connect to a Bluetooth device, or change the settings.



Tap **Left Arrow** or swipe screen to navigate left or right. Tap icon to select.

### Radio & My Library Icons:



**Satellite.** Listen when Lynx is in a Vehicle Dock or connected to a Home Dock that has a satellite antenna connected to it.

**Internet.** Listen when Lynx is connected to a Wi-Fi network. **MORE**

**My Library.** Access content saved with Love, Radio Replays, and your personal content. **MORE**

**Show Finder.** A SiriusXM program guide which you can explore to find content. **MORE**

**Bluetooth.** Access the list of available Bluetooth devices to pair and connect with.

**Settings.** Configure and change Lynx's settings. **MORE**

# Now Playing

The Now Playing screen is where you see what's currently playing, change channels, pause and replay, learn more, and access favorites.



Drag **My Favorites** bar up or down to display or hide favorites. Swipe screen for Spectrum.

**Status Bar:**



**Airplane Mode On** Turns off Satellite, Wi-Fi, & Bluetooth

**Wi-Fi Signal Strength**

**Bluetooth Disconnected/Connected**

**Battery Condition**


**Favorite Channel Pages.** Channels you have saved as favorites. Swipe left or right to select a favorite channel page (up to 5 selectable pages). Selected page is highlighted.

**Featured Favorite Channel Pages.** Channels the Radio has saved as favorites for your discovery. Swipe left or right to select a featured favorite channel page (5 selectable pages). Selected page is highlighted.

**Favorite Channels.** Tap to tune a saved favorite, or tap **+** to add current channel as a favorite channel. Press+hold+drag to reorder, replace, or delete favorites.

# Spectrum

Spectrum displays a preview of each channel so you can browse other channels while continuing to listen to the currently tuned channel.



Tap **Left Arrow** or **Right Arrow** to navigate left or right. Also swipe screen or drag slider. Tap card to tune channel.

**Sort:** Sort channels by number, by name, or by category.

**Filter:** Filter. View all channels, or only the categories your interested in, or just your favorite channels.

**Previous/Next Channels.** Shows previous or next channels. Favorite channels appear as lighter bars.

**Now Playing.** The displayed channel is currently playing.

**Slider.** Press+hold+drag to quickly navigate through the channels.

**Channel List**

Channel List tuning allows you to view and tune channels in a convenient list format.

Sort: Sort channels by category (default), by channel number, or alphabetically by channel name.


Filter: Filter channels to display all channels, create a custom channel filter of your own, or filter to show only your favorite channels.

Slider: Tap, or press+hold+drag to quickly navigate through channels.

Now Playing: This channel is currently playing.

# My Library

My Library contains content saved with Love, Radio Replays, and your personal content.



Tap item to select.

**microSDHC Memory Card.** Personal songs stored on a microSDHC memory card (sold separately).

**My SXM Channel.** A virtual channel of all your 'Loved' and 'Loved Artist' content.

**Loved Songs.** Recorded songs that you have 'Loved' from live satellite radio.

**Radio Replays.** Content which Lynx has automatically saved from your favorite channels, while listening to live satellite radio.

**My Music.** Your personal songs which you have copied to an optional microSDHC memory card.

**My Playlists.** Your personal playlists which you have copied to an optional microSDHC memory card.

**Show Finder**

Show Finder is a SiriusXM program guide which you can explore and find content to listen to.

**My Shows.** Your shows that you have selected for alerts when they begin broadcasting.

**Featured Shows.** Discover shows that are featured by SiriusXM.

**Find by Channel.** Find shows by channel. You can sort and filter channels by category to narrow results.

**Find by Category.** Find shows by category, such as Rock, Pop, Christian, etc.

**Find by Name.** Find shows by show name. You can filter the show names to narrow results.

**More** >>>



## Using Lynx (continued)

### Settings

Settings is where you configure, manage, and adjust the behavior of Lynx.



Tap item to select.

**My Account.** Displays the Radio ID, the status of your SiriusXM subscription, and the status of the Internet radio connection.

**Wi-Fi and Bluetooth.** Configure and manage Wi-Fi and Bluetooth connections. Also manage Airplane and satellite radio mode.

**My Content.** Manage My SXM Channel. Select channels to lock/unlock, and to hide/display; configure featured and smart favorites; configure and manage game alerts; enable show alerts; and configure traffic and weather jump.

**Modes.** Configure settings for handheld, Home Dock and Vehicle Dock modes, such as brightness, display lock, display timeout, audio level, auto off, and FM transmitter.

**System Sounds.** Configure and adjust the audio levels of the sounds Lynx makes. Manage the touch-screen feedback.

**Date & Time.** Configure and adjust date and time functions, including time zone and DST.

**About Lynx.** Displays the Radio ID, system update status, status (including satellite and terrestrial signal strength, and Wi-Fi status), battery usage, memory usage, device information (including MAC and IP addresses), and legal information.

**Reset & Erase.** Reset Lynx back to the factory settings and undo all configuration changes and adjustments you have made. Also select to erase all "Loved" songs and My Radio Replays content. (Does not erase personal content on the memory card.)

**Application Tour.** Begins a visual tour of the features of Lynx.

**Setup Wizard.** Step-by-step instructions to help you with Internet radio and satellite radio setup and activation.

**Legal.** Legal information about Lynx.

**FAQ & Links.** Frequently asked questions about Lynx, and the User Guide for Lynx.

### Pause and Replay

Pause and Replay allows you to pause, rewind, and replay Internet radio.



Tap **My Favorites** bar to display or hide favorites.

For all music channels, you will be limited to one rewind and five song skips per hour. Most other channels have no restrictions.

Lynx will alert you if you have reached a limit. **List** may be disabled for some content.

**Pause and Replay Time Bar.** Shows status of Pause and Replay.

**Time Behind Current Play Point.** Time in buffer behind current play point in Pause and Replay.

**Current Play Point.** Shows current play point in Pause and Replay.

**Time Behind Live.** Shows time behind live Internet radio in Pause and Replay.

## Buttons and Controls

**Audio Speaker**  
Press + to increase or - to decrease the audio volume.

**Power/Lock Button**  
Press and hold to turn Radio On or Off, or to select or deselect Airplane Mode (handheld only); press and release to lock or unlock touch screen.

**Volume Control**  
Press + to increase or - to decrease the audio volume.

**Now Playing**  
Press to return to the Now Playing screen for the currently playing content.

**Back**  
Press to go back to the previous screen.

**Home**  
Press to display the Home Screen.

**Headphone Jack**  
Connection for your own headphones or earbuds.

**Touch Screen**  
Interactive display screen, which is sensitive to touch. Tap to display and select items; swipe to browse through lists; press+hold+drag to move scroll bars, sliders, and favorites.

**Battery Compartment**

**microSDHC Card Slot**  
Slot for microSDHC™ memory card for your music and playlists (sold separately).

## What's in the Box?

**Lynx Radio**

**Battery**

**USB Travel Charger**


**USB Cable**

**Carry Bag/Cleaning Cloth**

## Charging the Battery

Lynx's battery can be charged by using the USB Travel Charger and Cable, or via a USB port on any computer using the USB Cable. It can also be charged when Lynx is in the optional Vehicle Dock or Bluetooth® Home Dock.


If you are charging the battery using a computer, it is recommended that Lynx be turned off, or not in any audio playing mode, otherwise the battery will not charge.



## Managing Memory Card Content

If you have installed an optional microSDHC memory card in Lynx, connecting Lynx to a computer using the USB Cable will allow you to manage content and playlists on the memory card.

When Lynx is connected to the computer, the memory card will be recognized as a removable hard drive. You can then copy and manage your personal songs and .M3U playlists on your memory card.



## Important Legal Information

Hardware and subscription sold separately. Activation fee, other fees, and taxes required. **Service will automatically renew for additional periods of the same length as the plan you choose, on the subscription package you choose (which may differ from the package which arrived with the radio), and you will automatically be charged at the rates then in effect at each renewal, until you call us at 1-866-635-2349 to cancel. See our Customer Agreement for complete terms at www.siriusxm.com.** All fees and programming are subject to change. Our satellite service is available only to those at least 18 and older in the 48 contiguous USA and DC. Our Sirius satellite service is also available in PR (with coverage limitations). Our Internet radio service is available throughout our satellite service area and in AK and HI. Certain channels are not available on our Internet radio service, including MLB® play-by-play.

This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

©2011 Sirius XM Radio Inc. Sirius, XM and all related marks and logos are trademarks of Sirius XM Radio Inc. The microSDHC logo is a trademark of SD-3C, LLC. The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Sirius XM Radio Inc is under license. TouchSense® Technology Licensed from Immersion Corporation. Immersion TouchSense 2000 and haptic effect libraries may be covered under one or more of the following United States Patents: 6147674, 7039866, 6169540, 6697086, 7027032, 6300936, 7168042, 6285351, 6131097, 6374255, 7191191, 6424356, 6750877, 7091948, and 7280095. Additional patents pending. The AMBE® voice compression software included in this product is protected by intellectual property rights including patent rights, copyrights, and trade secrets of Digital Voice Systems, Inc. The Wi-Fi CERTIFIED Logo is a certification mark of the Wi-Fi Alliance. "Wi-Fi" is a trademark of the Wi-Fi Alliance. Major League Baseball trademarks and copyrights are used with permission of Major League Baseball Properties, Inc. Visit the official website at MLB.com. "MSNBC" is a trademark and service mark of MSNBC Cable, LLC. Visit www.siriusxm.com/channellineup for updates. All other marks and logos are the property of their respective owners. All rights reserved.

## Specifications

Lynx Radio	
Dimensions:	4.4 in (width) x 2.5 in (height) x .44 in (depth) 112 mm (width) x 63 mm (height) x 11 mm (depth)
Weight:	4.8 oz (136 g) (with battery)
Audio Connector:	1/8 in (3.5 mm) female
Antenna Connector:	SMB male
Operating Temperature:	-4°F to +140°F (-20°C to +60°C)
<b>Compatible Audio File Codecs</b>	
Formats:	AAC LC, AAC LTP, HE-AAC v1, HE-AAC v2 (.3gp, .mp4, .m4a, .aac), MP3 CBR and MP3 VBR (.mp3)

## Sirius XM Radio Inc.

1221 Avenue of the Americas  
New York, NY 10020

1.800.967.2346

© 2011 Sirius XM Radio Inc.

Lynx QSG 072811a

[siriusxm.com](http://siriusxm.com)

Bluetooth®

Wi-Fi CERTIFIED

MicroSDHC

immersion TouchSense Technology

## Lynx

SiriusXM Portable Radio

QUICK START GUIDE