

۲

# FURREAL MAKERS GUIDE CREATE & CODE YOUR ULTIMATE PUP

2.4 GHz

( )

**CAUTION:** 

Hair entanglement may result if child's hair comes in contact with

 $\wedge$ 

AGES

### DID YOU EVER THINK YOU'D MAKE YOUR VERY OWN PET? WELL, NOW YOU CAN! JUST FOLLOW THIS GUIDE AND SOON YOU'LL BE PLAYING WITH YOUR

۲


# **ULTIMATE PUP!**

furrealmakers.com

( )

( )

( )



# IMPORTANT: BATTERY INFORMATION CAUTION:

#### 1. TO AVOID BATTERY LEAKAGE

- a. Always follow the instructions carefully. Use only batteries specified and be sure to insert them correctly by matching the + and polarity markings.
- b. Do not mix old batteries and new batteries or standard (carbon-zinc) with alkaline batteries.
- c. Remove exhausted or dead batteries from the product.
- d. Remove batteries if product is not to be played with for a long time.
- e. Do not short-circuit the supply terminals.
- f. RECHARGEABLE BATTERIES: Do not mix these with any other types of batteries. Always remove from the product before recharging. Recharge batteries under adult supervision. DO NOT RECHARGE OTHER TYPES OF BATTERIES.
- Should this product cause, or be affected by, local electrical interference, move it away from other electrical equipment. Reset (switching off and back on again or removing and re-inserting batteries) if necessary.

#### FCC STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undexired operation. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can addate radio frequency energy, and, if not installed and used in accordance with the instructions, may cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.
Increase the separation between the equipment and the receiver.

- Consult the dealer or an experienced radio/TV technician for help.
- Consult the dealer or an experienced radio/TV techr CAUTION:

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

CAN ICES-3 (B)/NMB-3(B)

This device complies with Industry Canada's license-exempt RSSs. Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.


Le present appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement. ( )

# 2. READY, SET, ASSEMBLE!

۲

LCD SCREEN GUIDES YOU THROUGH ASSEMBLY

۲




۲

#### **DON'T FORGET TO ADD YOUR PUP'S FACE!**

۲


(WHAT HAPPENS WHEN YOU REMOVE IT?)



۲




۲



C03990000\_FRR\_MAKERS\_PROTO\_MAX\_INST.indd 6

۲



TURN DIAL TO SEE STARTER PERSONALITIES 🖕 🐨 👅

PUSH PURPLE BUTTON TO SELECT.

# CUSTOMIZING OPTIONS





VOLUME

OPTION

FF

۲

۲

۲

# 4. DISCOVER THE ACTIVATION POINTS


### **EXPERIMENT** WHAT HAPPENS WHEN YOU... POP THE EARS ON? PUSH THE NOSE? REMOVE THE TAIL? PLAY MUSIC? PET ITS BACK?

# MICROPHONE

۲

۲

NOSE



# MAKE THE CONNECTION!

۲

#### DOWNLOAD THE FURREAL MAKERS<sup>TM</sup>\* PROTO MAX<sup>TM</sup>\* APP MAKE SURE THAT Bluetooth®

#### IS ENABLED ON YOUR MOBILE DEVICE



App image shown not final. Actual image may differ.



**Google Play** 

GET IT ON

#### App available through June 30, 2019. FURREAL MAKERS<sup>™</sup> PROTO MAX<sup>™</sup> app works with select iPhone<sup>®</sup>, iPad<sup>®</sup>, iPod touch<sup>®</sup>, and Android devices. Updates affect compatibility. Check furrealmakers.com for details. Ask a parent first. Not available in all languages.

Apple, the Apple logo, iPhone, iPad, and iPod touch are trademarks of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc. Android, Google Play, and the Google Play logo are trademarks of Google Inc. LINK TO THE



#### TAP TO INITIATE CONNECTION



#### PRESS NOSE TO CONNECT



App images shown not final. Actual images may differ.



TAP

( )



# **"SUPER-SWEET" PET**

IN THE APP, DRAG



INTO THE NOSE SLOT



App image shown not final. Actual image may differ.

#### PRESS THE NOSE FOR A "SUPER SWEET" PUP!

۲

MAKER: Alexia, 10

۲



TRY CREATING OBSTACLE COURSES FOR YOUR PUP TO RACE THROUGH!

USE CODE LIKE THIS TO SET EACH MOTION.



۲

App image shown not final. Actual image may differ.

USE THESE ICONS TO SET THE SPEED!



MAKER: Luca, 10

FOR MORE MAKER IDEAS VISIT

furrealmakers.com

M DETE TYPES

LIQUI FLAT-I THAT CURR LIQUI OR SO

۲

۲

# **FUN FACTS**

LIQUID CRYSTAL DISPLAY. FLAT-PANEL DISPLAY THAT USES ELECTRIC CURRENT TO MAKE LIQUID CRYSTALS CLEAR OR SOLID

#### CAPACITIVE SENSORS SENSORS THAT RESPOND TO TOUCH

۲

### **RGB LED**

RED-GREEN-BLUE LIGHT EMITTING DIODE. THE **LIGHT** IN THE PUP THAT PRODUCES ALL THE **COLORS** YOU SEE

ACCELEROMETER

A SENSOR THAT DETECTS CHANGES IN

**MOTION AND POSITION** 

m

DETECTS DIFFERENT

TYPES OF **SOUNDS** 


**MICROPHONE** 

# **TO RESET PUP**

1. REMOVE **PUP FACE**. PULL STRAIGHT OUT, NOT DOWN.

2. HOLD DOWN **NOSE BUTTON** AND **PURPLE BUTTON** ON SIDE OF HEAD FOR **FIVE SECONDS**. PUP WILL MAKE NOISE WHEN RESET IS COMPLETE.

۲



The *Blu* SIG, Ind trade r

Produc

۲

®\* and TM & ® U.S. Pat

C0399

۲

# **HELPFUL TIPS**

• IF YOUR PUP'S NOT RESPONDING TO THE APP:

- BE SURE THAT PUP IS POWERED ON. REPLACE BATTERIES IF THERE'S NO POWER.
- FOLLOW APP INSTRUCTIONS FOR CONNECTING THE PUP TO YOUR DEVICE.
- MAKE SURE THAT PUP IS WITHIN 10 FEET OF DEVICE AND NOT CONNECTED TO ANOTHER ONE. IF IT IS, DISCONNECT.
- ALLOW THE APP TO TURN ON *Bluetooth*<sup>®</sup> IF PROMPTED.
- YOUR PUP DOESN'T LIKE WATER, SO KEEP IT AWAY FROM SINKS, BATHTUBS, POOLS, AND ALL OTHER WET PLACES.
- IF YOUR PUP ISN'T RESPONDING TO INPUTS PROPERLY, IT MAY BE TIME TO CHANGE THE BATTERIES.
- FOR MORE TIPS, GO TO FURREALMAKERS.COM

### SURFACE CLEAN ONLY GENTLY WIPE WITH CLEAN, DRY CLOTH. DO NOT GET WET.

DO NOT USE DETERGENT OR STAIN REMOVERS.

Product and colors may vary. Please retain this information for future reference.

The Bluetooth<sup>®</sup> word mark and logo are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Hasbro is under license. Other trademarks and trade names are those of their respective owners.

 $\textcircled{B}^*$  and/or TM\* & O 2016 Hasbro, Pawtucket, RI 02861-1059 USA. All Rights Reserved. TM & B denote U.S. Trademarks. US/CANADA TEL. 1-800-255-5516.

U.S. Pat. Nos. 6773344, 6356867 & 6160986.

C0399 PN00014446



# WILL YOU DREAMUP?

۲



furrealmakers.com

۲

۲