

4 HOUSING LABEL

4.1 Label Position

Label should be glued in the space foreseen on the backside of the plastic housing.

