

























INSIDE

- J1
- 1. UART1_RX
 - 2. BOOT0
 - 3. UART1_TX
 - 4. GND
 - 5. 3.3V
 - 6. SWDIO
 - 7. SHCLK
 - 8. GND

DUP3

DUP1

L10

DUP10

L6

L4

DUP8

ds
F4

ds
F4

ds
F4

F18C

F10C

C48C

F180

B50

R17C

B5U(824-849

R10

BI 281 30K