

Photo 1: Internal photo of EUT (Base)



Photo 2: Internal photo of EUT (Base)




Photo 3: Internal photo of EUT (Base)




Photo 4: Internal photo of EUT (Base)




Photo 5: Internal photo of EUT (Base)




Photo 6: Internal photo of EUT (Base)




Photo 7: Internal photo of EUT (Base)

Antenna




Photo 8: Internal photo of EUT (Handset)



Photo 9: Internal photo of EUT (Handset)



Photo 10: Internal photo of EUT (Handset)



Photo 11: Internal photo of EUT (Handset)

FR Module




Photo 12: Internal photo of EUT (Handset)

Antenna




Photo 13: Internal photo of EUT (Handset)

Battery



Photo 14: Internal photo of EUT (Charger)



Photo 15: Internal photo of EUT (Charger)

