

Setup Guide for



**For Windows 98SE/Me/2000/XP and Vista
& Mac OS X 10.3.9 or later**

Use this to quickly setup and use your mimio wireless.

Box Contents



Wireless Module - Replaces the USB Module on any mimio Xi, enables wireless communication



USB Adapter - Plugs into any available USB port, provides a wireless link to your mimio Xi



USB Cable - Extension cable for the USB Adapter, for computers with very close USB ports



AC Adapter - Provides persistent power for your mimio Xi



mimio Studio - Advanced user friendly interactive application suite

System Requirements



Microsoft Windows

- IBM compatible, Pentium 166 MHz minimum
- MS Windows 98SE/ME/2000 or XP
- 32 MB RAM minimum (64 MB RAM recommended)
- 30 MB free disk space minimum
- CD-ROM Drive
- Available USB port



Mac OS X

- 400 MHz processor (800 MHz or faster recommended)
- Mac OS X version 10.2.7 or higher
- 128 MB RAM minimum (256 MB RAM recommended)
- 30 MB free disk space minimum
- CD-ROM Drive
- Available USB port


Setup Process

1




Install the mimio software from CD if not already installed. Check our website for the latest mimio software (www.mimio.com).

2



Depress the release button and slide the linkUSB module downward to remove the module from the mimio Xi.

3



Insert/slide the Wireless Module into the mimio Xi.

Setup Process continued

4



Plug the Wireless USB Adapter into an available USB port. If there is insufficient space to fit the USB Adapter into a USB port, the included USB Extension cable can be used with the USB Adapter to allow for the USB connection.

5




OR



Power on mimio Xi. mimio Xi can be powered by 4 AA batteries or the included AC Adapter.

Setup Process continued

6



Open the mimio software.

7



Begin using a mimio stylus to use your mimio Wireless.