



Switches 1 thru 4 select among sixteen different ID codes.
Switches 1 thru 3 select among eight different frequencies.

1	2	3	MHz
ON	ON	ON	903.37
OFF	ON	ON	906.37
ON	OFF	ON	907.87
OFF	OFF	ON	909.37
ON	ON	OFF	912.37
OFF	ON	OFF	915.37
ON	OFF	OFF	919.87
OFF	OFF	OFF	921.37