

Wireless Wrist Band operation guidance




1. Wear the wrist band as below:




5. APP interface introduction

5.1 There are 4 main features will be displayed on the main page, include "steps taken", "Calories burned", "Distance walked" and "Time walked" in the day.



5.2 Press "Record" to enter the activity record menu. This menu will show you all activities on a daily, weekly, or monthly basis.




2. Parameters:

- Bluetooth version: Bluetooth 4.0
- Input voltage: DC 5V
- Range of application: -20℃-60℃



3. Screen display introduction  
3.1.To activate the screen, tap/click on the screen twice to display the time as below.



3.2.Tap/click on the screen again to switch between the following modes.



5.3 Press "Sleep" to enter the Sleep record menu. This menu will show you all your sleep activities on a daily, weekly, or monthly basis.




3.3.Tap/click on the screen four times to enter the sleep mode.

3.4.Tap/click on the screen four times to exit the sleep mode, and enter the "Time Display"

6.Data Sync

After successful connection, return to main interface, then finish User Setting and Goal Setting, after that, all data from Band will be sync with app software.Besides, there are other three main functions as below:



3.5.Charging the Band

Use the supplied charger to charge smart wristband. Once connected properly your device will display "Charging" as below.

Attention:

- When charging, sport record and sleep detecting are invalid
- When battery energy was totally used up, it needs about 1.5 hours for full charging
- Disconnect the charging cable, it will return time display interface

Downloading app from mobile phone:

Searching "SmartFit"(SmartFit-Wristband) on the software store or google play of mobile phone, and download it.

Attention:

Mobile phone needs android 4.3 or higher versions, or IOS 8.0 or higher versions.

6.1.Sharing function

In the main interface, click "Share" to social media, slip up or down to view the content sharing, click sharing to view platform and choose one to share.(sharing platform will be different according to different software installed from mobile phone)

6.2.Reminder function :

In the main interface, click "Reminder" to enter reminder setting interface, set sedentary and drinking time. When it is at reminder time, The smart wristband will vibrate for 3 seconds during reminders. Click on the screen once to stop the reminder.

6.3 The App is equipped with 2 alarm settings: The smart wristband will vibrate for 10 seconds during reminders. Click on the screen once to stop the reminder

sedentary reminder

drinking reminder

After downloading and installation, there is "SmartFit" symbol in mobile phone, please click it and enter, will see below interface:

4.Connecting the Activity tracker to the APP

4.1. Click "SmartFit" and displays connection setting as below picture:

4.2.Tap the "connection setting" then it displays as below picture.

4.3.Tap/click on the screen twice to activate the screen, the App will automatically search for your smart wristband.

6.3 The App is equipped with 2 alarm settings: The smart wristband will vibrate for 10 seconds during reminders. Click on the screen once to stop the reminder

4.4.Tap the "connection setting" then it displays as below picture.

4.5. After click "Connect", at same time, Band device display ten seconds connection countdown as below:

4.6. Once the countdown begins, tap on the activity tracker screen in order to repair. SYNC will appear on the activity tracker screen once paired successfully.

Tracker is accessory with adsorbed back clip type USB charging base

When charging,insert the USB port to USB adaptor or USB power port(USB output port of computer),another head attach to the back charging area,the back clip has adsorbed function(no left and right direction,see below charging way)

Once connected properly your activity tracker will display "Charging" as the picture below. The manufacturer already did the current limit protection on the tracker, so it won't cause damage due to large current. Please charge it in the correct way.

4.4.Tap the "connection setting" then it displays as below picture.

4.5. After click "Connect", at same time, Band device display ten seconds connection countdown as below:

4.6. Once the countdown begins, tap on the activity tracker screen in order to repair. SYNC will appear on the activity tracker screen once paired successfully.

Common problems and solutions

- The screen can not be light up or activated. Please charge the tracker and keep it has enough battery power
- Tracker can not connect to the APP. Please check your phone's version. It should be IOS 8.0 or higher versions, and android 4.3 or higher versions. If the tracker already paired with other devices, then disconnect it first.

Attentions:

- When charging,please keep it away from high temperature,strong magnet,humid environment
- When wrong operation or other reasons caused disconnection with APP,please unpair it from tracker or APP and pair it again
- One tracker only can pair with one device When the device is paired with other tracker,must unbundle it firstly,then pair with new tracker
- It won't give a special declaration because of software updating
- APP is only compatible with IOS 8.0 or higher versions,android 4.3 or hither verions.

4.4.Tap the "connection setting" then it displays as below picture.

4.5. After click "Connect", at same time, Band device display ten seconds connection countdown as below:

4.6. Once the countdown begins, tap on the activity tracker screen in order to repair. SYNC will appear on the activity tracker screen once paired successfully.

Common problems and solutions

- The screen can not be light up or activated. Please charge the tracker and keep it has enough battery power
- Tracker can not connect to the APP. Please check your phone's version. It should be IOS 8.0 or higher versions, and android 4.3 or higher versions. If the tracker already paired with other devices, then disconnect it first.

Attentions:

- When charging,please keep it away from high temperature,strong magnet,humid environment
- When wrong operation or other reasons caused disconnection with APP,please unpair it from tracker or APP and pair it again
- One tracker only can pair with one device When the device is paired with other tracker,must unbundle it firstly,then pair with new tracker
- It won't give a special declaration because of software updating
- APP is only compatible with IOS 8.0 or higher versions,android 4.3 or hither verions.

Once your device is successfully paired with the activity tracker, the APP will display a green LED "✓" on the top left hand connner. And the activity tracker will also display the bluetooth logo on the screen.

Attentions:

Toggle "Auto Upload" to upload sport record and sleep record from Band to app software(in sleep mode, sport data won't update to app software)

FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.