

User Manual

1. Receiver access to a computer USB port, the bright lights at this time.
2. Press the key to the code, the indicator light will flash at this time.
3. Power switch to open the mouse, press the button on the code, when the receiver does not light a long-time flash on the mouse and receiver on the success of the code.
4. Following the success of the code, the next time without the use of code for.
5. When the mobile mouse , the receiver will receive the mouse signal lights will flash
6. When the mouse did not find the feedback signal receiver, this time moving the mouse or the mouse button pressed, the mouse wheel flash Lantern Festival, prompted not connected to the receiver.

Dynapoint(DongGuan)Inc.

6th Industrial Park, shangsha Cun, South Area ChangAn, DongGuan GuangDong China.

FCC WARNING

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

NOTE: The manufacturer is not responsible for and radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.