

## 1. General Functions

Turn on	Press power button until the light turns blue, if there is a device connected before, automatically connect the previous device, otherwise enter pairing mode, the red and blue flash in turns.
Enter the pairing mode	If product is paired before, it will automatically connect the previous device when turned on. If there's no previous device, it will enter pairing mode, the red and blue flash in turns, when connected, and the blue LED flashes blue twice per 5 seconds.
Pairing	In pairing mode, use a mobile phone with Bluetooth function or other Bluetooth Master Device to perform pairing action.
Turn off	When device is on, press the power button 4 seconds, the red LED flashes for 1second, the product shuts down.
Charging	Plug the charger to port of the device. (Red LED is on.)
Answer call	Short press power button for an incoming call.
End call	Short press power button again to end call.
Transfer call between headset and device	Long press power button for 1 second to transfer the call between the mobile phone and the device during on-going call.
Reject call	Long press power button for 1~2 seconds to reject incoming call.
Incoming second call	When there's a second incoming call, short press the power button to answer the second call or long press the power button for 1 second to reject the second call. When answering the second call, the current call will be on hold. Long press the middle button for 1 second to switch between the second call and the previous call, short press the middle button to end the current call.
Volume up	Short Press "+" button for volume up.
Volume Down	Short Press "-" button for volume down.
Next	Short press "V" button for next track.
Previous	Short press "Λ" button for previous track.
Play/pause	Short press power button to play/pause the music when the product is connected.
Stand by	Under pairing mode, if there is no device to connect, it goes into standby mode.
Automatic power-off	In standby mode, if there is no device to connect, it will shut down automatically in 2 minutes.
Factory reset	Press "+" and "-" for 4 seconds, light flashes red once, to restore factory settings. Pairing information is cleared, you will need to enter pairing mode again to activate the Bluetooth feature.

## 2. Pairing to a phone or entertainment device:

- Turn on your phone and ensure its Bluetooth function is activated.
- Turn on the Bluetooth Headset and go to the pairing mode.
- Search your Bluetooth devices on your phone by following the phone's instructions. Refer to your phone's user manual for more information.
- After a few second the phone will list the device as a discover device. Select it and follow your phone instruction to select this pairing.
- Your phone will confirm the pairing, and then press Yes/Ok.
- Finally, select "connect with device" from your phone.

## 3. Line in input

EKU-LNK2-BK supports a 3.5mm audio jack line in when the battery is low or where wireless devices cannot be used.

**FCC Caution:**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.