

INSTRUCTIONS MANUAL

CONTENTS

PRODUCT OVERVIEW AND INTRODUCTION

FUNCTIONS AND FEATURES

USAGE

PRECAUTIONS

TROUBLESHOOTING

WARRANTY INFORMATION

FCC NOTICE

Dear customers:

We at Sam Jin Development thank you and congratulate you on your purchase of Molle. We all hope this product will help you have a more comfortable and convenient experience in the bathroom or where ever you may use this product.

SAM JIN R&D CO., LTD.

■PRODUCT OVERVIEW AND INTRODUCTION

1. The automatic sensor is set in Molle. When the automatic sensor senses motion in its field of view, music is automatically played, and smoothly stops when it no longer senses motion.
2. Molle helps save water, by concealing any sound during your time of defecation.
3. The natural sounds set in Molle contains Alpha wave and waving of 1/f (look in page 3 for details).
4. A built in motion detector in Molle, can be used as security. It alarms you of any motion in the area.

5. If you want to listen to your favorite music or data of studying, you can download from Computer or MP3 player etc. by using USB cable.

6. The Aroma of Molle makes you a refreshing feeling and agreeable bathroom.

■FUNCTIONS AND FEATURES

Simple automatic sensor

Functional music from natural sounds

The benefits and effect of saving water

High quality hardware

Security Alarm

USB Port

Modern design

Development

■SPECIFICATION

Model: R-1265

Voltage: DC9V 300mA

Memory: 128Mb

Audio: Stereo

Speakers: Cloth-wave, 3 in. 8 ohms

Size(mm): height 90 × length × 280 width 48

Weight: 450 g

■Parts and components

1. Molle is configured so that it is easily set up, you can mount it on a wall by using the 2 holes on the back or with the bracket, you can also use the bracket to place on a stand.

2. Motion detector

3. Decoration face

4. Bracket

5. Volume Control <High/Low>

6. Sensor Distance Control <Far/Near>

7. USB Port

8. Aroma Membrane

9. Power

10. Power Adapter

■Usage

1. Insert the adapter to an outlet.
2. Set a suitable place after checking the distance and angle of the sensor.
 - Do not put any items that may obstruct the sensors field of view.
 - Set the sensor distance according to the installed place by turning the "Sensor Distance Control" <Picture 2>
3. Set the volume to your preference with the volume control.
 - The volume will automatically be set to default (medium) every time the power is turned off/on.
4. There will be a 10 second delay for reactivation of Molle every time you turn it on/off. (It takes about 10 seconds for the program to be reset)
5. Open the Aroma Membrane and put into the membrane housing.
6. If you want to listen to your favorite music or data of studying, you can download from Computer or MP3 player etc. by using USB cable. <Picture 3>

■PRECAUTIONS

1. Please use only the adapter that's included with Molle.
2. Tightly insert the adapter to Molle.
3. Please read the instructions manual before use.
4. Do not place Molle near a heater or any other place that may have high temperatures. This may severely damage Molle.
5. Never touch the adapter with wet hands.
6. For long lasting high quality sound and durability of your product, please follow these instructions.
 - Do not splash water directly to Molle.
 - Do not place Molle in a room with thick fumes for a prolonged period.

■TROUBLE SHOOTING

Having problems? Please read and check the following.

Problems:	Answers:
It's not working.	Is the adapter properly plugged into Molle and a power outlet?
Low quality sound and	Is Molle set in a damp room?

volume.	If so please remove Molle to a dry and cool place. Caution: Never dry Molle with a hair dryer or any other type of heat producing items.
---------	---

■WARRANTY INFORMATION

1. This product is manufactured through strict inspection and through a quality control process.
2. Warranty service is only valid during the warranty period.
3. Please submit the warranty card that is included with Molle when asking for warranty service.
4. Despite warranty period, warranty will be void under the circumstances listed below.
 - Damage caused by users carelessness.
 - Damage caused by mishandling of product.
 - Damage caused from natural sources such as electricity overload.
 - When you use this product at another location other than in your home.
 - When you don't have a warranty card.
 - When the card has been altered in any way.
5. The warranty card is issued only once at the time of your purchase.
6. After the warranty period is over you will have to pay for any costs relating to services or repairing of your product.

■FCC NOTICE

Caution: Any changes or modifications in construction of this device which are not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generated, uses instructions, may cause harmful interference to radio communications, However there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures.

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.
- Connect the equipment into outlet on a circuit different from that to which the receiver is connected

Consult the dealer or an experienced radio/TV technician for help