

# 1134 Label location

---

The 1134 LF RFID Reader has a single label on the back of the reader. The serial number is printed on a paper label which is protected behind a self-adhesive label. The self-adhesive label is printed on 0.125mm velvet polycarbonate with a 3M 468MP adhesive backing or equivalent.

