


**Label Location**


<Bottom of the EUT>




Label Here

**RUCKUS®**  
**R350 Access Point** 無線接入點  
Default IP Address: 192.168.0.1  
User name=super Password=sp-admin




860-76557-001-B



Ruckus Wireless, Inc.  
350 West Java Drive  
Sunnyvale, CA 94089 USA  
Marca/Brand: Ruckus  
Model(型號/型号): R350

 Tested To Comply  
With FCC Standards  
FOR HOME OR OFFICE USE

For indoor use only  
FCC ID: S9GR350  
IC: 5912A-R350  
額定輸入: 12V === 1.0A 12伏特 1.0 安培(DC)  
48V === 0.35A 48伏特 0.35 安培(PoE)  
For applicable power supplies, see user instructions

 R-NZ  
 CE  
  
Made in XXX