


Label Location



<Bottom of the EUT>





Label Here



RUCKUS®
T350c Access Point
Default IP Address: 192.168.0.1
User name=super Password=sp-admin

860-7655-0102-4B

 Tested To Comply
With FCC Standards
FOR HOME OR OFFICE USE
FCC ID: S9GT350C
IC: 5912A-T350C

 D39347
RoHS

48V \equiv 0.40A

Ruckus Wireless, Inc.
350 W Java Dr.
Sunnyvale, CA 94089 USA
Origen/Made in XXX