








## Label Location



<Bottom of the EUT>

Label Here

	<b>RUCKUS®</b> <b>T350se Access Point</b> Default IP Address: 192.168.0.1 User name=super Password=sp-admin	  RUCKUS
 Tested To Comply With FCC Standards FOR HOME OR OFFICE USE	 D33D96 RoHS	FCC ID: S9GT350SE IC: 5912A-T350SE For patents, see www.cs-pat.com 48V== 0.40A
 R-NZ	Origin/Made in XXX	Ruckus Wireless, Inc. 350 W Java Dr. Sunnyvale, CA 94089 USA Model: T350se