




Sonoran Cereus Patio Lamp


# Lamp Instructions


Assemble as Easy as.....



To remove/install battery (G), remove Finial (I) and twist off Battery Cover (H).








UMBRELLA INSERT

### **Parts**



Electronic Housing







Ε






Cover












## Remote Instructions

Please read instructions carefully and retain it for future reference.



#### **BATTERY SAVER MODE**

Press the battery-saving key at any time when the lamp is on. The lamp will be on 100% Lumen power and gradually decline from bright to dim to
off within 2 seconds, then again go on 100% Lumen power and gradually decline from bright to dim to off within another 2 seconds.... after this
process cycled 3 times, it goes into the battery power-saving mode.

#### PAIR/SYNC LAMP WITH REMOTE CONTROLLER

- The remote controller and the lamp will be paired/synced before it is shipped.
- Insert the battery pack into lamp, then turn lamp on, it will be lit immediately by 20%Lumen Power.
- Press the ON/OFF switch on the lamp (the pressing time is less than 2 seconds), and switch between on and off.
- Press the ON/OFF switch on the lamp for about 3 seconds, and the lamp will start to turn on slowly and turn off slowly, this means the lamp is in the syncing/pairing state.
- At this time, press the ON and OFF key on the remote controller at the same time, until the lamp turns 20% Lumen Power, the remote controller and the lamp are paired.
- Each lamp can only pair one remote controller.

#### RECOMMENDED CLEANING TIPS

- Clean the shade with a damp soft clean cloth. The shade can be protected by spraying with a water repellent product.
- Metal part of the lamp can be cleaned with a damp soft clean cloth.

## **Safety Information**

You are cautioned that changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

This Device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference, and
- This device must accept any interference received, including interference that may cause undesired operation.

#### **Battery Safe Handling:**

- Do Not Mix Old And New Batteries.
- Do Not Mix Alkaline, Standard (Carbon Zinc), or Rechargeable (Nickel – Cadmium) Batteries.
- □ Battery must be recycled or disposed of properly.
- Keep battery away from children. If swallowed, promptly see a doctor. Do not open battery, dispose of in fire, put in backwards, or short circuit—it may ignite, explode, leak or get hot causing injury.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



**WARNING:** Keep batteries out of reach of children.