

4. SETUP PHOTOS

DYNAMIC FREQUENCY SELECTION MEASUREMENT SETUP

MASTER CONFIGURATION:



DFS BACK PHOTO



SLAVE CONFIGURATION:



END OF REPORT