
PHOTOGRAPHS of Changed Items

LCD Rear Cover

(Before : VK1000)



(After:VK1010)



LCD Rear Cover

(After :VK1020)



LCD Rear Cover

(Before : VK1000)



(After:VK1010)



LCD Rear Cover

(After :VK1020)



**LCD Front Cover
(Before : VK1000)**



(After:VK1010)



LCD Front Cover

(After :VK1020)



**LCD Front Cover
(Before : VK1000)**



(After:VK1010)



LCD Front Cover

(After :VK1020)



**Keypad Cover
(Before : VK1000)**



(After:VK1010)



Keypad Cover


(After :VK1020)



Keypad Cover
(Before : VK1000)



(After:VK1010)



LCD Cover

(After :VK1020)

