

Vivitar One Year Warrantv

This warranty covers the original consumer purchaser only and is not transferable.

This warranty covers products that fail to function properly UNDER NORMAL USAGE, due to defects in material or workmanship. Your product will be repaired or replaced at no charge for parts or labor for a period of one year.

What Is Not Covered by Warranty

Damages or malfunctions not resulting from defects in material or workmanship and damages or malfunctions from other than normal use, including but limited to, repair by unauthorized parties, tampering, modification or accident.

To obtain Warranty Service and Troubleshooting information:

Call 1-800-592-9541 in the U.S. or 0-800-917-4831 in the U.K or Visit our website at www.vivitar.com

To receive Warranty service along with the name and address of an authorized product service center, the original consumer purchaser must contact us for problem determination and service procedures. Proof of purchase in the form of a bill of sale or receipted invoice, evidencing that the Product is within the annlicable

Warranty period(s), MUST be presented in order to obtain the requested service. It is your responsibility to properly package and send any defective products along with a dated copy of proof of purchase, a written explanation of the problem, and a valid return address to the authorized service center at your expense. Do not include any other items or accessories with the defective. product. Any products received by the authorized service center that are not covered by warranty will be returned unrepaired.

Vivitar One Year Warranty (continued)

NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT

OTHER THAN THOSE EXPRESSLY DESCRIBED ABOVE SHALL APPLY. DISTRIBUTOR FURTHER DISCUAINS AU WARRANTIES AFTER THE EXPRESS WARRANTY PERIOD STATED ABOVE. NO OTHER EXPRESS WARRANTY OR GUARANTY GIVEN BY ANY PERSON FIRM OR ENTITY WITH RESPECT TO THE PRODUCT SHALL BERINDING ON DISTRIBUTOR REPAIR REPLACEMENT OR REFUND OF THE ORIGINAL PURCHASE PRICE - AT DISTRIBUTOR'S SOLE DISCRETION - ARE THE EXCLUSIVE REMEDIES OF THE CONSUMER IN NO EVENT WILL DISTRIBUTOR, ITS MANUFACTURERS, OR SAKAR INT, BELIARI F FOR ANY INCIDENTAL, DIRECT, INDIRECT, SPECIAL, PUNITIVE OR CONSEQUEN-TIAL DAMAGES (SUCH AS, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF PROFITS BUSINESS SAVINGS DATA OR RECORDS) CAUSED BY THE USE MISUSE OR INABILITY TO USE THE PRODUCT, EXCEPT AS STATED HEREIN, NO OTHER WARRANTIES SHALL APPLY NOTWITHSTANDING THE FOREGOING CONSUMER'S RECOVERY AGAINST DISTRIBUTOR SHALL NOT EXCEED THE PUBCHASE PRICE OF THE PRODUCT SOLD BY DISTRIBUTOR. THIS WARBANTY SHALL NOT EXTEND TO ANYONE OTHERTHAN THE ORIGINAL CONSUMER WHO PURCHASED THE PRODUCT AND IS NOT TRANSFERABLE.

Some countries, states or provinces do not allow the exclusion or limitation of incidental or consequential damages or allow limitations on warranties, so limitation or exclusions may not apply to you. This warranty gives you specific legal rights, and you may have other rights that vary from state to state or province to province. Contact your authorized retailer to determine if another warranty applies. This product is manufactured, distributed and sold by SAKAR International, Inc. All other trademarks are the property of the respective owner, who has not sponsored, endorsed or approved this product.

Introduction

Thank you for purchasing the Vivitar Voltage Wireless Speaker, Item V1322B1 You can use this item with iPads, iPhones, iPods and many types of smartphones to stream

music, and enjoy hands-free calling. In order to get the best results when using this device, please read this manual first before using.

Features Speaker Functions

-Rechargeable and Portable -Auxiliary Port

Specifications

Bluetooth Specification: V2.1+EDR Operation Frequency: 2.402-2.48GHz Supported Profile: HSP. HEP. A2DP Operation Range: Up to 10 meters Play Time: 2 Hours Charge Time: Approximately 3 Hours

Package Contents

-Bluetooth Speake -USB Charging Cable -3.5mm Auxiliary Cable -User's Manual with Warranty Information

Important Safety Precautions

When using your Bluetooth Speaker, basic safety precautions should always be followed, including the following:

1. Do not use this device near water. Clean using a dry or slightly moist cloth.

 Do not place your speaker on any wet surfaces. 3. Do not allow children or the infirm to play with this speaker without adult

supervision.

4. Do not expose your speaker to excessive heat, flames or fire.

battery will lose its capacity if it is not used on a regular basis.

Important.

Ensure that the battery is fully charged if you do not use the device for a long period of time. To avoid a complete discharge of the battery, the V1322BT should be charged at least once every 6 months.

Charging Your Speaker

The V1322BT speaker is powered by an internal rechargeable battery. Charge the battery completely before its first use. Read the section titled "Battery information" in this manual before starting the charging process. 1) Connect one end of the included USB Charging Cable to your speaker's charaina port

2) Connect the other end of the USB Charging Cable to a USB port. 3) When your speaker is charging, the red LED indicator light will turn red. The battery will take approximately three hours to fully charge 4) When the battery is fully charged, the LED indicator light will turn off. Disconnect the charging cable from your speaker and the outlet. Your speaker is ready to

NOTES:

- Give your speaker a full charge before using for the first time. - When the battery power is low, the indicator light will turn red and start to flash.

Turning ON Your Speaker

Before you can start using your speaker, you must first charge the rechargeable battery. Once charged, slide the ON/OFF switch to the ON position to power on vour speaker.

If your speaker completed the pairing process successfully, when the speaker is turned on, it will connect to the phone you last connected to automatically. Please ensure your phone's Bluetooth® function is active.

Turning OFF Your Speaker

Slide the ON/OFF Switch to the OFF position to power down your device. Note: To conserve power, if your speaker is not connected to a device for approximately 10 minutes, it will turn off automatically.

Pairing Your Speaker to a Bluetooth Phone

Before you use your speaker the first time, you must pair it with a Bluetooth® enabled mobile phone. Pairing is a one time process and required only for the first connection with the Bluetooth® enabled mobile phone. The V1332BT can be connected with two Bluetooth® enabled mobile phones simultaneously. 1) Keep the V1332BT within one meter range of a Bluetooth® enabled mobile phone.

2) Slide the ON/OFF Switch to the ON position. The LED indicator light on your speaker will illuminate, flashing red and blue alternately. The device is now in pairing mode.

3) Find the Bluetooth® setting of your mobile phone and start the search for Bluetooth® devices. (For further details, please read the operating instructions of vour mobile phone).

 From the list of devices found, select your speaker." Vivitar speaker." 5) If required, enter the PIN code "0000" and confirm the entry. Once the pairing process was successful the V1332BT will connect to your mobile phone automatically then switch to standby mode. The LED light indicator light will turn solid blue.

Note: - If pairing is not completed within 10 minutes, the speaker will turn off. If this happens, please repeat the pairing steps.

Listening to Music on Your Speaker

pause.

Play/Pause Press the Speaker button to get music from your audio SOURCE to play or The V1322BT has an ALIX-IN port which can be used to connect an additional audio source using the included 3.5mm Auxiliary Cable. When an audio source is plugged in using the 3.5mm Auxiliary Cable, any music playing on your speaker will pause and music playing from the plugged in audio source will play instead.

The V1322BT supports the A2DP profile which allows stereo music to stream from a Bluetooth phone. The music will pause automatically if a call is incoming, and resume when the call has ended.

Using Your Speaker during a Phone Call Last number re-dialing

Press and hold the Speaker button for two seconds, and the last number you dialed will be redialed

Answering a call Press the Speaker button to answer an incoming call.

Ending a call

Press the Speaker button to end a call.

FCC and IC Statements For Users (USA & Canada Only)

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference , and (2) this device must accept any interference received, including interference that may cause undesired operation.

This class B digital apparatus complies with Canadian ICES-003. Cet appareil numérique de la classe B est conforme á la norme NMB-003 du

Caution: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the

equipment NOTE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules, These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates. Uses and can radiate radio frequency energy and, if not installed and used in accordance with instructions. May cause harmful interference to radio or -television reception, which can be determined by turning the equipment off and on, the user is

encouraged to try to correct the interference by one or more of the following measures:-Reorient or relocate the receiving antenna.-Increase the separation between the equipment and receiver.-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.- Consult the dealer or experienced radio/ TV technician for help.



The product is made conforming with all the applicable European regulations.

The device (including its removable parts and accessories) must not be disposed of together with municipal waste at the end of its life, but in compliance with European Directive 2002/96/EC. Since must be handled separately from household waste, either carry it o a separately-collected waste disposal center for electrical and electronic appliances or give it back to be retailer on purchasing a new device with the same purpose. Any infringement will be severely prosecuted.

尺寸: 70*362.5MM

External Audio Input

Always press all buttons carefully. Do not manhandle your speaker. 6. Do not use in extremely dry environments, as this can lead to static discharge

7. Do not expose speaker to temperatures above 35°C. Keep out of direct

8. Do not attempt to repair this product yourself. Contact a qualified service

center if this speaker is in need of service.

9. Do not drop, puncture or expose your speaker to excessive trauma. 10. This speaker is not intended for commercial use.

11. Do not place near objects that generate a strong magnetic field.

A Quick Look at Your Device

during usage

sunlight



1. ON/OFF Switch 2. LED Indicator Light 3 ALIXIN Port 4. Sneakerphone Button

- 5 Microphone
- 6. Charaina Port

Battery Information

The device is equipped with an integrated lithium-polymer battery. The battery cannot be replaced. Do not attempt to remove the battery from the device since it would damage the device. The full performance of a new battery is not achieved until after two or three complete charging-discharging cycles. The battery can be charged and discharged several hundred times, but it loses its capacity over time

Disconnect the V1322BT from the power supply as soon as the battery is fully charged, overcharging would reduce the service life of the battery. A charged

