




HEADRUSH®

8074003

INSTRUCTION MANUAL

# HeadRush BT NFC Speaker HRSP 5005

HRSP 5005  
FLOAT




## WHAT'S INCLUDED:

- Speaker
- Micro USB charging cable
- 3.5mm audio cable
- Instruction Manual

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth® SIG, Inc. and any use of such marks by The Source (Bell) Electronics Inc. is under license. Other trademarks and trade names are those of their respective owners.

### COMPONENT IDENTIFICATION

1. Power ON/OFF
2. Decrease volume/Previous track
3. Increase volume/Next track
4. NFC connection location
5. LED indicator
6. USB charging port
7. AUX in
8. 1/4"-20 mount attachment location (accessories sold separately)



### PRODUCT OVERVIEW

You can use this item with iPad®, iPhone®, iPod® devices and many types of smartphones to stream music, and enjoy handsfree calling. In order to get the best results when using this device, please read this manual first before using. This unit has IP67 rating: Dust tight, protected against temporary immersion in water.

### PAIRING

1. Make sure your Bluetooth® audio source is held within 10 metres of your speaker.
  2. Press and hold the power button for around 2 seconds. The speaker will turn ON and enter pairing mode. The speaker will beep and the red and blue LEDs will flash alternately.
  3. Enable your Bluetooth® device, and make sure it is in searching mode.
  4. Select "HR Float" from the list of discovered Bluetooth® devices on your mobile phone. Enter PIN "0000" if required. Once paired the speaker will beep.
  5. You can now listen to your music or make/receive telephone calls on the speaker.
  6. To turn the speaker OFF hold the Power ON/OFF button, you will hear a beep.
- Tip:** The next time you switch the speaker ON, it will connect automatically as long as your Bluetooth® function is switched ON on your audio device.
- When you disconnect the speaker while paired, the blue and red LED will start to blink quickly, the speaker has entered into pairing mode. If there is no device paired within 15 minutes, the speaker will turn OFF.

### PAIRING BY ONE-TOUCH CONNECTION WITH NFC

1. Enable the NFC function on your device and turn the speaker ON.
2. Unlock your NFC-enabled device and touch the NFC logo on the speaker.
3. Confirm the NFC connection on your device. This will vary depending on your device, check your device manual for compatibility.

### CHARGING

This speaker has a built-in rechargeable Li-Ion battery. Fully charge the speaker before first use. Charge the battery as follows:

1. Connect one end of the included USB charging cable to the charging port on your speaker. Then plug the other end of the USB charging cable into a suitable port on your computer or 5V/1A power adapter (sold separately).
2. The red LED light will turn ON. When the charge is complete the red LED light will turn OFF.
3. It will take 3 hours to fully charge the speaker.

**Tip:** When battery is low the speaker will beep periodically. Charge the speaker. If the speaker is not plugged in to charge within approximately 15 minutes, it will turn OFF.

### HANDSFREE SPEAKERPHONE

When a smartphone is connected to your speaker follow the steps below to take calls handsfree.

1. If there is an incoming call while streaming music the speaker will ring for iOS ring tone or beep for Android™.
2. Short press the Power ON/OFF button to answer the call.
3. Short press the Power ON/OFF again to end the call.

### LINE-IN

1. Use the supplied 3.5mm cable to connect the speaker directly with your device.
2. The LED turns solid blue.

**Tip:** LINE-IN will take priority over Bluetooth® connection.

### OPERATION

TO	DO THIS
Play/pause	Press the  button to play, press again to resume.
Next track	Press and hold the  button for 2 seconds.
Previous track	Press and hold the  button for 2 seconds.
Increase volume	Press the  button.
Decrease volume	Press the  button.
Answer call	Press the  button.
End call	Press the  button.
Redial	Press the  button twice in standby mode.
Increase call volume	Press the  button.
Decrease call volume	Press the  button.

### UNDERSTANDING THE LED STATUS LIGHTS

- **When charging your speaker**
  - o Solid red LED=charging
  - o LED OFF=charging complete
- **When pairing your speaker to a Bluetooth® device**
  - o Quick blinking blue and red LED=Bluetooth® not connected, ready to pair
  - o Slow blinking blue LED=Bluetooth® connected
- **When connected via LINE-IN**
  - o Slow blinking blue LED=connected

### TECHNICAL SPECIFICATIONS

Carrier Frequency : Bluetooth® 4.2+EDR  
 Battery Capacity : 3.7V, 2200mAh  
 Frequency Response: 100Hz -20kHz  
 Operation Distance: Up to 10 metres/33 feet  
 Output Power: 3Wx2 (Max)  
 Impedance: 4 Ohms

**NOTE:** This speaker is in compliance with the specified Bluetooth® version. It does not guarantee compatibility with all the functions on every Bluetooth® enabled device. Please check your mobile phone's user manual for compatibility and functionality.

### TROUBLESHOOTING

No Sound:

- Ensure the speaker is charged and has enough battery power for operation
- Ensure the speaker is switched ON
- Ensure Bluetooth® device is ON
- The volume of the speaker is too low, adjust the volume to an appropriate level

**WARNING:** Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### THE FCC WANTS YOU TO KNOW

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference and
- (2) this device must accept any interference received, including interference that might cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### Industry Canada Notice

This device complies with RSS-247 of Industry Canada. Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.

This digital apparatus does not exceed the Class B limits for radio noise emissions from digital apparatus set out in the Radio Interference Regulations of Industry Canada.

IC: 255A-8074003

## THE SOURCE - WARRANTY

The Source warrants that this product will be free from defects in materials and workmanship for a period of 12 months from the date of purchase. Within this period, simply take the product and your proof of purchase to any The Source store or participating dealer and the product will be replaced (where available) without charge. Any product which has been subject to misuse or accidental damage is excluded from this warranty.

This warranty is only applicable to a product purchased through The Source company-owned stores or participating dealers in Canada where the warranty is included with the product. While this warranty does not confer any legal rights other than those set out above, you may have additional statutory rights which will vary under the laws of the various countries, states, provinces and other governmental entities in which The Source operates. This warranty is subject to all statutory rights you may have in Canada.

Imported by:  
The Source,  
Barrie, Ontario, Canada, L4M 4W5

Manufactured in China

www.headrushaudio.com



Please Recycle  
© 2018 The Source  
All rights reserved.