

BIUCXTCI 深圳澳特爱电子有限公司 ATI Electronics (Shenzhen) Co.,LT

W320(80×4)×H70mm, 80g书写纸, 单黑双面印刷

Vivitar[®] VL60011BT Bluetooth[®] Speaker User Guide

Thank you for purchasing the Vivitar® VL60011BT Bluetooth® Speaker.

Introduction

With this speaker, you will enjoy listening to high quality music wirelessly using Bluetooth® technology. Easily connect to any mobile device for both conversation and music listening. It also pairs with other Bluetooth-enabled devices (Bluetooth V4.1+EDR specification and HSP, HFP, A2DP and AVRCP profiles)

Specifications

 Bluetooth Specification: V3.0+EDR Operation Frequency: 2.402-2.48GH; Supported Profile: HSP. HEP. A2DP. AVRCE Operation Range: Up to 33 feet (10 meters) Talk Time: 5 hours Play Time: 4 hours Standby Time: 10 hour

 Battery Type: 400mAh, 3.7V. Polymer Lithium Ion Battery Charge Time: 2 Hours In the Box

 Bluetooth[®] Sneaker USB Charging Cable

 User Manu Safety Precautions

Please read this User Manual carefully and follow all instructions

W320(80×4)×H70mm, 80g书写纸, 单黑双面印刷

Turning OFF Your Speaker Slide the ON/OFF Switch to the OFF position to power down your device

Pairing Your Speaker to a Bluetooth Phone



the Bluetooth® enabled mobile phone. 1. Keep the VL60011BT within one meter range of a Bluetooth® enabled mobile phone 2. Slide the ON/OFF Switch to the ON position. The LED indicator light on your speaker will

- illuminate, flashing red and blue alternately. The device is now in pairing mode 3. Find the Bluetooth® setting of your mobile phone and start the search for Bluetooth® devices (For further details, please read the operating instructions of your mobile phone)
- 4. From the list of devices found, select your speaker "Vivitar 60011".
- 5. If required, enter the PIN code "0000" and confirm the entry. Once the pairing process was successful, the VL60011BT will connect to your mobile phone automatically then switch to

Listening to Music on Your Speaker

版

单

Plav/Pause Press the Play/Pause button to get music from your audio source to play or pause



• To avoid damage or malfunction of the speaker do not drop it from high locations and/or on to hard surfaces, do not place heavy objects on it. Keep speaker away from humidity, water and other liquids. If it does get wet, do not operate as this may cause an electrical shock, explosion and damage to the device or to the user

 Do not place or keep this product near heat sources such as direct sunlight radiators stoves or any other apparatus that produces heat. This may cause an explosion, degrade the performance and/or reduce battery life

 Do not modify, repair or disassemble device (especially the battery). Doing so will void the warranty. The battery in this device may present a risk of fire or chemical burns if misused or tampered with. · Use only supplied and manufacturer-approved chargers and unplug this device when not in use for long periods of time or during lightning storms

FCC Statemen

Operation is subject to the following two conditions:

1. This device may not cause harmful interference 2. This device must accept any interference received, including interference that may cause undesired

operatio Note: Any changes or modifications to this unit not expressly approved by the party responsible fo compliance could void the user's authority to operate the equipment.

EC Declaration of Conformity

Operation is subject to the following two conditions:

1 This device may not cause harmful interference 2. This device must accept any interference received, including interference that may cause undesired Note: The manufacturer is not responsible for ANY interference, for example RADIO or TV interference, caused by unauthorized modifications to this equipment. Such modifications could

void the user's authority to operate the equipment. This product is CE certified according to the provision of the R&TTE Directive (99/5/EC). This declares that this product is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC Please note that this product uses radio frequency bands not harmonized within EU. Within the EU this product is intended for use in Austria, Belgium, Denmark, Finland, France, Germany, Greece, Ireland, Italy, Luxembourg, the Netherlands, Portugal, Spain, Sweden, and United Kingdom and within EFTA in Iceland, Norway and Switzerland.

Location of Controls



Battery Information

The device is equipped with an integrated lithium-polymer battery. The battery cannot be replaced. Do not attempt to remove the battery from the device since it would damage the device. The full performance of a new battery is not achieved until after two or three complete charging-discharging cycles. The battery can be charged and discharged several hundred times, but it loses its capacity over time

Disconnect the VL60011BT from the power supply as soon as the battery is fully charged overcharging would reduce the service life of the battery. A charged battery will lose its capacity if it is not used on a regular basis

mportant: Ensure that the battery is fully charged if you do not use the device for a long period of time. To avoid a complete discharge of the battery, the VL60011BT should be charged at least once every 6 months

Charging Your Speaker

The VL60011BT speaker is powered by an internal rechargeable battery. Charge the battery completely before its first use. Read the section titled "Battery information" in this manual before starting the charging process

- Connect one end of the included USB Charging Cable to your speaker's charging port. 2. Connect the other end of the USB Charging Cable to a USB port.
- 3. When your speaker is charging, the red LED indicator light will turn red. The battery will take approximately two hours to fully charge
- When the battery is fully charged, the LED indicator light will turn off. Disconnect the charging cable from your speaker and the outlet. Your speaker is ready to use.

NOTES

- Give your speaker a full charge before using for the first time - When the battery power is low, the indicator light will turn red and start to flash

Turning ON Your Speaker

Before you can start using your speaker, you must first charge the rechargeable battery. Once charged, slide the ON/OFF switch to the ON position to power on your speaker. If your speaker completed the pairing process successfully, when the

speaker is turned on, it will connect to the phone you last connected to automatically. Please ensure your phone's Bluetooth® function is active



Q4-RD-07A0

Damages or malfunctions not resulting from defects in material or workmanship and damages o malfunctions from other than normal use, including but limited to, repair by unauthorized parties tampering, modification or accidents.

Service and Returns

What is NOT Covered

When returning a defective product (postage pre-paid) for service, the package should include 1. Copy of original bill of sale.

2. A detailed written description of the problem 3. Your return address and telephone number (Davtime)

Where to send defective products

United States United Kingdom / Europe Australia Sakar Internationa Sakar International Return faulty device to the Attention: Service Department Attention: Service Department Refund Counter at the store 195 Carter Drive 2D, Siskin Parkway East where the product was Edison, NJ 08817 4020 Middlemarch Business Park purchased. Coventry, CV3 4SU

Technical	Support	

For technical support issues, visit our website at www.vivitar.com. Manuals, software and FAQ's are available on line. If you can't find what you are looking for, e-mail us at support@vivitar.com where one of our technical support team members will help you. US phone: 1-800-592-9541; UK phone: 0800 917 4831; Australia phone: 1800-006-614. Telephone numbers from other countries can be found at: www.vivitar.com

External Audio Input	
The VL60011BT has an AUX-IN port which can be used to	i i c
connect an additional audio source using the 3.5mm Auxiliary	
Cable. When an audio source is plugged in using the 3.5mm	Auxiliary Port -
Auxiliary Cable, any music playing on your speaker will pause and music playing from the plugged in audio source will play instead.	(Local)
Using Your Speaker during a Phone Call	
Last number re-dialing	
Double press the Answer button, the last	
	The VL60011BT has an AUX-IN port which can be used to connect an additional audio source using the 3.5mm Auxiliary Cable. When an audio source is plugged in using the 3.5mm Auxiliary Cable, any music playing on your speaker will pause and music playing from the plugged in audio source will play instead. Note: The VL60011BT supports the A2DP profile which allows stere stream from a Bluetooth phone. The music will pause autom resume when the call has ended. Using Your Speaker during a Phone Call Last number re-dialing



number you dialed will be redialed Answering a call Press the Answer button to answer a incoming call Reject an Incoming Call



discretion · Specifically exempt from any warranty are limited-life consumable components subject to normal if a call is incoming, and wear and tear such as batteries, decorates and other accessories. repair, or modification.

 Modification and repair of the unit should be done by an authorized and qualified service center or returned to the manufacture

local laws.

This warranty is non-transferable and is limited only to the original purchaser. The conditions of this

. You must be able to prove the date of original purchase of the unit with a dated receipt.


. The warranty is not applicable if the product has been subject to physical abuse, improper

warranty and supplier's responsibilities under this warranty are as follows:

What is Covered

Warranty Information

fail to function properly UNDER NORMAL USAGE, due to defects in material or workmanship will be ired at no charge for parts or labor for a period of one year from the time of purchase






· Supplier is not responsible, for failure resulting from accident, abuse, misuse, or any unauthorized

. This warranty gives you specific legal rights, and you may also have other rights, which vary under

This warranty covers for the original consumer purchaser only and is not transferable. Products that



Press and hold the Answer button for two seconds to reject an incoming call. Ending a call Press the Answer button to end a call ALKINO

Before you use your speaker the first time, you must pair it with a Bluetooth[®] enabled mobile phone. Pairing is a one time process and required only for the first connection with