



## 802.11ax-HE20 - Ant 1

## Channel 01 (5955MHz)

## The Reference Level




## The Mask Data




## Channel 49 (6195MHz)

## The Reference Level




## The Mask Data




## Channel 93 (6415MHz)

## The Reference Level




## The Mask Data




## 802.11ax-HE20 - Ant 1

## Channel 97 (6435MHz)

## The Reference Level




## The Mask Data




## Channel 105 (6475MHz)

## The Reference Level




## The Mask Data




## Channel 113 (6515MHz)

## The Reference Level




## The Mask Data




## 802.11ax-HE20 - Ant 1

## Channel 117 (6535MHz)

## The Reference Level




## The Mask Data




## Channel 149 (6695MHz)

## The Reference Level




## The Mask Data




## Channel 181 (6855MHz)

## The Reference Level




## The Mask Data




## 802.11ax-HE20 - Ant 1

## Channel 185 (6875MHz)

## The Reference Level




## The Mask Data




## Channel 189 (6895MHz)

## The Reference Level




## The Mask Data





## Channel 209 (6995MHz)

## The Reference Level



## The Mask Data







## 802.11ax-HE40 - Ant 1

## Channel 03 (5965MHz)

## The Reference Level




## The Mask Data




## Channel 51 (6205MHz)

## The Reference Level




## The Mask Data




## Channel 91 (6405MHz)

## The Reference Level




## The Mask Data




## 802.11ax-HE40 - Ant 1

## Channel 99 (6445MHz)

## The Reference Level




## The Mask Data




## Channel 107 (6485MHz)

## The Reference Level




## The Mask Data




## Channel 115 (6525MHz)

## The Reference Level




## The Mask Data




## 802.11ax-HE40 - Ant 1

## Channel 123 (6565MHz)

## The Reference Level




## The Mask Data




## Channel 147 (6685MHz)

## The Reference Level




## The Mask Data




## Channel 187 (6885MHz)

## The Reference Level



## The Mask Data







## 802.11ax-HE40 - Ant 1

## Channel 195 (6925MHz)

## The Reference Level




## The Mask Data




## Channel 211 (7005MHz)

## The Reference Level




## The Mask Data




## Channel 227 (7085MHz)

## The Reference Level




## The Mask Data




## 802.11ax-HE80 - Ant 1

## Channel 07 (5985MHz)

## The Reference Level




## The Mask Data




## Channel 55 (6225MHz)

## The Reference Level




## The Mask Data




## Channel 87 (6385MHz)

## The Reference Level




## The Mask Data




## 802.11ax-HE80 - Ant 1

## Channel 103 (6465MHz)

## The Reference Level




## The Mask Data




## Channel 119 (6545MHz)

## The Reference Level




## The Mask Data




## Channel 135 (6625MHz)

## The Reference Level




## The Mask Data




## 802.11ax-HE80 - Ant 1

## Channel 151 (6705MHz)

## The Reference Level




## The Mask Data




## Channel 167 (6785MHz)

## The Reference Level




## The Mask Data




## Channel 183 (6865MHz)

## The Reference Level




## The Mask Data




## 802.11ax-HE80 - Ant 1

## Channel 199 (6945MHz)

## The Reference Level




## The Mask Data




## Channel 215 (7025MHz)

## The Reference Level




## The Mask Data




## 802.11ax-HE160 - Ant 1

## Channel 15 (6025MHz)

## The Reference Level




## The Mask Data




## Channel 47 (6185MHz)

## The Reference Level




## The Mask Data




## Channel 79 (6345MHz)

## The Reference Level




## The Mask Data




## 802.11ax-HE160 - Ant 1

## Channel 111 (6505MHz)

## The Reference Level




## The Mask Data




## Channel 143 (6665MHz)

## The Reference Level




## The Mask Data




## Channel 175 (6825MHz)

## The Reference Level



## The Mask Data





802.11ax-HE160 - Ant 1

Channel 207 (6985MHz)

The Reference Level

The Mask Data







## 802.11ax-HE20 - Ant 2

## Channel 01 (5955MHz)

## The Reference Level




## The Mask Data




## Channel 49 (6195MHz)

## The Reference Level




## The Mask Data




## Channel 93 (6415MHz)

## The Reference Level




## The Mask Data




## 802.11ax-HE20 - Ant 2

## Channel 97 (6435MHz)

## The Reference Level




## The Mask Data




## Channel 105 (6475MHz)

## The Reference Level




## The Mask Data




## Channel 113 (6515MHz)

## The Reference Level




## The Mask Data




## 802.11ax-HE20 - Ant 2

## Channel 117 (6535MHz)

## The Reference Level




## The Mask Data




## Channel 149 (6695MHz)

## The Reference Level




## The Mask Data




## Channel 181 (6855MHz)

## The Reference Level




## The Mask Data




## 802.11ax-HE20 - Ant 2

## Channel 185 (6875MHz)

## The Reference Level




## The Mask Data




## Channel 189 (6895MHz)

## The Reference Level




## The Mask Data





## Channel 209 (6995MHz)

## The Reference Level



## The Mask Data







## 802.11ax-HE40 - Ant 2

## Channel 03 (5965MHz)

## The Reference Level




## The Mask Data




## Channel 51 (6205MHz)

## The Reference Level




## The Mask Data




## Channel 91 (6405MHz)

## The Reference Level




## The Mask Data




## 802.11ax-HE40 - Ant 2

## Channel 99 (6445MHz)

## The Reference Level




## The Mask Data




## Channel 107 (6485MHz)

## The Reference Level




## The Mask Data




## Channel 115 (6525MHz)

## The Reference Level




## The Mask Data




## 802.11ax-HE40 - Ant 2

## Channel 123 (6565MHz)

## The Reference Level




## The Mask Data




## Channel 147 (6685MHz)

## The Reference Level




## The Mask Data




## Channel 187 (6885MHz)

## The Reference Level



## The Mask Data







## 802.11ax-HE40 - Ant 2

## Channel 195 (6925MHz)

## The Reference Level




## The Mask Data




## Channel 211 (7005MHz)

## The Reference Level




## The Mask Data




## Channel 227 (7085MHz)

## The Reference Level




## The Mask Data




## 802.11ax-HE80 - Ant 2

## Channel 07 (5985MHz)

## The Reference Level




## The Mask Data




## Channel 55 (6225MHz)

## The Reference Level




## The Mask Data




## Channel 87 (6385MHz)

## The Reference Level




## The Mask Data




## 802.11ax-HE80 - Ant 2

## Channel 103 (6465MHz)

## The Reference Level




## The Mask Data




## Channel 119 (6545MHz)

## The Reference Level




## The Mask Data




## Channel 135 (6625MHz)

## The Reference Level




## The Mask Data




## 802.11ax-HE80 - Ant 2

## Channel 151 (6705MHz)

## The Reference Level




## The Mask Data




## Channel 167 (6785MHz)

## The Reference Level




## The Mask Data




## Channel 183 (6865MHz)

## The Reference Level




## The Mask Data




## 802.11ax-HE80 - Ant 2

## Channel 199 (6945MHz)

## The Reference Level




## The Mask Data




## Channel 215 (7025MHz)

## The Reference Level




## The Mask Data




## 802.11ax-HE160 - Ant 2

## Channel 15 (6025MHz)

## The Reference Level




## The Mask Data




## Channel 47 (6185MHz)

## The Reference Level




## The Mask Data



## Channel 79 (6345MHz)

## The Reference Level



## The Mask Data

