

## Internal Photographs

EUT - Open View



EUT - PCB View

Antenna Location









