

On/Off
 Marche/Arrêt
 On/Off
 conectado/desconectado

Fully Functional
 Completamente funzionante • Completamente
 funcional • Entierement fonctionnel



Left • Gauche
 Sinistra • Izquierda



Straight • Diritto
 Recto • Tout droit

Right • Droite
 Destra • Derecha

Forward • Avant
 Avanti • Adelante

Stop
 Arrêt
 Stop
 Parar

Reverse • Arrière
 Indietro • Atrás



Requires 1 9V battery (included)
 Fonctionne avec 1 pile 9V (fournies)
 Necessita di 1 batteria 9V (includa)
 Se requieren 1 pila 9V (incluidas)

Lightning McQueen



Fonctionne avec 3 piles AAA (fournies)
 • Se requieren 3 pilas AAA (incluidas)

Warning: Changes or modification not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.