




USER MANUAL




Wireless Keyboard




- Starting Bluetooth Keyboard(For MAC System)
Switch on the keyboards,press"Connect"button,then you will see the blue led flash,Bluetooth is looking for the pair device



- Open "setting" of the iPad, chose "General", and click on the Bluetooth button "On", the iPad will looking for the pair device by itself



- When the device "Bluetooth Keyboard" showed on the screen of Pad,click it,they will connect and pair,need to enter the pin code by keyboard,Each time require different pin code,no need to record it,Pin code will be showed on iPad or iPhone when connected.



- When you see "connected" on the iPad, the connection indicator will go out.




Starting Bluetooth Keyboard(For Windows System)


- Switch on the Bluetooth keyboard;press the "connect" button,Blue LED will flash,the Bluetooth Keyboard is ready to connecting and pair with PC.

Start-Setting- Control Panel-Add device (Windows XP, Windows2000)

Start-Control Panel- Add Device(Windows 7.Vista),your PC will search Bluetooth device by itself.



- If find "Bluetooth Keyboard",click it and add,enter the pin code which displayed in PC screen by Bluetooth keyboard,(The pin code is different when every connect, no need to record).



FCC Certification Requirements

Caution: Any changes or modifications in construction of this device which are not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.