

User manual

一、1、 This K/B and mouse use a frequency of 2.4GHZ ,can work with 360 degrees.and with many internet hot keys ,can be used more than 10 meters which can be used more convience and satisfactory.

2、 Wireless K/B use battery as the power,many power save ways have beed used . The K/B can be change to sleep mode when don' t use any keys within 5 miniutes. then the MCU will stop to work ,the receive light will glint to show that the connection is cut off.at such time when press any key the K/B can wake up and work again automatic.

二、 Combine parts: K/B, Wireless Mouse, receiver, two alkalescence batteries,two rechargeable batteries,a connection cable,a driver and user manual.

三、 User guide:

1、 Release your formal K/B, mouse and the driver for your formal K/B also included.

2、 Put batteries to the K/B and mouse.

3、 Put the connector to your PC USB port, and then the match code light will glint slowly.

4、 Receiver ,Keyboard and mouse to match the ID code.

4.1 Press the receiver's match code switch, the instruction light will glint quickly,then press the K/B or Mouse's match code ,If the instruction light can chang from quick glint to slow glint,that means three of them matches. (all the match should be finished within 15 seconds) If more than 15 seconds ,Please rework as above.

4.2 The other's ID code match is the same as 4.1


4.3 When both the K/B and mouse are match well ,then the instruction light of Receiver will illuminated all the time ,that means the K/B and mouse can work .

5、 Low power instruction:

5.1 K/B use two batteries as the power,if the voltage lower than designed voltage ,then the low power instruction light will glint .at this time ,please change the batteries.

5.2 When the mouse' s power voltage lower than work voltage ,the mouse may can not work normally,and the low instruction light will glint,at this time please charge the batteries about 6 hours


四、 Function



1、 Mouse:

1、 Left key; 2、 Middletrolley; 3、 back; 4、 forward; 5. right key

2、 Keyboard



1 2 3 4 5 6 7 8 9

- 1、 Back: Back, back to the formal item you have already scan .such as web browser
- 2、 Web site: Goes to web home page
- 3、 Email: Calls the email application
- 4、 Forward: Changes to the previous media track
- 5、 Pre-track : Change to the formal media
- 6、 Stop: Stop the media play,when press “ Play/Pause” then the media will play again.
- 7、 Play/Stop: Change media play and stop.If it is stop, press this key again then it will play again.
- 8、 Next-track : Change to next media ,each press ,it will be go next media
- 9、 Sleep:If the system support the power management and the power management is used,then the system will enter into Power management mode.If the system doesn't support the power management ,the Hot keys can not be used.

五、 Install the Driver:

- 1、 Driver for the hot keys is needed on operating system of lower than Windows 2000.
- 2、 Before install the driver ,please release all the other K/B and Mouse's driver.
- 3、 Insert the CD-ROM to the computer. And run Keyboard setup.exe.

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.